

Operating Instructions

Compact Scale Puro® Count



98628-000-63

Edition 1.0.0

03/05/2020

Foreword

Must be followed!

Any information in this document is subject to change without notice and does not represent a commitment on the part of Minebea Intec unless legally prescribed. This product should only be operated/installed by trained and qualified personnel. In correspondence concerning this product, the type, name, and release number/serial number as well as all license numbers relating to the product have to be cited.

Note

This document is partially protected by copyright. It may not be changed or copied, and it may not be used without purchasing or written permission from the copyright owner (Minebea Intec). The use of this product constitutes acceptance by you of the abovementioned provisions.

Table of contents

1	Introduction.....	4
1.1	Read the manual.....	4
1.2	This is what operating instructions look like.....	4
1.3	This is what lists look like.....	4
1.4	This is what menu items and softkeys look like.....	4
1.5	This is what the safety instructions look like.....	4
2	Safety instructions.....	6
2.1	General safety information.....	6
2.2	Incoming goods inspection.....	6
2.3	Before operational startup.....	6
3	Device installation.....	7
3.1	Package Contents.....	7
3.2	Requirements on location.....	7
3.3	Leveling the equipment.....	7
3.4	Power supply.....	8
3.4.1	Battery Power.....	8
3.5	Connect printer.....	9
3.6	Connect scanner.....	9
4	Device description.....	10
4.1	Operating.....	10
4.1.1	Display and operating elements.....	10
5	Operation.....	14
5.1	Basic Weighing Function.....	14
5.1.1	Turn on the device.....	14
5.1.2	Turn off the device.....	14
5.1.3	Adjust GEO setting.....	14
5.1.4	Display Functions.....	15
5.1.5	Digit.....	15
5.1.6	Unloaded Scale.....	15
5.1.7	Enter Values.....	15
5.1.8	Initializations.....	15
5.1.9	Active Applications for the first start up.....	15
5.1.10	Two scales.....	15
6	Application Programs.....	17
6.1	General Information.....	17
6.2	Weighing Mode.....	17
6.2.1	Stability.....	17

6.2.2	Taring	17
6.2.3	Preset Tare	18
6.2.4	Weight Unit switch.....	18
6.2.5	Printouts.....	19
6.3	Counting Mode	19
6.3.1	Initialization Mode	19
6.3.2	Running Mode (without Checkweighing).....	20
6.3.3	Printouts (without Checkweighing).....	21
6.4	Check Mode	21
6.4.1	Check Weighing Modes	21
6.4.2	Check Weight values	22
6.4.3	Check number of pieces.....	24
6.4.4	Menu settings.....	27
6.5	Totalization Mode.....	27
6.5.1	Menu Selection.....	27
6.5.2	Running Modes	27
6.6	Auto-Tare	30
6.6.1	Menu Selection.....	30
6.6.2	Running Mode	30
6.7	Auto-Print.....	31
6.7.1	Menu-Selections	31
6.7.2	Running Mode	31
6.8	Product Memory.....	32
6.8.1	Storing Product Data.....	33
6.8.2	Load Product Parameters.....	33
6.8.3	Change/Define Product Parameters	34
6.8.4	Delete Product Storage/Parameters	39
6.8.5	Printouts.....	39
6.9	Handling Second Scale	39
7	Menu Settings	41
7.1	Menu Representation on Displays	41
7.2	Menu Mode.....	43
7.3	Handling Input Values in menu	45
7.4	Menu Navigation	45
7.4.1	Menu Selection [METRO].....	45
7.4.2	Menu Selection [UNIT]	46
7.4.3	Menu Selection [OP.FUNC].....	46
7.4.4	Menu Selection [PRINT]	48
7.4.5	Menu Selection [PRN.COM]	49
7.4.6	Menu Selection [PC.OUT]	50
7.4.7	Menu Selection [PC.COM]	51
7.4.8	Menu Selection [CAL.ADJ].....	51

7.4.9	Menu Selection [AD.CON2]	52
7.4.10	Menu Selection [INFO]	52
7.4.11	Menu Selection [SECURE].....	53
8	Calibration and Adjustment	54
8.1	Calibration	54
8.1.1	Calibration/Adjustment Procedure	54
8.1.2	Menu Settings	56
8.2	Linearization.....	56
8.2.1	Linearization Procedure.....	56
8.2.2	Menu Settings	57
8.3	Geographical Factor Adjustment Procedure.....	57
8.4	GEO Code Table	59
9	Printing.....	61
9.1	Output Format	61
9.2	Product Storages	62
9.3	Menu settings Print.....	62
10	PC-OUT	64
10.1	Output Format	64
10.2	Menu settings PC-OUT	64
11	SBI Interface	65
12	Maintenance/repairs/cleaning.....	67
12.1	Repairs.....	67
12.2	Cleaning	67
12.2.1	Cleaning instructions.....	67
12.2.2	Cleaning agents.....	67
13	Disposal	68
14	Troubleshooting	69
14.1	Service Information	69
15	Technical data	70
15.1	Ambient Conditions	70
15.2	Specifications	70
15.3	Accessories	71
15.4	Dimensions	72
16	Appendix	75
16.1	Printouts	75
16.2	FCC Note	77

1 Introduction

1.1 Read the manual

- Please read this manual carefully and completely before using the product.
- This manual is part of the product. Keep it in a safe and easily accessible location.

1.2 This is what operating instructions look like

- 1. - n. are placed before steps that must be done in sequence.
- ▶ is placed before a step.
- ▷ describes the result of a step.

1.3 This is what lists look like

- indicates an item in a list.

1.4 This is what menu items and softkeys look like

[] frame menu items and softkeys.

Example:

[Start]- [Applications]- [Excel]

1.5 This is what the safety instructions look like

Signal words indicate the severity of the danger involved when measures for preventing hazards are not followed.

DANGER

Warning of personal injury

DANGER indicates death or severe, irreversible personal injury which will occur if the corresponding safety measures are not observed.

- ▶ Take the corresponding safety precautions.

WARNING

Warning of hazardous area and/or personal injury

WARNING indicates that death or severe, irreversible injury may occur if appropriate safety measures are not observed.

- ▶ Take the corresponding safety precautions.

CAUTION

Warning of personal injury.

CAUTION indicates that minor, reversible injury may occur if appropriate safety measures are not observed.

- ▶ Take the corresponding safety precautions.

NOTICE**Warning of damage to property and/or the environment.**

NOTICE indicates that damage to property and/or the environment may occur if appropriate safety measures are not observed.

- Take the corresponding safety precautions.

Note:

User tips, useful information, and notes.

2 Safety instructions

2.1 General safety information

Follow these safety precautions:

- The equipment may only be used as intended for weighing tasks.
- The device may only be opened by authorised personnel.
- Observe the operating limits of the device.
- Ensure that the supply voltage at the installation site matches the AC input voltage indicated on the data label.
- Avoid shock stress (falling down, hard shocks, falling loads, any impact from the side).
- Do not use the equipment in hazardous areas and unstable environments.
- Do not expose the equipment to aggressive chemical vapors or to unnecessarily extreme temperatures, moisture, or vibration.
- Unplug the device before you connect or disconnect any electronic peripheral devices to or from the interface port.
- Unplug the power cord from the mains supply before cleaning.
- Make sure that no liquid enters the equipment.
- Do not use loads that exceed the capacity of the scale.

2.2 Incoming goods inspection

The shipment must be checked for completeness. A visual inspection must be performed to determine if the shipment has been damaged. If there are grounds for a complaint, this must be brought to the attention of the delivery company immediately. A Minebea Intec sales or service point must be informed. Visit our website <http://www.puroscales.com> or contact your dealer.

2.3 Before operational startup

NOTICE

Perform visual inspection.

Before operational startup as well as after storage or transport, inspect the product visually for signs of mechanical damage.

- The product may not be put into operation if it has visible damage and/or is defective.

3 Device installation

3.1 Package Contents

- Scale
- Sub-platform
- Safety Instructions and QR code with access to the detailed documentation
- Pan
- USB power supply and cord

3.2 Requirements on location

- Set up the device on a stable, even surface.
- Position the device so that the power plug is freely accessible and the power cord is not an obstacle or trip hazard.
- Avoid placing the device in close proximity to a heater or otherwise exposing the scale to heat or direct sunlight.
- Do not expose the device to excessive temperature fluctuations.
- Protect the device from drafts that come from open windows or doors.
- Avoid exposing the device to extreme vibrations during weighing.
- Protect the device from aggressive chemical vapors.
- Do not expose the device to extreme moisture over long periods.

NOTICE

Acclimatizing the device

Condensation can form on the surfaces of a cold device when it is brought into a substantially warmer area.

- Unplug the device from the power supply and allow it to acclimatize for about 2 hours at room temperature.

3.3 Leveling the equipment


Purpose:

- to compensate for unevenness at the place of installation
- to ensure that the device is placed in a perfectly horizontal position for consistently reproducible weighing results

Always re-level the device any time after it has been moved to a different location.

- Level the scale using the four leveling feet.
- Ensure that all leveling feet make contact with the floor.
- Turn the feet until the air bubble is centered in the level indicator.
 - ▷ Each of the leveling feet must support an equal load.

- Adjusting the leveling feet: To raise the scale, extend the leveling feet (turn clockwise). To lower the weighing platform, retract the leveling feet (turn counterclockwise).



3.4 Power supply

AC power is used to power the scale when battery power is not needed.
Plug the USB-C plug into the USB-C jack on the bottom of the unit, then plug the AC power supply into a wall outlet.

Note:

Do not use the USB-C power supply cable for the PC communication. Instead use a standard USB-C cable.

3.4.1 Battery Power

The scale can be used on AC power immediately. Allow the battery to charge for 12 hours before using the scale on battery power. The Scale will automatically switch to battery operation if there is a power failure or the power cord is removed. With AC power, the scale is constantly charging, so the battery charge indicator (see Chapter [4.1.1.2](#)) will remain lit. The scale can be operated during charging, and the battery is protected against overcharging.

When the device is switched on, the battery status LED lights red while the battery is charging and green when the battery is fully charged.

For maximum operating time, the battery should be charged at room temperature.

During battery operation, the battery symbol indicates the battery charge level remaining. The indicator will automatically turn off when the batteries are empty.

Symbol	Charge level
	0 to 10 % Remaining
	11 to 40 % Remaining
	41 to 70 % Remaining
	71 to 100 % Remaining

Note:

When battery symbol blinks fast, approximately 30 minutes working time is left.

When [lo.bat] is displayed, the scale will shut off.

Charging the scale must be performed in a dry environment.

⚠ WARNING

Risk of explosion can occur

If the rechargeable battery is replaced with the wrong type or if it is not properly connected.

- ▶ Battery is to be replaced only by an authorized Puro® service dealer.
- ▶ Dispose of battery according to local laws and regulations.

If the hardware can't recognize a connected ACCU, it is defined:


Battery	USB-C Cacle	Charging LED Light	Display Icon
Battery Not Full	Plug-in	Red	No Icon
Battery Full	Plug-in	Green	No Icon
No Battery install	Plug-in	Red	No Icon
Battery Not Full	Unplug	Turn off	Battery Content
Battery Full	Unplug	Turn off	Battery Full

3.5 Connect printer

A printer can be connected to the printer port on the underside of the device.

3.6 Connect scanner

Connect scanner according to the following figure. The product may only be connected using the original cable YP-CYSSR1.



4 Device description

4.1 Operating


4.1.1 Display and operating elements

- Overview, see Chapter [4.1.1.1](#).
- Display elements, see Chapter [4.1.1.2](#).
- Operating elements, see Chapter [4.1.1.3](#).


4.1.1.1 Overview

Display definitions:

- Display-Weight = little display on the left side
- Display-PW (Piece Weight) = little display on the right side
- Display-Count = bigger display in the middle




Control Panel.




No.	Description
1	Display elements, see Chapter 4.1.1.2 .
2	Operating elements, see Chapter 4.1.1.3 .

4.1.1.2 Display elements




LCD Display



Item	Description	Item	Description
1	Busy	2	Plus symbol
3	Minus symbol	4	Zero-setting
5	Counting	6	Weighing
7	Checkweighing	8	Totalizing
9	Auto Taring or Auto Reference Optimization Symbol	10	Low Average Piece Weight
11	Low Sample Weight	12	Two scales are active
13	Number of the active scale	14	Data transfer
15	Weight unit	16	Battery charge
17	Warning symbol	18	Printer Icon
19	NET, Preset Tare, Gross	20	Pieces

LED indicators



The colored LED indicators (1) on the right side of the Count control panel are used in Check mode (see Chapter 6.4.2.2) and will light up according to the following rules:

	(Red) Weight value > upper tolerance limit (Green) Weight value ≤ ≥ is within OK range (Yellow) Weight value < lower tolerance limit
--	--

4.1.1.3 Operating elements

Button	Primary Function (short press) < 1 second	Secondary Function (long press) hold > 2 second
	On/Zero Power on the scale (when scale is off). Set zero (when scale is on).	Off Power off the scale.
	Print Sends the current value to the selected COM ports if AUTO-PRINT is set to off.	Unit Changes the weighing unit.
	Target Set Check limits, if Check Mode is WEIGHT or COUNT.	Select the Check Mode
	M+ Write into the Totalization Storage or exit any input process.	Menu Enter the user menu.
	Mem Store or load a Product	Start Product definition
	Sample Set number of reference weights	
	APW Set Piece Weight	

Button	Primary Function (short press) < 1 second	Secondary Function (long press) hold > 2 second
	Tare Set or clear a tare value	Clear Totalization storage
	0...9 Input characters	
	* 12	Change Scale
	C +/- Clear the last input charcter or ends the display of the totalization values.	Toggles the sign


Buttons Menu Navigation


Button	Menu Function (short press) < 1 second
	Yes Accepts the current setting on the display.
	No Rejects the current setting on the display and advances to the next available setting. Advances to the next menu or item. Show next value.
	Back Moves back to previous menu items. Show prvious value.
	Exit Exits the user menu. Aborts the calibration in progress.

5 Operation

5.1 Basic Weighing Function


5.1.1 Turn on the device

- ▶ Press the  Button for a short time.
 - ▷ All Elements of **all** displays will be shown for 2 seconds.
 - All Checkweighing LEDs are ON for 2 seconds.




After this time the software version number [SR 2.5] is shown for 2 seconds on the Display-Weight and also on the Display-PW the selected Geo area like: [GEO 12] is shown for the same time. The Display-Count is empty.

Weight



Piece Weight




The latest active (selected) application combination before turning OFF the device will be started. If the applications were already initialized, they start with these parameters.

Default unit for the very first start is [kg].

If a second scale is defined in menu then device starts up always with WP1.

5.1.2 Turn off the device

- ▶ Press the  Button for a long time.
 - ▷ The Display-Count will show [-OFF-] for about 2 seconds.

Count



The other displays are dark. After that time the device switches off and all displays are dark.

This button is active in **ALL** application and menu states!


5.1.3 Adjust GEO setting

Adjust the GEO setting according to your location to ensure accurate weighing results. See Chapter [8.3](#).

5.1.4 Display Functions

In normal weighing mode the displays have the following functionalities:

- Display-Weight shows the actual weight value with the selected unit.
- Display-PW shows the actual piece weight with the gram or ounce.
- Display-Count shows the calculated number of pieces with unit pcs.

The "Charging" Symbol  is only shown on the Display-Weight if there is an ACC connected.

The "Weighing" Symbol  12 is only shown on the Display-Weight.

If there is only one scale the "Weighing" Symbol is dark. Only if two scales are the "Weighing" Symbol is visible on Display-Weight!

5.1.5 Digit

One "d" represents the lowest displayable weight value.

For example $d = 0,02g \rightarrow 2d = 0,04g \rightarrow 3d = 0,06g$


5.1.6 Unloaded Scale


A scale is unloaded generally when the weight on the pan is below $2d$ ($<2d$).

5.1.7 Enter Values

Values can be entered via the key pad and are shown on the Display-Count.

All inputs starts with a dark display and on the right side with a blinking under line

(cursor) at the last digit. The input can be corrected via the  Button which deletes the last digit of the input.

The  decimal button as first input Character is also alternatively allowed. Then the software added the zero before the decimal point automatically.

5.1.8 Initializations

During any initialization process an activation of the menu isn't possible!

5.1.9 Active Applications for the first start up

For the very first start of the device the applications "Weighing" and "Totalization" are activated automatically and Checkweighing is OFF.

5.1.10 Two scales

A second platform can be connected to realize a counting system consisting of a reference scale and a scale for larger quantities.

Each scale has a separate serial number with 13 characters.

Number design:

- Serial number of Weighing scale 1: W1 38457989
- Serial number of Weighing scale 2: W2 38457989

Printed is:

```
SERNO: W1 38457989
SERNO: W2 38457989
```

Displayed is in [INFO] in menu:
[W1 38457989] and [W2 38457989]

6 Application Programs

6.1 General Information

Counting is the main application which is always active.


The scale is always started with Counting.

The following applications can be activated parallel to counting:

- Check weighing (in two modes: Check-Weighing and Check-Count).
- Totalization which accumulates pieces or weights.
- Automatic Tare.
- Automatic Print.

There is a Product Storage for 30 products.

6.2 Weighing Mode

If Counting isn't initialized (piece weight = 0) then the application symbol weight  is shown on Display-Weight.

Weight



6.2.1 Stability

The weighing value and the application symbols are displayed on Display-Weight.

If a weighing value is stable, the unit symbol shall be displayed on Display-Weight and also on Display-Count:


stable:	[2.342 kg]	and [47 pcs]
unstable:	[2.342]	and [47]

and printed:

stable:	2.342 kg , 47 pcs
unstable:	2.342 , 47

Stable weighing value on Display-Weight:

Weight



6.2.2 Taring


- ▶ Press the  Button briefly for taring if the pan is loaded.

- ▷ On the Display-Weight the [NET] Symbol is shown.


While the taring process is in action the Busy-Symbol is shown on Display-Weight without a weighing value and the Display-Count is dark.

Tared value on Display-Weight:

Weight




6.2.3 Preset Tare

There is only **one** Tare storage in the device which contains either a measured weight value (pressing  button) or an entered value (Preset Tare).

1. Enter a weighing value like [0.010] via the numeric keypad or a Scanner.
 - ▷ This value is shown on the Display-Count.

Count




2. Press the  Button briefly.
 - ▷ The input value is set as Preset-Tare with the actual unit and overwrites the actual value in the Tare storage.


The weight value on Display-Weight is calculated with this Preset Tare value advance.


The actual number of pieces on the pan is recalculated and displayed on the Display-Count.

Clearing Preset Tare by:

3. Pressing  Button when pan is unloaded.
 - ▷ Clear Tare storage.


Set new Tare value by:

Pressing  Button when pan is loaded, then the Tare storage is overwritten with the weight on the pan.

Or pressing  Button when pan is unloaded. Clear Tare storage.
After Turning OFF the device Preset Tare is also cleared.

6.2.4 Weight Unit switch

You can toggle the display of a weight value between different weight units.

- ▶ Pressing the  Button for a long time will change the displayed unit.
Possible units are: gram [g], kilogram [kg], pound [lb], ounce [oz], pound-ounce [l:o].
Only such units that have been activated in the menu can be changed.
While the button is pressed the unit will change and after about 2 second the next unit will be displayed and so on, until the button is released.
The units switch results on Display-Weight and Display-PW:

Units on Display-Weight	Units on Display-PW
kilogram	gram
gram	gram
pound	ounce
ounce	ounce
pound : ounce	ounce

6.2.5 Printouts

Printout elements are configured in menu.

Printout	Description
5.003 g N	positive netto weight value
- 0.003 g N	negative netto weight value
2.003 g G	positive measured gross weight value
2.003 g G#	positive calculated gross weight value
1.003 g T	tare weight value (measured value)
0.010 g PT	preset tare value (entered value)
- 0.010 ! G	stable gross weight below zero

6.3 Counting Mode

Scale starts up with counting. If a piece weight was set before turning OFF the device, the device starts up with this piece weight again.

Counting is always active. But it might be uninitialized.

If there is no piece weight initialized both Display-PW and Display-Count show [0.] and

the application symbol weight  is displayed on Display-Weight.

The device starts up with Totalization activated.

Weight



Counting isn't initialized

Weight



Counting is initialized

6.3.1 Initialization Mode

- Initialization by Sample (see chapter [6.3.1.1](#))
- Initialization by known Piece Weight (see chapter [6.3.1.2](#))

Count-Initialization is only possible on scale 1! Initialization is done with the internal scale resolution.

6.3.1.1 Initialization by Sample

This initialization only takes place if the weight values are stable.


- Initialization (see chapter [6.3.1.1.1](#))
- Initialization negative Sample (see chapter [6.3.1.1.2](#))

These initializations are also possible if already a piece weight is calculated.


The input can be corrected via the  Button which deletes the last digit of the input.

If the pan is unloaded (<2d) then the error message [REF.ERR] is displayed on Display-PW for about two seconds.

Piece Weight




6.3.1.1.1 Initialization

1. Put a number of pieces on the pan.
2. Input the desired number of pieces on the pan via the key pad (only integer values) or a scanner.
 - ▷ The input value will be displayed on Display-Count.
3. Then press the  Button briefly.
 - ▷ The new calculated piece weight is displayed on Display-PW and the actual calculated number of pieces is displayed on Display-Count.


6.3.1.1.2 Initialization negative Sample

If a negative Sample is required (= removing samples from a container):

1. Put a filled container on the pan.
2. Press the  Button briefly (tare the weight).
3. Remove a number of pieces from the container.
 - ▷ Now a negative weight value is displayed on Display-Weight.

Go on at step 2 on chapter [6.3.1.1.1](#).

6.3.1.2 Initialization by known Piece Weight


1. Input the desired piece weight via the key pad or a scanner.
 - ▷ The input value will be displayed on Display-Count.
2. Then press the  Button briefly.
 - ▷ The new calculated piece weight is displayed on Display-PW and the actual calculated number of pieces is displayed on Display-Count.








6.3.2 Running Mode (without Checkweighing)

Automatic Reference Optimization (see Chapter [6.3.2.1](#)).


If a piece weight is initialized then it is shown on Display-PW.

- ▶ Put a weight on the pan.
 - ▷ The actual weight value is shown on the Display-Weight.
 - On Display-Count the calculated number of pieces is shown.

Application Symbol count  is displayed on the Display-Weight.


- ▶ Pressing the  Button briefly a printout is generated.
- ▶ Pressing the  Button long the unit switches on Display-Weight and in some cases also on Display-PW (see Chapter 6.4.1).
- ▶ Pressing the  or the  Button briefly or the key pad an initialization is started as described above.
- ▶ Pressing the  Button long or briefly looks at chapter Checkweighing.
- ▶ Pressing the  Button look at chapter product memory.
- ▶ Pressing the  Button the initialization is cleared.

6.3.2.1 Automatic Reference Optimization

If in menu [OP.FUNC] - [A.OPT] - [ON] is set, then the automatic reference optimization is activated. The symbol  is shown on the Display-PW.

Main feature is to calculate automatically the piece weight more exactly.

The optimization calculates the piece weight again if the following conditions are all fulfilled:

- Scale has stability
- No sign change
- The current piece count exceeds the original piece count by at least two. The new piece count must not be more than twice as large as the old piece count (this restriction does not apply to the first optimization if the piece weight was entered using a bar code scanner or keyboard input).
- The internally calculated number of pieces (e.g. 17.24) must deviate by less than ± 0.3 pieces from the whole number (in the example: 17).
- If an optimization has taken place the symbol  is shown on the Display-PW and the new calculated piece weight is also shown in Display-PW.

Automatic Optimization isn't done on scale 2.

6.3.3 Printouts (without Checkweighing)

Normal printout:


Printout	Description
441 pcs QNT	positive value
- 41 pcs QNT	negative value
MODE: COUNT	activated Application
WREF 4.15431 oz	piece weight, same value as shown on Display-PW

6.4 Check Mode


For Check Weighing there are limit LEDs which signal the actual range.

6.4.1 Check Weighing Modes

While Counting is running Check Weighing Modes can be activated via  Button.

► Press the  Button long and hold it.

▷ [CHECK] is shown on Display-Weight.






The activated Check Mode is shown on the Display-PW for about 2 seconds. Display-Count is dark.


After this waiting time the next mode is displayed and so on. If the  Button is released the mode displayed on Display-PW is selected.

Possible Check Modes are:

[OFF]	Checking is off.
[WEIGHT]	Check Weighing is active
[COUNT]	Check Count is active

If Check Mode [WEIGHT] is activated and Count isn't initialized then the Display-Weight shows the application symbols:  +/-.


But if Counting is initialized the count symbol is shown additional   +/-.


If Check Mode [COUNT] is activated and Count is initialized the Display-Weight shows the symbols:  +/-.



6.4.2 Check Weight values

- Initialize Check Weighing (see chapter [6.4.2.1](#))
- Running Mode (see chapter [6.4.2.2](#))
- Printouts (see chapter [6.4.2.3](#))


6.4.2.1 Initialize Check Weighing

The  Button pressed long generates a minus sign in input mode on Display-Count.

Pressing  (Exit) Button the initialization process is left at once without storing a new input or limit.


Pressing  (No) or  button briefly the blinking limit value is cleared and a blinking cursor is shown on the right side ready for a new input.

Initialization is possible on both scales.

1. After a Check Mode is selected press the  Button briefly.
 - ▷ [SET.LOW] is displayed on the Display-Weight.

Weight



The previous low limit is also displayed on Display-PW with the unit which was active before pressing the  Button.


On the Display-Count this weight value is also shown blinking. The Yellow LED is on.

2. Enter a numeric weight value via the key pad or a scanner which then is displayed on Display-Count.

▷ On Display-Count the same unit is shown as on Display-Weight.


The input value isn't blinking. Only the actual cursor position (marked by an under line) is blinking. Input starts from the right side.


3. Accept the input by pressing  (Yes) Button briefly.

▷ If  (Back) Button is pressed briefly then the input is rejected, the limit isn't changed.

[SET.HI] is displayed on the Display-Weight.

Weight





The previous high limit is also displayed on Display-PW with the unit which was active before pressing the  Button.

On the Display-Count this weight value is also shown blinking. The Red LED is on.

4. Enter a numeric weight value via the key pad or a scanner which then is displayed on Display-Count.

▷ The input value isn't blinking. Only the actual cursor position (an under line) is blinking.

5. Accept the input by pressing  (Yes) Button briefly or press the  (Back) Button then the input is rejected.

▷ If the limit conditions are correct then Check Weighing is initialized.

Count



But if there is an error because e.g. high limit < low limit the Display-Count shows [LIM.ERR] for about 2 seconds then go back to step 1.

The normal Counting mode is active again. Additional the Check LEDs are active if the pan is loaded.

Checking additional weights then both limits must be a positive value.

Checking removed weights then both limits must be a negative value.

Using "Zero Check" then the high limit is a positive and the low limit is a negative value.

Checking exactly a weight the under and over limit must be the same.

6.4.2.2 Running Mode

Limit LEDs:

positive weight	< low limit	Yellow LED will light
positive weight	\geq low limit and \leq high limit	Green LED will light
positive weight	> high limit	Red LED will light
negative weight	> low limit	Yellow LED will light
negative weight	\leq low limit and \geq high limit	Green LED will light
negative weight	< high limit	Red LED will light

Using "Zero Check" the reference weight is put on the pan and then the scale is tared. The reference weight is removed and then the weight to be checked is put on the pan.

6.4.2.3 Printouts

Counting isn't initialized:

Printout	Description
115 g OVER	positive netto value > high limit
- 115 g OVER	negative netto value < negative high limit
99 g ACCEPT	positive netto value in target area
75 g UNDER	positive netto value < low limit
MODE: CHECKWEIGH	activated Application
UNDER LIMIT 81 g	Low Limit
OVER LIMIT 100 g	High Limit

Counting is initialized:


Printout	Description
115 g OVER	positive netto value > high limit
- 115 g OVER	negative netto value < negative high limit
99 g ACCEPT	positive netto value in target area
75 g UNDER	positive netto value < low limit
115 pcs	netto count
MODE: CHECKWEIGH	activated Application
UNDER LIMIT 81 g	Low Limit
OVER LIMIT 100 g	High Limit
WREF 0.35423 g	piece weigh


6.4.3 Check number of pieces



- Initialize Check count (see chapter [6.4.3.1](#))

- Running Mode (see chapter 6.4.3.2)
- Printouts (see chapter 6.4.3.3)


6.4.3.1 Initialize Check Count

The  Button pressed long generates a minus sign in input mode on Display-Count.


Pressing  (Exit) Button the initialization process is left at once without storing a new input or limit.

Pressing  (No) or  button briefly the blinking limit value is cleared and a blinking cursor is shown on the right side ready for a new input.

Initialization is possible on both scales.

1. After a Check Mode is selected press the  Button briefly.
 - ▷ [SET.LOW] is displayed on the Display-Weight.

Weight




The previous low limit is also displayed on Display-PW.

On the Display-Count this number of pieces is also shown blinking. The Yellow LED is on.


2. Enter a number of pieces via the key pad or a scanner which then is displayed on Display-Count.
 - ▷ The input value isn't blinking. Only the actual cursor position (marked by an under line) is blinking. Input starts from the right side.

3. Accept the input by pressing  (Yes) Button briefly.

- ▷ If  (Back) Button is pressed briefly then the input is rejected → the limit isn't changed.

[SET.HI] is displayed on the Display-Weight.



Weight



The previous high limit is also displayed on Display-PW.

On the Display-Count this number of pieces is also shown blinking. The Red LED is on.

4. Enter a number of pieces via the key pad or a scanner which then is displayed on Display-Count.
 - ▷ The input value isn't blinking. Only the actual cursor position (an under line) is blinking.

5. Accept the input by pressing  (Yes) Button briefly or press the  Button then the input is rejected.

▷ If the limit conditions are correct then Check Weighing is initialized.

Count



But if there is an error because e.g. high limit < low limit the Display-Count shows [LIM.ERR] for about 2 seconds then go back to step 1.

The normal Counting mode is active again. Additionally the Check LEDs are active if the pan is loaded.

Checking additional weights then both limits must be a positive value.

Checking removed weights then both limits must be a negative value.

Using "Zero Check" then the high limit is a positive and the low limit is a negative value.

Checking exactly a weight the under and over limit must be the same.

6.4.3.2 Running Mode

- Only number of pieces will be checked.

Limit LEDs:

positive number of pieces	< low limit	Yellow LED will light
positive number of pieces	≥ low limit and ≤ high limit	Green LED will light
positive number of pieces	> high limit	Red LED will light
negative number of pieces	> low limit	Yellow LED will light
negative number of pieces	≤ low limit and ≥ high limit	Green LED will light
negative number of pieces	< high limit	Red LED will light

Using "Zero Check" the reference weight is put on the pan and then the scale is tared. The reference weight is removed and then the weight to be checked is put on the pan.

Show the warning symbol  on Display-Count if unit [pcs] is displayed.

6.4.3.3 Printouts

Counting isn't initialized:

Printout	Description
115 g N	normal netto value as result
MODE: CHECKWEIGH	activated Application
UNDER LIMIT -20 pcs	Low Limit
OVER LIMIT -60 pcs	High Limit

Counting is initialized:

Printout	Description
115 pcs OVER	positive netto count > high limit
- 115 pcs OVER	negative netto count < negative high limit
99 pcs ACCEPT	positive netto count in target area
75 pcs UNDER	positive netto count < low limit
MODE: CHECKWEIGH	activated Application
UNDER LIMIT -20 pcs	Low Limit
OVER LIMIT -60 pcs	High Limit
WREF 0.35423 oz	piece weigh, same as displayed

6.4.4 Menu settings

Regarding Check application there are some more functions which can be activated via the menu:

OP.FUNC

— A.TARE

— OFF

— ON

— ON-ACC

Automatic Tare

disabled* (default setting)

1st stable weight is tared

Stable loads within the accept limits are tared
(in all check modes)

— BEEP.SI

— OFF

— ACCEPT

— UNDER

— OVER

— UNDOVR

Beeper Signal (in Checkweighing Mode)

disabled* (default setting)

Beep when weight is within accept area

Beep when weight is under the low limit

Beep when weight is over the high limit

Beep when weight is outside the accept area

6.5 Totalization Mode

The application symbol is Σ . It is shown only on Display-Weight.

If counting isn't initialized then only weights are accumulated. If counting is already initialized then pieces and weights are accumulated.

Only Net values can be accumulated!

6.5.1 Menu Selection

This application is selectable in menu:

OP.FUNC

— TOT.SET

— OFF

— AUTO

— MAN

Totalization Setting

disabled* (default setting)

Automatic Totalization

Manual Totalization

6.5.2 Running Modes

- Manual Mode (see chapter [6.5.2.1](#))
- Automatic Mode (see chapter [6.5.2.2](#))
- Printouts (see chapter [6.5.2.3](#))

- The statistical information can be shown on the display by briefly pressing the



Button.

But the pan must be unloaded (weight < 2d) too.

The following parameters are displayed for three seconds:

Weight

totalized weight with unit

Piece Weight

number of elements in the sum memory

Count

total number of pieces if counting is active

or the display is dark if only weighing in active!

After the first three seconds are over the next statistical parameters will be shown for three seconds too:

Weight

Text for minimum and maximum value

Piece Weight

minimum weight

Piece Weight

minimum number of pieces

Count


maximum weight

Count

maximum number of pieces if pieces are accumulated


The  Button ends this state and activates the state before.

This state is left automatically when the waiting time is over. It goes on with the state before.




- Clearing the statistical information is done by long pressed  Button.

Therefore the pan must be unloaded: weight on the pan < 2d.

Weight



Then [CLR.TOT] is displayed.

- If the statistical information shall be cleared press  (Yes) Button briefly.
- If the statistical information shall not be cleared press  (No) Button briefly.
- Clearing the counting initialization is done via the  Button pressed briefly or via a new counting initialization which will cause that the Totalization parameters are cleared.


After the sum memory was written the Display-Weight shows the sum weight (= sum value after takeover), Display-PW shows the number of elements in the sum memory after take over, Display-Count shows the content of sum memory (only number of pieces, no weights) after takeover. This state lasts for about 2 seconds.

If a weight or a number of pieces was taken over into the sum memory the symbol will keep flashing until the weight is removed from the pan and the weight < 2d. A new addition can only be started when the pan was unloaded before.

If there are two scales connected then the weights are added accurate to display.


Example: first item in sum memory is taken from WP1 and the second one from WP2:

1,003 kg	// WP1 with accuracy 1 g
+ 5,15 kg	// WP2 with accuracy 50 g
= 6,153 kg	// total = sum memory

Totalization shall be done also with negative weight values (removing mode). Put weights on the pan, press  Button. Then remove first weight. Add to Totalization memory.

Press  Button again. Then remove second weight. Add to Totalization memory.

6.5.2.1 Manual Mode

Stable weights $\geq 2d$ can be accumulated via the  Button pressed briefly. That is also valid for a number of pieces when there is stability.

The next weight / number of pieces can be accumulated if the scale was unloaded before!

6.5.2.2 Automatic Mode

Stable weights $\geq 2d$ shall be accumulated automatically if the scale is unloaded before. That is also valid for a number of pieces if there is stability.

6.5.2.3 Printouts

Min, Max is only printed if ALL is selected in print content [PRINT] - [CONTNT] - [TOTAL] in menu.

Weights as parameters (= weights are added up):

Printout	Description
N: 2	Number of weighing done, here 2
TOTAL: 1.955 g	Totalized value
MAX: 1.485 g	Maximum value
MIN: 0.470 g	Minimum value

Pieces as parameters (= pieces and weights are added up):

Printout	Description
N: 25	Number of weighing done, here 25
TOTAL: 148 g	Totalized value of weights
124 pcs	Totalized value of pieces
MAX: 20 g	Maximum value as weight
10 pcs	Maximum value as number of pieces
MIN: 4 g	Minimum value as weight
2 pcs	Minimum value as number of pieces

6.6 Auto-Tare

Application symbol ^{AUTO} is on Display-Weight.
Weight



6.6.1 Menu Selection

OP.FUNC
 └─ A.TARE
 └─ OFF
 └─ ON
 └─ ON-ACC

Automatic Tare
 disabled* (default setting)
 first stable weight $\geq 2d$ is tared
 Check: every stable weight within the accept
 limits is tared. That means Auto-Tara isn't done
 only for one time!

6.6.2 Running Mode

Normal reaction:

- First weight put on the pan is tared if it is $\geq 2d$.
- If the scale is unloaded ($<2d$) the Tara storage is cleared.

Check weighing applications:

- First option [ON]:
First weight put on the pan is tared if it is $\geq 2d$
- Second option [ON-ACC]:

Only stable values within the accepted limit area is tared if $\text{load} \geq 2d$. Here each weight in the accepted limit area is tared.

This function is executed before automatic print and also before automatic Totalization! Automatic Tare has higher priority as Printing or Totalization. First weight put on the pan is tared. Second weight put on the pan is taken over into the totalization storage and is also printed automatically when "Automatic print" and "Totalization Automatic" is selected in menu.

Auto-Tare isn't active if the menu is active or an initialization process is running.

Auto-Tara isn't active if a Preset-Tare is set before or a product with Preset-Tare has been loaded.

6.7 Auto-Print

A print is done automatically for **one time** if the Netto weight on the pan is $\geq 2d$.

If the weight is removed from the pan and the Netto weight is $< 2d$ then the next Netto weight $\geq 2d$ generates a print.

6.7.1 Menu-Selections

Set conditions at menu point [PRINT]:

PRINT	
— A.PRINT	automatic printout disabled* (default setting)
— OFF	
— ON.STAB	automatic print on stability for one time, if weight $> 1d$
— INTER	automatic print at defined intervals of seconds without stability
— 25	Enter an interval in seconds in range from 1 to 3600
— CONT	automatic print at every weighing cycle without stability
— ACCEPT	automatic print for one time with stability within check limits

6.7.2 Running Mode

- Running Mode general (see chapter [6.7.2.1](#))
- Running Mode: ON STABLE (see chapter [6.7.2.2](#))
- Running Mode: INTER (see chapter [6.7.2.3](#))
- Running Mode: CONTNT (see chapter [6.7.2.4](#))
- Running Mode: ACCEPT (see chapter [6.7.2.5](#))

6.7.2.1 Running Mode general

"Auto-Print" has second priority after "Auto-Tare". First weight on the pan is handled by "Auto-Tare". The second weight on the pan is handled by "Auto-Print".

6.7.2.2 Running Mode: ON STABLE

An automatic printout is generated when the weight value is stable. This may be done delayed. So the printout waits until the weight value is stable.

Each selected element in [PRINT] - [CONTNT] is printed except the functionality like TOTALIZATION if it isn't activated in menu.

This automatic print is generated **after** the weight is accumulated in TOTALIZATION with AUTO-Mode. So TOTALIZATION has higher priority than Auto-Print.

6.7.2.3 Running Mode: INTER

An interval is to be selected in the menu. The selectable steps are in seconds starting from 1 to 3600 second.

Example: 5 seconds are selected, so each 5 seconds a printout is generated automatically. The printout is done when the weight value is stable or not.

Each selected element in [PRINT] - [CONTNT] is printed except the functionality like TOTALIZATION if it isn't activated in menu.



During this state Display-Weight shows [A.PRINT], Display-PW shows [INTER] and Display-Count shows the number of seconds which can be entered via the keypad or a scanner.

6.7.2.4 Running Mode: CONTNT

Each selected element in [PRINT] - [CONTNT] is printed except the functionalities like TOTALIZATION if it isn't activated in menu and Preset Tare when it is empty.

The elements are printed with or without stability as fast as possible.

6.7.2.5 Running Mode: ACCEPT

An automatic print is only generated when one application of "Checkweighing" is activated AND the weight on the pan or the removed weight is within the defined limits.

This automatic print is generated **after** the weight is accumulated in TOTALIZATION with AUTO-Mode.

Each selected element in [PRINT] - [CONTNT] is printed except the functionality like TOTALIZATION if it isn't activated in menu.

6.8 Product Memory



The device has a product memory which contains 30 products at maximum.

Each product contains at minimum:

- Product ID (memory number)
- Product Name = 12 ASCII character long. Via scanner alpha characters are possible!
- Preset Tare value
- Piece Weight
- Checkweighing Low Limit = a weight value or a number of pieces.
- Checkweighing High Limit = a weight value or a number of pieces.

If a Checkweighing limit is unequal to zero then the application Checkweighing is activated. Or if these limits are equal zero then the application Checkweighing is deactivated.

Example: Checkweighing is active. If a product is activated which contains only counting parameters then Checkweighing is set to [OFF] (is deactivated).


If the  Button is pressed briefly and the user wants to end this state (storing or loading) this is done by pressing the  (Exit) Button briefly.

If there are two scales defined in menu then the product can be loaded even the scales have different accuracies. This is the responsibility of the customer.

Contents of Product Id and Product Name are printed when no product is loaded or the product settings were changed or the whole product memory is empty.

6.8.1 Storing Product Data

Requirement for storing: Application is already initialized.

1. Press the  Button briefly.

▷ The displays show:

Weight

STORE

Piece Weight

PROD

Count

MEM 12

= next free product storage number is blinking

The memory number (ID) can be changed via the key pad or scanner.

2. Press the  or  (Yes) Button briefly storing the product parameters.

First product memory has the number 1.

If the Input contains an error e.g. memory number is too big, then Display-Count shows [LIM.ERR] for about 2 seconds.

Count


LIM.ERR


During the storing process the Busy symbol  in Display-Weight is active and the other displays are dark.


The storage memory (ID) is freely selectable. It doesn't have to be the next free one.

If the selected memory is already occupied then this memory is overwritten.

6.8.2 Load Product Parameters


1. Input a product memory number via the key pad or a scanner.
 - ▷ Number is shown on Display-Count.
2. Press the  Button briefly.
 - ▷ The displays show:





3. Pressing the  or  (Yes) Button.


▷ The product parameters of the selected product are loaded.


If the memory is empty then [NO.DATA] is shown on Display-Weight for about 1 second.




After that time the device returns to the state before input the product number.

The product ID in Display-Count can be changed via the  (No) and  (Back) Buttons pressed briefly.

Using the  (No) Button the number is incremented, but only occupied storages are incremented.

Using the  (Back) Button the number is decremented but only occupied storages are decremented.

Example: Storages 1, 2, 5, 7 are occupied. Displayed number is 5 then pressing 


(No) Button → 7 is displayed. Pressing  (Back) → 5 is displayed.

If the entered product ID is too big (>30), then the Display-Count shows for about 2 seconds [LIM.ERR].




6.8.3 Change/Define Product Parameters

Here a present product can be changed or a new product can be defined.

Pressing the  (Exit) Button briefly in any state of this input process the device returns to the state before starting this input process.

1. Input a product ID via the key pad or a scanner.

▷ Number is shown on Display-Count.

2. Press the  Button briefly.

- ▷ The displays show:

Weight


LOAD

Piece Weight

PROD

Count


MEM 12

3. Pressing the  Button long.

- ▷ [CHANGE] is shown on Display-Weight as long as the button is pressed.

Weight

CHANGE

After the  Button was released [PROD.NA] is displayed on Display-Weight for about 2 seconds.

Piece Weight

PROD.NA

Display-PW is empty and Display-Count isn't changed.

After that 2 seconds the actual product name is displayed blinking on Display-Weight and Display-PW. Display-Count shows the entered product ID (doesn't change).

If an input is done during [PROD.NA] is displayed then the input process starts at once with a blinking under line (cursor) with the last digit of Display-PW.

Piece Weight

PROD.NA

The blinking product name can be changed via key pad or scanner.

The input of the product name which can be up to 12 characters long is done on Display-PW and also on Display-Weight. Possible characters are numbers, capital letters, "-", "/", "." and blank.

Example: Product name is 123456789012.

Then [123456] is shown on Display-Weight and [789012] is shown on Display-PW.

4. Pressing  Button briefly while the product name is blinking.

- ▷ The whole product name is cleared on the displays and a blinking under line is shown for a new input in Display-PW at its last digit.

5. Pressing  Button briefly while the cursor is blinking.

▷ The last digit before the blinking cursor is deleted.

Pressing a key of the key pad the old name is cleared and the pressed number is shown.


If a string of 12 characters is scanned via a scanner the whole string is displayed.

6. Pressing the  (Yes) Button briefly.


▷ The input string is taken over, go on point ①.

- ① It is shown on

Weight




Piece Weight



blinking weight value of Preset-Tare in the unit used before activating this change process.

Count




The Preset Tare value can be entered via key pad or scanner.

The value is taken over by pressing the  (Yes) Button briefly. Go on point ②.


Pressing the  (Back) Button go back to Product Name.

- ② It is shown on

Weight




Piece Weight




blinking weight value of piece weight in the unit defined before activating this change process. (here only g or oz are possible as units).

Count



The Piece weight can be entered via key pad or scanner.

The value is taken over by pressing the  (Yes) Button briefly. Go on point ③.

Pressing the  (Back) Button go back to point ①.

- ③ It is shown on

Weight

SET.LOW

Piece Weight

0.24567 g

blinking weight value of Low Limit if checkweighing was initialized. Show unit used before activating this change process.

Piece Weight


25 pcs

Blinking number of pieces if Checkcount was initialized.

Count

MEM 12

The Low Limit can be entered via key pad or scanner.

Pressing the  Button long, the unit will change between a weight unit used before this change process and unit pcs if the product wasn't initialized before (= empty product). This selection is also used in point ④ (Set high limit).

The value is taken over by pressing the  (Yes) Button briefly. Go on point ④.

Pressing the  (Back) Button go back to point ②.

- ④ It is shown on

Weight


SET.HI

Piece Weight

15.2456 g


blinking weight value of High Limit if checkweighing was initialized. Show unit used before activating this change process.

Piece Weight



Blinking number of pieces if Checkcount was initialized.

Count



The High Limit can be entered via key pad or scanner.

Handling of an empty product see point ③.

The value is taken over by pressing the  (Yes) Button briefly. Go on point ⑤.

Pressing the  (Back) Button go back to point ③.

The limits are checked with the same conditions as defined in chapter [6.4.2.1](#).

If a condition is violated [LIM.ERR] is shown on Display-PW for about 1 second.


Count



Then the input process for low limit is going on with the old value.

- ⑤ It is shown on


Weight





blinking

Display-PW is empty.

Count



The product data are saved by pressing the  (Yes) or  Button briefly.


Pressing the  (Back) Button go back to point ④.

- Depending on the product data the applications are initialized. If checkweighing was deactivated before and now the product contains a limit > 0 then Checkweighing is initialized automatically and vice versa.
- Applications are running, changing or initialization process was left.


6.8.4 Delete Product Storage/Parameters

- 1. Input a product number via the key pad or a scanner.
 - ▷ Number is shown on Display-Count.

- 2. Press the Mem Button briefly.
 - ▷ The displays show:



- 3. Pressing the C +/- Button briefly.
 - ▷ The displays show:



- 4. Pressing the On/Zero Off (Yes) or Mem Button briefly the product storage (parameters) is deleted or pressing the M+ Menu (Exit) Button briefly process is left.

6.8.5 Printouts


In menu: [PRINT] - [CONTNT] it can be defined that the product storage and product name is to be printed:

Printout	Description
PROD-ID: 2	Product storage number (ID), here 2
PROD-NAME: Metal4712123	Product name; 12 alpha-numeric character at max.

6.9 Handling Second Scale


If a second scale is activated then the Display-Weight looks like:

Weight




Scale WP1 is active

Weight



Scale WP2 is active

A scale switch is done by long pressed  (Scale) Button: If scale 1 is active then it is switched to scale 2 and vice versa.

The weight values of the active scale will be written to the display, will be used for Count and Check application, will be used for printing and PC-Output. This means always the weights of one scale are used!


Initialization of application count is only done on scale 1. But the initialization of Checkweighing can be done on both scales. The initialized application runs also on scale 2. Loading a product is also possible on both scales.

7 Menu Settings

Activated menu selections are signed by the symbol: [o].

If the latest menu level is reached the active selected parameter signed with [o] is displayed first.

If there has been a change in one or several menu items, so this parameters are present after leaving the menu. This could also be realized by a software-reset or any other solution.

If the menu is activated via the  button long pressed then [M.E.N.U] is displayed as long as this button is pressed. If the button is released the first element of the highest menu level [METRO] is displayed.

A menu level can be left via the menu item [END]. Then it is changed in the next higher level. If the highest menu level is active and [E.N.D] is selected the menu will be left.

Inputs via key pad are only possible on the right state where an input is expected.

The User Menu (Menu Mode) allows the customizing of scale settings.

Note:

Additional Sub-Menus may be available if Interface Options are installed.

See Interface User Manual for the additional setting information.

7.1 Menu Representation on Displays

Presentation of the first 3 menu levels in the 3 displays.

Weight

Piece Weight

First menu level

Second menu level

Count

Third menu level

Example:

- First menu level:

Weight

METRO

First menu level

Display-PW and Display-Count are empty.

- Second menu level is selected:

Weight

METRO

First menu level

Piece Weight

STARRR

Second menu level

Display-Count is empty.

- Third level is reached:

Weight

METRO

First menu level

Piece Weight

STARRR

Second menu level

Count

100

Third menu level = selection

If there are more than three menu levels the latest levels will be shown.

Weight

Second menu level

Piece Weight

Third menu level

Count

Fourth menu level

Example:

- Second Level is reached:

Weight

PRINT

First menu level

Piece Weight

CONTNT

Second menu level

Display-Count is empty.

- Third Level is reached:

Weight

CONTNT

First menu level

Piece Weight

PRDINA

Second menu level

Display-Count is empty.

- Fourth Level is reached:

Weight

CONTNT

First menu level

Piece Weight

PRDINA

Second menu level


Count

OFF ○

Fourth menu level = selection

7.2 Menu Mode

Enter into Menu Mode:


1. Press the  button long.
 - ▷ On the Display-Weight [M.E.N.U] is shown for 2 seconds and then the 1st menu item [METRO].

Weight

M.E.N.U

Weight

METRO

2. Press  (No) button to move to the next menu item.
 - ▷ The 2nd menu item [UNIT] shown on Display-Weight.

Weight

UNIT

3. Or press (Yes) button to enter into Sub-Menus on Display-PW (in this example [[METRO][STAB.RA]]).

▷ The second menu level is shown on Display-WP.

Weight

METRO

Piece Weight

STAB.RA

Display-count is empty.

4. To enter into menu item (in this example [[METRO][STAB.RA]]), press (Yes) button.

▷ On Display-Count value 1D is blinking.

Weight

METRO

Piece Weight

STAB.RA

Count

1D

The current selection is signed by [◦].

5. Press (No) button to change setting or press (Yes) button to accept setting.

▷ The next second menu level [FILTER] shown on Display-WP.

Weight

METRO

Piece Weight

FILTER

Display-count is empty.

6. Press (No) button to go forwards on Display-PW or press (Back) button to go backwards.

Weight

METRO


Piece Weight


END

7. When [END] is displayed, press (Yes) button.

- ▷ The 2nd menu item [UNIT] shown on Display-Weight.





Weight



8. Press  (Exit) button to exit the menu.

7.3 Handling Input Values in menu

For menu items with numeric settings such as Capacity, the current setting is displayed with all digits flashing.

1. Press  (Yes) Button to accept the setting or press  (No) Button to resume editing.
2. For End menu items, pressing  (Yes) Button advances to the next menu, while pressing  (No) Button returns to the top of the current menu.

7.4 Menu Navigation

Overview of Menu Mode options.

— METRO	Metrology (see chapter 7.4.1)
— UNIT	Weighing units (see chapter 7.4.2)
— OP.FUNC	Operation functions (see chapter 7.4.3)
— PRINT	Printer outputs (see chapter 7.4.4)
— PRN.COM	Printer port communication (see chapter 7.4.5)
— PC.OUT	PC output (see chapter 7.4.6)
— PC.COM	PC port communication (see chapter 7.4.7)
— CAL.ADJ	Calibration / Adjustment (see chapter 7.4.8)
— AD.CON2	ADC configuration of the second scale, only visible when [AD.CON2] (see chapter 7.4.9) was activated before
— INFO	Information (shows serial number and type designation)(see chapter 7.4.10)
— SECURE	Block menu items (see chapter 7.4.11)
— E.N.D.	Leave menu

7.4.1 Menu Selection [METRO]

Enter this menu to customize display functionality and scale functionality.

Default settings are identified by an "*"

METRO

— STAB.RA	Stability range valid for both scales
— 0.5D	0.5 digits
— 1D	1 digit*
— 2D	2 digits
— 4D	4 digits
— FILTER	Adaption Filter valid for both scales
— LOW	Less precion, short stabilization time
— MED	Normal precion, medium stabilization time*

— HI	High Precion, Long stabilization time
— A.ZERO.T	Auto Zero-Tracking valid for both scales
— OFF	Turn off
— 0.5D	Drift of 0.5 digit / second*
— 1D	Drift of 1 digit / second
— 3D	Drift of 3 digit / second
— AUT.OFF	Auto Off Timer
— OFF	Turn off*
— 1 MIN	power off after 1 minute of no activities
— 5 MIN	power off after 5 minute of no activities
— 10 MIN	power off after 10 minute of no activities
— RESET	Factory setting
— NO	not restored*
— YES	enabled
— END	Leave menu level

7.4.2 Menu Selection [UNIT]

Enter this menu to customize weighing unit to be used.

Default settings are identified by an "*"

UNIT	
— kg	Kilogram
— OFF	disabled
— ON	enabled*
— g	Gram
— OFF	disabled
— ON	enabled*
— lb	Pound
— OFF	disabled
— ON	enabled*
— oz	Ounce
— OFF	disabled
— ON	enabled*
— lb:oz	Pound / Ounces
— OFF	disabled*
— ON	enabled
— RESET	Factory setting
— NO	not restored*
— YES	enabled
— END	Leave menu level

7.4.3 Menu Selection [OP.FUNC]

Enter this menu to setup scale parameters.

Default settings are identified by an "*"

OP.FUNC	
— WP2	Activate a second scale
— OFF	disabled*
— ON	enable
— UNIT.ON	Select unit at Power ON
— AUTO	Last unit in use when turned OFF*
— kg	kilogram
— g	gram

— lb	pound
— oz	ounce
— lb:oz	pound:ounces
— ZERO.RA	Zero Range
— 2%	disabled
— 10%	enabled*
— A.OPT	Automatic reference weight optimization
— OFF	disabled
— ON	enable*
— A.TARE	Automatic Tare
— OFF	disabled*
— ON	1st stable weight is tared
— ON-ACC	Stable loads within the accept limits are tared (in all check modes)
— BEEP.OP	Beep when piece weight has been optimized automatically
— OFF	disabled
— ON	enable*
— BEEP.SI	Beeper Signal (in Checkweighing Mode)
— OFF	disabled*
— ACCEPT	Beep when weight is within accept area
— UNDER	Beep when weight is under the low limit
— OVER	Beep when weight is over the high limit
— UNDOVR	Beep when weight is outside the accept area
— BEEP.KE	Button Sound
— OFF	disabled
— ON	enabled*
— TOT.SET	Totalization Setting
— OFF	disabled
— AUTO	Automatic Totalization
— MAN	Manual Totalization*
— LIGHT.T	Back lighting time (D.LIGHT = AUTO)
— 3 SEC	Backlight off after 3 minutes of no activity
— 5 SEC	Backlight off after 5 minutes of no activity*
— 8 SEC	Backlight off after 8 minutes of no activity
— D.LIGHT	Display Backlight
— OFF	disabled
— ON	enabled
— AUTO	turns on when a button is pressed or the displayed weight changes*
— COM.EQU	Communication Module
— OFF	disabled*
— BLUE.TH	Bluetooth Enabled (when Bluetooth module installed)
— WIFI	Wi-Fi Enabled (when WIFI module installed)
— ETHER.N	Ethernet Enabled (when Ethernet module is installed)
— RESET	Factory setting
— NO	not restored*
— YES	enabled
— END	Leave menu level

7.4.4 Menu Selection [PRINT]

Enter this menu to configure print conditions and printouts.

Default settings are identified by an "*"

PRINT	
— STABLE	Printing criteria
— OFF	values are printed immediately
— ON	values are only printed when stable*
— A.PRINT	Automatic Print
— OFF	disabled*
— ON.STAB	Print on stability for one time, if weight >1d
— INTER	Printing at the defined interval
— 1...3600	1 ... 3600 second
— CONT	Print continuously
— ACCEPT	Print on stable and within checklimit
— CONTNT	Content of a printout
— RESULT	Display Value
— OFF	disabled
— ON	enabled*
— GROSS	Gross Value; it doesn't matter measured or calculated
— OFF	disabled*
— ON	enabled
— NET	Net Value; it doesn't matter measured or calculated
— OFF	disabled*
— ON	enabled
— TARE	Tare
— OFF	disabled*
— ON	enabled
— PRE.TAR	preset Tare
— OFF	disabled*
— ON	enabled
— HEADER	Header info; set via the interface (see SBI-specification)
— OFF	disabled*
— ON	enabled
— FOOTER	Footer info; set via the interface (see SBI-specification)
— OFF	disabled*
— ON	enabled
— MODE	Mode info
— OFF	disabled*
— ON	enabled
— INFO	Check limits
— OFF	disabled*
— ON	enabled
— PW	piece weight
— OFF	disabled*
— ON	enabled
— TOTAL	Total Value
— OFF	disabled*

—	—	—	RESULT	Accumulated result is printed
		—	ALL	Result and statistical parameters like Min, Max, ...
		—	PROD.ID	Product storage number
		—	OFF	disabled*
		—	ON	enabled
		—	PROD.NA	Product name; 12 alpha-numeric characters at maximum
		—	OFF	disabled*
		—	ON	enabled
		—	SERNO	serial number of the active (displayed) scale Example: W1 38457989 or W2 38457989
		—	OFF	disabled*
		—	ON	enabled
—	LI.SET			List Set
		—	FORMAT	Format send to printer and to PC
		—	MULTI	Multi-line (single column) printout*
		—	SINGLE	Single line printout; whole content defined above is printed in one line
		—	FEED	Paper Feed Setting
		—	LINE	Move a paper up one line after printing
		—	4LF	Move a paper up four lines after printing*
		—	FORM	Form feed after printing
		—	END	
—	PROD.LI			Print whole product storage
		—	NO	disabled*
		—	YES	print all products. This is done in that moment when YES is selected. Then all products are printed. Afterwards NO is set automatically!
—	RESET			Factory setting
		—	NO	not restored*
		—	YES	enabled
—	END			Leave menu level

"Without stability" means here weight values with or without stability.

"With stability" means here only weigh values with stability!

7.4.5 Menu Selection [PRN.COM]

Enter this menu to setup Print Communication parameters.

Default settings are identified by an "*"

PRN.COM

—	BAUD	Baud Rate
	—	2400
	—	4800
	—	9600
	—	19200
	—	38400
	—	57600
	—	115200
—	PARITY	Parity

7 EVEN	7 data bits, even parity
7 Odd	7 data bits, odd parity
7 NONE	7 data bits, no parity
8 NONE	8 data bits, no parity*
STOP	Stop Bit
1	1*
2	2
RESET	Factory setting
NO	not restored*
YES	enabled
END	Leave menu level

7.4.6 Menu Selection [PC.OUT]

Enter this menu to define PC Output parameters.

This is an additional interface based on RS232 with USB-C connector.

Default settings are identified by an "*"

PC.OUT

MODE	PC Output Mode
OFF	disabled*
MAN.OUT	Manual output without stability = device expects a request via a serial interface. Response is generated immediately
MAN.STA	Manual output without stability= device expects a request via a serial interface.
INT.OUT	interval output with 16 characters without stability = device sends weighing values automatically without stability in the selected interval of display refresh cycles (see below)
AUT.OUT	automatic output without stability with 16 characters = device sends weighing values without stability automatically every display refresh cycle
AUT.STA	automatic output with stability with 16 characters at each value change = device sends weighing values with stability automatically
INTERV	Set the output interval (when INT.OUT is selected)
1 CYC	Each display cycle
2 CYC	After 2 display cycle
5 CYC	After 5 display cycle
10 CYC	After 10 display cycle*
20 CYC	After 20 display cycle
50 CYC	After 50 display cycle
100 CYC	After 100 display cycle
RESET	Factory setting
NO	not restored*
YES	enabled
END	Leave menu level

"Without stability" means here weight values with or without stability.

"With stability" means here only weigh values with stability!



7.4.7 Menu Selection [PC.COM]


Enter this menu to define PC Communication parameters.
Default settings are identified by an "*"

PC.COM	
— BAUD	Baud Rate
— 4800	4800
— 9600	9600*
— 19200	19200
— 38400	38400
— 57600	57600
— 115200	115200
— PARITY	Parity
— 7 EVEN	7 data bits, even parity
— 7 Odd	7 data bits, odd parity
— 7 NONE	7 data bits, no parity
— 8 NONE	8 data bits, no parity*
— 7 MARK	7 data bits, no parity
— 7 SPACE	7 data bits, no parity
— STOP	Stop Bit
— 1	1*
— 2	2
— HAND.SH	Handshake
— NONE	No Handshaking*
— XON.XOF	has no function
— RESET	Factory setting
— NO	not restored*
— YES	enabled
— END	Leave menu level

7.4.8 Menu Selection [CAL.ADJ]

Default settings are identified by an "*"

CAL.ADJ	
— CAL	Initiates a span calibration procedure (zero and span)
— WP 1	Initiates a span calibration procedure for WP1
	This procedure is interruptable by the  (Exit) Button
	The span weight is freely selectable by input the value
— WP 2	Only visible if there is a second scale defined in menu [OP.FUNC] - [WP2] :
	Initiates a span calibration procedure for WP2
	This procedure is interruptable by the  (Exit) Button
	The span weight is freely selectable by input the value
— LIN	Initiates a linearity calibration procedure (zero, mid-point and span)
— WP 1	Initiates a linearization procedure for WP1



This procedure is interruptable by the (Exit) Button

M+
Menu

The weight values are fix

Only visible if there is a second scale defined in menu [OP.FUNC] - [WP2] :

Initiates a linearization procedure for WP2

This procedure is interruptable by the (Exit) Button

M+
Menu

The weight values are fix

Geographical Adjustment Factor (GEO) is used to adjust the calibration based on the current location


selectable area from 0 to 31 in single steps*

Leave menu level

7.4.9 Menu Selection [AD.CON2]

Enter this menu to ADC configuration for scale 2

AD.CON2



Step with of the scale (1 digit) changeable via

Print
Unit

or Target

Button only!

Calibration weight, which is used in [CAL.ADJ] - [CAL] - [WP2] and which is free selectable within 30% Max-Load and Max-Load


Maximum capacity of the scale

"H" is displayed if this entered value is reached.

Leave menu level

7.4.10 Menu Selection [INFO]

INFO



show serial number (if two scales selected, then show two serial numbers)

With (No) or Button next six digits or first six digits again are displayed.

With (No) or Button next six digits or first six digits again are displayed.

Show scale type name

Show software version

Show selected GEO area which is valid for both scales

selected GEO area

Info Wp1

Accuracy

Max.-Load

Info Wp2 when selected in menu

Accuracy

— MAX	Max.-Load
— END	
— LFT.MOD	Show state of the legal for trade mode: ON or OFF for both scales
— OFF	standard mode
— ON	Legal for trade mode is activated
— LOCK.SW	Show state of the lock switch for both scales
— OPEN	switch is open
— CLOSED	switch is closed
— END	Leave menu level

7.4.11 Menu Selection [SECURE]

Enter this menu to define Security setting (Lock) on menu option to prevent tampering. Default settings are identified by an "*"

SECURE

— S.METRO	Metrology Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.UNIT	Unit Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.OP.FUN	Operation Function Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.PRINT	Print Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.PR.COM	Printer Communication Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.PC.OUT	PC Output Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.PC.COM	PC Communication Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.CAL.AD	Calibration Menu
— OFF	menu item is changeable*
— ON	lock menu item
— S.ADC.CO	ADC Menu
— OFF	menu item is changeable*
— ON	lock menu item
— RESET	Restore factory setting of current menu
— OFF	menu item is changeable*
— ON	lock menu item
— END	Leave menu level

8 Calibration and Adjustment

8.1 Calibration

Calibration is executed in the menu after activating item [WP1] or [WP2].

8.1.1 Calibration/Adjustment Procedure

Weights for calibration points are freely selectable when the value is blinking.

If the unit used for the normal weighing is pound then the calibration unit is also lb = pounds.


If the unit used for the normal weighing is ounce then the calibration unit is also oz = ounce.

If a metric unit (kg or g) is used for the normal weighing then the calibration unit is kg = kilo gram.

1. After WP1 or WP2 (if present) was activated.


▷ The Displays show:

Weight



Second menu level = Calibration

Piece Weight




Third menu level = here WP1

Count




blinking first weight value

2. Remove all weights from the pan and press  (Yes) Button.

▷ Now the first calibration point is taken over and internal stored.


During this time the Displays show:

Weight




Second menu level = Calibration

Piece Weight



Third menu level = here WP1


Count



waiting message until the weight is
taken over


Second weighing point is shown blinking

Weight




Second menu level = Calibration

Piece Weight




Third menu level = here WP1

Count




blinking weight which can be changed
via key pad

3. If the right second weighing point is selected press  (Yes) Button.

Take over the second weighing point. During internal calculations the same display view is shown as under step 2.


If everything was OK the displays show for about 2 seconds:

Weight



Second menu level = Calibration

Piece Weight



Third menu level = here WP1

Count



OK-Message = Calibration is finished

Then device leaves menu and returns to normal application usage.

If there was an error during calibration the displays show for about 2 seconds:

Weight

CAL

Second menu level = Calibration

Piece Weight

WP 1

Third menu level = here WP1

Count

CAL.ERR

Error message = calibration is aborted

Then device leaves menu and returns to normal application usage.

Same procedure is done for WP2. Then Display-PW shows WP2 and the Device changes automatically to scale 2.

8.1.2 Menu Settings

CAL.ADJ

— CAL

— WP 1

— WP 2

— LIN

— GEO

— END

Selects the scale which is to be calibrated and starts calibration.

Initiates a span calibration procedure (zero and span) for WP1

This procedure is interruptable by the "Exit" Button.

The span weight is freely selectable by input the value

Only visible if there is a second scale defined in menu:

Initiates a span calibration procedure (zero and span) for WP2

This procedure is interruptable by the "Exit" Button.

The span weight is freely selectable by input the value

Leave menu level

8.2 Linearization

Linearization is executed in the menu after activating item [WP1] or [WP2] .

8.2.1 Linearization Procedure

If the unit used for the normal weighing is pounds then the calibration unit is also lb = pounds.

If the unit used for the normal weighing is ounces then the calibration unit is also oz = ounce.

If a metric unit (kg or g) is used for the normal weighing then the calibration unit is kg = kilo gram.

Linearization weights are fix. There are three points: zero, $0.5 * \text{MaxLoad}$, Maxload.

Procedure is nearly the same as for Calibration. Only Display-Weight shows [LIN]

► After WP1 or WP2 (if present) was activated


▷ The Displays show:

Weight



Second menu level = Calibration

Piece Weight



Third menu level = here WP1

Count



blinking first weight value

8.2.2 Menu Settings

CAL.ADJ

— CAL

— LIN

— WP 1

— WP 2

— GEO

— END

Selects the scale which is to be linearized and starts linearization. Initiates a linearization procedure for WP1

Initiates a linearization procedure for WP1

This procedure is interruptable by the (Exit) Button.

The weight values are fix.

Only visible if there is a second scale defined in menu

Initiates a linearization procedure for WP2.

This procedure is interruptable by the (Exit) Button.

The weight values are fix.

Leave menu level



8.3 Geographical Factor Adjustment Procedure

The Geographical Adjustment Factor [GEO] is used to adjust the calibration based on the current location. (Settings from 0 ... 31 are available). Refer to table 8.4 to determine the GEO factor that corresponds to your location.


Enter into Menu Mode:

1. Press and hold the  button long.

- ▷ The 1st menu item [METRO] shown on Display-Weight.

Weight


METRO

2. Press  (No) button to change the menu item until [CAL.ADJ] show on Display-Weight.

Weight

CAL.ADJ

3. Press  (Yes) button enter into sub-menu item.

4. Press  (No) button to change the menu item until [GEO] show on Display-PW.

Weight

CAL.ADJ

Piece Weight

GEO

5. Press  (Yes) button to start GEO Factor selection.

- ▷ The default GEO factor [12] is indicated and blinking.

Weight

CAL.ADJ

Piece Weight

GEO

Count

0000 12

6. If changing the value is needed, input values from 0 ... 31 via the key pad.

7. Press  (Yes) button to confirm GEO Factor value.

- ▷ The GEO factor has been stored, when [END] show on Display-PW.

Weight


CAL.ADJ

Piece Weight

END

8. Press  (Yes) button.

- ▷ The menu item [INFO] shown on Display-Weight.

9. Press  (Exit) button to exit the menu.

8.4 GEO Code Table

		Elevation in meters										
		0	325	650	975	1300	1625	1950	2275	2600	2925	3250
		325	650	975	1300	1625	1950	2275	2600	2925	3250	3575
		Elevation in feet										
		0	1016	2130	3200	4260	5330	6400	7460	8530	9600	10660
		1060	2130	3200	4260	5330	6400	7460	8530	9600	10660	11730
Latitude		GEO value										
0°00'	5°46'	5	4	4	3	3	2	2	1	1	0	0
5°46'	9°52'	5	5	4	4	3	3	2	2	1	1	0
9°52'	12°44'	6	5	5	4	4	3	3	2	2	1	1
12°44'	15°06'	6	6	5	5	4	4	3	3	2	2	1
15°06'	17°10'	7	6	6	5	5	4	4	3	3	2	2
17°10'	19°02'	7	7	6	6	5	5	4	4	3	3	2
19°02'	20°45'	8	7	7	6	6	5	5	4	4	3	3
20°45'	22°22'	8	8	7	7	6	6	5	5	4	4	3
22°22'	23°54'	9	8	8	7	7	6	6	5	5	4	4
23°54'	25°21'	9	9	8	8	7	7	6	6	5	5	4
25°21'	26°45'	10	9	9	8	8	7	7	6	6	5	5
26°45'	28°06'	10	10	9	9	8	8	7	7	6	6	5
28°06'	29°25'	11	10	10	9	9	8	8	7	7	6	6
29°25'	30°41'	11	11	10	10	9	9	8	8	7	7	6
30°41'	31°56'	12	11	11	10	10	9	9	8	8	7	7
31°56'	33°09'	12	12	11	11	10	10	9	9	8	8	7
33°09'	34°21'	13	12	12	11	11	10	10	9	9	8	8
34°21'	35°31'	13	13	12	12	11	11	10	10	9	9	8
35°31'	36°41'	14	13	13	12	12	11	11	10	10	9	9
36°41'	37°50'	14	14	13	13	12	12	11	11	10	10	9
37°50'	38°58'	15	14	14	13	13	12	12	11	11	10	10
38°58'	40°05'	15	15	14	14	13	13	12	12	11	11	10
40°05'	41°12'	16	15	15	14	14	13	13	12	12	11	11
41°12'	42°19'	16	16	15	15	14	14	13	13	12	12	11
42°19'	43°26'	17	16	16	15	15	14	14	13	13	12	12
43°26'	44°32'	17	17	16	16	15	15	14	14	13	13	12
44°32'	45°38'	18	17	17	16	16	15	15	14	14	13	13

		Elevation in meters										
		0	325	650	975	1300	1625	1950	2275	2600	2925	3250
		325	650	975	1300	1625	1950	2275	2600	2925	3250	3575
		Elevation in feet										
		0	1016	2130	3200	4260	5330	6400	7460	8530	9600	10660
		1060	2130	3200	4260	5330	6400	7460	8530	9600	10660	11730
Latitude		GEO value										
45°38'	46°45'	18	18	17	17	16	16	15	15	14	14	13
46°45'	47°51'	19	18	18	17	17	16	16	15	15	14	14
47°51'	48°58'	19	19	18	18	17	17	16	16	15	15	14
48°58'	50°16'	20	19	19	18	18	17	17	16	16	15	15
50°16'	51°13'	20	20	19	19	18	18	17	17	16	16	15
51°13'	52°22'	21	20	20	19	19	18	18	17	17	16	16
52°22'	53°31'	21	21	20	20	19	19	18	18	17	17	16
53°31'	54°41'	22	21	21	20	20	19	19	18	18	17	17
54°41'	55°52'	22	22	21	21	20	20	19	19	18	18	17
55°52'	57°04'	23	22	22	21	21	20	20	19	19	18	18
57°04'	58°17'	23	23	22	22	21	21	20	20	19	19	18
58°17'	59°32'	24	23	23	22	22	21	21	20	20	19	19
58°17'	59°32'	24	23	23	22	22	21	21	20	20	19	19
60°49'	62°90'	25	24	24	23	23	22	22	21	21	20	20
62°90'	63°30'	25	25	24	24	23	23	22	22	21	21	20
63°30'	64°55'	26	25	25	24	24	23	23	22	22	21	21
64°55'	66°24'	26	26	25	25	24	24	23	23	22	22	21
66°24'	67°57'	27	26	26	25	25	24	24	23	23	22	22
67°57'	69°35'	27	27	26	26	25	25	24	24	23	23	22
69°35'	71°21'	28	27	27	26	26	25	25	24	24	23	23
71°21'	73°16'	28	28	27	27	26	26	25	25	24	24	23
73°16'	75°24'	29	28	28	27	27	26	26	25	25	24	24
75°24'	77°55'	29	29	28	28	27	27	26	26	25	25	24
77°55'	80°56'	30	29	29	28	28	27	27	26	26	25	25
80°56'	85°45'	30	30	29	29	28	28	27	27	26	26	25
85°45'	90°00'	31	30	30	29	29	28	28	27	27	26	26

9 Printing

Every time a print is done, [PRINT] is displayed on Display-Weight for about 1 second, no longer.

Weight



9.1 Output Format

General Definitions:

- Space = 0x20 hex as ASCII character.
- CRLF = 0x0D0A hex as ASCII character.
- The sign is set directly beside the MSB of a value with a space between these.

Example: - 14.112

- Values shall be written among themselves:

Example:

- 10.075 oz OVERCRLF
0.015 oz TCRLF
- 10.060 oz G#CRLF

- A stable weight value is printed with unit. 10.25 kg
An unstable weight value is printed without unit: 10.25
- A stable negative gross weight value has a "!" instead of a unit: - 0.25 !
An unstable negative gross weight value has no unit symbol: - 0.25
- Error format is generated when there is no valid weighing value or an error message is displayed. The error number of the display is also printed as: [Err 8.1] for example.

9.2 Product Storages

Printing all product storages see menu item [PRINT] - [PROD.LI] :

Printout	Description
PROD-ID: 2	Product Storage, here 2. Storage 1 is empty
PROD-NAME: Metal4712123	Product Name
5.23 g PT	Preset Tare
WREF 0.43245 g	Piece Weight
UNDER LIMIT 580.0 g	Low Limit
OVER LIMIT 681.0 g	High Limit
MODE: CHECK WEIGHT	Check Mode
	Line feed
PROD-ID: 3	Product Storage, here 3. Only Counting without Preset Tare
PROD-NANE: Metal458ab	Product Name
0.0 g PT	Preset Tare
WREF 0.83241 g	Piece Weight
UNDER LIMIT 0.0 g	Low Limit
OVER LIMIT 0.0 g	High Limit
MODE: CHECK OFF	Check Mode
	Line feed
PROD-ID: 8	Product Storage, here 8. Storages 4,5,6,7 are empty
PROD-NANE: Metal471	Product Name
0.0 g PT	Preset Tare
WREF 0.0 g	Piece Weight
UNDER LIMIT 580.0 g	Low Limit
OVER LIMIT 681.0 g	High Limit
MODE: CHECK WEIGHT	Check Mode
	Line feed

9.3 Menu settings Print

Menu point [PRINT] has the following submenus:

PRINT

— STABLE	Printing criteria
— A.PRINT	Automatic Print
— CONTNT	Content of a protocol print
— LI.SET	Frame Format
— PROD.LI	Print whole product storage
— RESET	set menu point [PRINT] to factory defaults
— END	Leave menu level

Print conditions

Set conditions in menu point [PRINT] (see Chapter [7.4.4](#))

Printout content

- The content of a print protocol is set in menu point [PRINT] - [CONTNT] (see Chapter [7.4.4](#)).

Each parameter which is selected here shall be printed at **every** printout even its content is zero.

For Example: if there is no Tara value it is printed 0.000 kg T.

This does not apply to TOTALIZATION and PRESET-TARE. The TOTALIZATION parameters shall be printed only if TOTALIZATION is activated in menu!

And the Preset-Tare is only printed when it is occupied!

- If there is a stable weighing value, the Unit is always printed. It is not selectable!

Frame Format

The frame format is to be configured in menu point [PRINT] - [LI.SET] (see Chapter [7.4.4](#)).

Print-Interface settings

Interface parameter selection for printing [PRN.COM] (see Chapter [7.4.5](#)).

10 PC-OUT

This is an additional interface based on USB-C standard.

10.1 Output Format

This output format is the response to the interface commands which requests a weighing value like "ESCP".

Also this format is used for automatically generated telegrams which are generated regarded the menu settings: [INT.OUT] , [AUT.OUT] , [AUT.STA] please look above.

This format is specified in the SBI-Specification by Uwe Anlauf.

Output (16 characters):

V	W	W	W	W	W	W	W	W	W	W		E	E	E	CR	LF
V:	Sign (possible characters: "+", "-", " ")															
W:	Weight Value (possible characters: "0" ... "9", ".", " ")															
E:	Unit (possible characters: "a" ... "z", "A" ... "Z", " ")															
CR:	Carriage Return (ASCII 0x0D)															
LF:	Line Feed (ASCII 0x0A)															

Possible Commands are:

P	Read displayed value
Z	Zero the weighing platform
T	Tare the weighing platform

10.2 Menu settings PC-OUT

Menu point [PC.OUT] has the following submenus:

PC.OUT

— MODE	PC Output Mode
— INTERV	Set the output interval (when [INT.OUT] is selected in MODE)
— RESET	Set menu point [PC.OUT] to factory defaults
— END	Leave menu level

The PC-Output Mode is to be configured in menu point [PC.OUT] - [MODE] (see Chapter [7.4.6](#))

The PC-Output Interval is to be configured in menu point [PC.OUT] - [INTERV] (see Chapter [7.4.6](#))

11 SBI Interface

You can enter certain commands to control weighing platform functions through the SBI interface. Each command starts with an escape sequence. The command is always closed with an end of command (EOC). The end of command can be any combination of CR and LF. Every data after EOC and before ESC will be ignored by the scale.

Read displayed value:

ESC	P	EOC
-----	---	-----

Answer (16 Byte):

V	W	W	W	W	W	W	W	W	W	E	E	E	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	---	----	----

V	Sign	possible characters: "+", "-", " "
W	Weight Value	possible characters: "0"... "9", ".", " ", " "
E	Unit	possible characters: "a"... "z", "A"... "Z", " "
CR	Carriage Return	ASCII 0x0D
LF	Line Feed	ASCII 0x0A

Zero the weighing platform:

ESC	Z	EOC
-----	---	-----

Answer: see special Response Commands

Tare the weighing platform:

ESC	T	EOC
-----	---	-----

Answer: see special Response Commands

Special Response commands:

There are some special response commands. These commands are used as standard responses. For example, error or confirmation. Special Response Commands always have the same size of 5 Bytes!

OK

1	2	3	4	5
O	K	!	CR	LF

The Scale confirmed the command execution without any errors.

ERROR

1	2	3	4	5
E	R	R	CR	LF

The Scale has reported an Error during command execution.

LOCKED

1	2	3	4	5
L	O	C	CR	LF

The command can not be executed because the parameter is currently locked.

12 Maintenance/repairs/cleaning

12.1 Repairs

Immediately disconnect a defective device from the power supply.

Defective or damaged cables or screw connections must be replaced as a complete unit.

The seals placed on the device indicate that the device may only be opened and serviced by authorized specialists to ensure trouble-free and safe operation of the device, and to ensure that the warranty remains valid.

WARNING

Improper repairs can pose considerable risks to the user.

- Repairs should only be performed by Minebea Intec authorized dealers using original spare parts.

12.2 Cleaning

12.2.1 Cleaning instructions

The device should be cleaned at regular intervals.

Disconnect the device from the supply voltage before cleaning.

Remove all traces of corrosive substances on a regular basis.

If the scale is located in a dry environment, then wipe the weighing platform using a damp cloth.

Do not allow liquid to enter devices with an IP43 degree of protection.

The device may not be cleaned using a high-pressure or steam cleaner. Consider the IP rating.

Condensation may form in the device if it is cleaned with water that is too hot or too cold, due to temperature differences. Condensation may cause the device to malfunction.

12.2.2 Cleaning agents

NOTICE

Some cleaning agents may not be compatible with the device material.

- Do not use cleaning agents for stainless steel parts that contain chlorine, alkalines, acetic acid, hydrochloric acid, sulfuric acid, or citric acid.
- The use of cleaning sponges made of steel wool is prohibited (e.g. S.O.S pads).
- Use a damp cloth or sponge to clean stainless steel parts on the scale (if present). You can use any commercially available household cleaning agent that is suitable for use on stainless steel.

13 Disposal

If the packaging is no longer required, please take it to your local waste disposal facility and/or a reputable disposal company or collection point. The packaging largely consists of environmentally friendly materials which can be used as secondary raw materials.

It is not permitted—even for small businesses—to dispose of this product with the regular household waste or at collection points run by local public waste disposal companies.

EU legislation requires its Member States to collect electrical and electronic equipment and dispose of it separately from other unsorted municipal waste so that it can then be recycled.

Before disposing of or scrapping the product, any batteries should be removed and taken to a suitable collection point.


Please see our T&Cs for further information.

We reserve the right not to accept products that are contaminated with hazardous substances (ABC contamination) for repair.

14 Troubleshooting

The Table lists common problems and possible causes and remedies.

If the problem persists, contact Minebea Intec or your authorized dealer.

Symptom	Possible Cause	Remedy
Cannot turn on	No power to scale	Verify connections and voltage
Poor accuracy	Improper adjustment Unstable environment	Perform adjustment Move scale to suitable location
Cannot access mode	Mode not enabled	Enter menu and enable mode
Cannot access unit	Unit not enabled	Enter menu and enable unit
Battery icon flashing	Low Battery error	Connect the scale to AC power and charge the battery
[Err 8.1]	Power On Error	Weight reading exceeds Power On Zero limit
[Err 8.2]	Power On Error	Weight reading below Power On Zero limit
[Err 8.3]	Over Range Error	Weight reading exceeds Overload limit
[Err 8.4]	Under Range Error	Weight reading below Underload limit
[Err 8.5]	Tare out of range	Adjust tare value to be within range
[Err 8.6]	Display overflow	Weight exceeds 6 digits
[Err 9.5]	Calibration data error	Calibration data not present
	Busy	Displayed during tare setting, zero setting, printing
[--NO--]	Action not allowed	Function not executed
[CAL.ERR]	Calibration error Unstable environment Incorrect calibration weight	Calibration value outside allowed limits Move the scale to suitable location Use correct calibration weight
[LIM.ERR]	Entered value out of range	Enter a suitable value
[REF.ERR]	Unacceptable reference weight	Reference weight too small. Weight on the pan is too small to define a valid reference weight. Increase reference weight
Battery fails to charge fully	Battery is defective	Have battery replaced by Minebea Intec authorized service dealer.

14.1 Service Information

If the troubleshooting chapter does not resolve or describe your problem, contact your authorized service agent. Please visit our website <http://www.puroscales.com> to locate the office nearest you.

15 Technical data

15.1 Ambient Conditions

- Indoor use only
- Operating temperature: -10°C to +40°C
- Storage temperature: -10°C to +50°C
- Relative humidity: 20 % to 85 % relative humidity, non-condensing
- Altitude: up to 3575 m

15.2 Specifications

Model number	EF - LT	P1	P3	P6	P15	P30
Max. Capacity (g)		1,500	3,000	6,000	15,000	30,000
Readability d (g)	- 30 d	0.05	0.1	0.2	0.5	1
Max. resolution		30,000	30,000	30,000	30,000	30,000
Readability d (g)	- 6 d	0.2	0.5	1	2	5
Max. resolution		7,500	6,000	6,000	7,500	6,000
Application Package Count Professional		Weighing, Automatic tare, Count professional				
Minimum recommended sample weight (g)		1	2	4	10	20
Minimum recommended APW (g)		0.005	0.01	0.02	0.05	0.1
Maximum internal coun- ting resolution		1:1,500,000 internal / 1:300,000 external				
Weighing units		kg, g, lb, oz, lb:oz				
Construction/material		ABS plastic housing, stainless steel 304 weighing platform				
Ingress protection rating		IP43				
Display		3 windows LCD display with white backlight, 1.1 in / 28 mm height digits				
Checkweighing indicators		3 LED (yellow, green, red) with configurable operation and alert beeper				
Memory		30 item library				
Keypad		8 function, 12 numeric mechanical keys				
Zero range		2 % or 10 % of full scale capacity				
Tare range		Full capacity by subtraction				
Stabilization time		1 second				
Auto-zero tracking		Off, 0.5, 1 or 3 divisions				
Safe overload capacity		150 % of rated scale capacity				
Levelling components		Externally visible level indicator and adjustable, non-slip levelling feet				



Model number	EF - LT	P1	P3	P6	P15	P30
Power		U _{DC} = 5 V, 100 – 240 V – 50/60 Hz AC adapter or internal rechargeable lithium battery				
Battery operation		Up to 210 hours operation time (with standard battery) between recharges with 12 hour recharge time				
Calibration		External, with freely selectable calibration weights				
Interface		Built-in USB-C, Printer port, RS232, optional Bluetooth or WiFi				
Operating temperature (°C)		-10 ... +40				
Storage temperature (°C)		-10 ...+50				
Product dimension (w x d x h)		310 x 302 x 115 mm				
Platform size (w x l)		280 x 180 mm				
Shipment dimension (w x d x h)		370 x 370 x 220 mm				
Net weight		2.9 kg				
Shipping weight		4.5 kg				


15.3 Accessories

Option	Order-No.
Data Printer	YP-DP1
Paper for Data Printer	YP-P1
Printer cable	YP-CAS1
USB-C cable	YP-CAC1
Handheld Laser Barcode Scanner	MD2000
Scanner cable	YP-CYSSR1
USB Charger	YP-PS1
Weighing hook	YP-H1


15.4 Dimensions

Count






all dimensions in mm / inch



all dimensions in mm / inch



all dimensions in mm / inch

16 Appendix

16.1 Printouts

Printout elements are configured in menu.

Weighing Printout

Printout	Description
5.003 g N	positive netto weight value
- 0.003 g N	negative netto weight value
2.003 g G	positive measured gross weight value
2.003 g G#	positive calculated gross weight value
1.003 g T	tare weight value (measured value)
0.010 g PT	preset tare value (entered value)
- 0.010 ! G	stable gross weight below zero

Weighing Printout (without Checkweighing) Normal printout

Printout	Description
441 pcs QNT	positive value
- 41 pcs QNT	negative value
MODE: COUNT	activated Application
WREF 4.15431 oz	piece weight

Check Weighing Printout (Counting not initialized)

Printout	Description
115 g OVER	positive netto value > high limit
- 115 g OVER	negative netto value > negative high limit
99 g ACCEPT	positive netto value in target area
75 g UNDER	positive netto value < low limit
MODE: CHECKWEIGH	activated Application
UNDER LIMIT 81 g	Low Limit
OVER LIMIT 100 g	High Limit

Check Weighing Printout (Counting initialized)

Printout	Description
115 g OVER	positive netto value > high limit
- 115 g OVER	negative netto value > negative high limit
99 g ACCEPT	positive netto value in target area
75 g UNDER	positive netto value < low limit
115 pcs	netto count >
MODE: CHECKWEIGH	activated Application
UNDER LIMIT 81 g	Low Limit
OVER LIMIT 100 g	High Limit
WREF 0.35423 oz	piece weigh, same as displayed

Check Number of pieces Printout (Counting not initialized)

Printout	Description
115 g N	normal netto value as result
MODE: CHECKWEIGH	activated Application
UNDER LIMIT -20 pcs	Low Limit
OVER LIMIT -60 pcs	High Limit

Check Number of pieces Printout (Counting initialized)

Printout	Description
115 pcs OVER	positive netto count > high limit
- 115 pcs OVER	negative netto count > negative high limit
30 pcs ACCEPT	positive netto count in target area
15 pcs UNDER	positive netto count < low limit
MODE: CHECKWEIGH	activated Application
UNDER LIMIT -20 pcs	Low Limit
OVER LIMIT -60 pcs	High Limit
WREF 0.35423 oz	piece weigh, same as displayed

Totalization Printout: Weights as parameters (= weights are added up)

Printout	Description
N: 2	Number of weighing done, here 2
TOTAL: 1.955 g	Totalized value
MAX: 1.485 g	Maximum value
MIN: 0.470 g	Minimum value

Totalization Printout: Weights as parameters (= pieces and weights are added up)

Printout		Description
N:	25	Number of weighing done, here 25
TOTAL:	248 g	Totalized value of weights
	124 pcs	Totalized value of pieces
MAX:	22 g	Maximum value as weight
	11 pcs	Maximum value as number of pieces
MIN:	4 g	Minimum value as weight
	2 pcs	Minimum value as number of pieces

16.2 FCC Note**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Published by

Minebea Intec Bovenden GmbH & Co. KG | Leinetal 2 | 37120 Bovenden, Germany

Phone: +49.551.309.83.0 | Email: info@minebea-intec.com

www.minebea-intec.com

