

Instrument Manual

Process Controller Maxxis 4 PR 5500

	sartorius
Maxxis 4 NET 10000 0°°° 0°000 HP-A A 0.0000 NET 100000 0°° 0.0000 0.00249 1 1 0.0000 0.00249 1 1 1 1 0.00249 1 1 1 1 1 0.00249 1 </td <td>$\begin{array}{c} F_{1} \\ F_{1} \\ F_{1} \\ F_{1} \\ F_{2} \\ F_{3} \\ F_{4} \\ F_{1} \\ F_{4} \\ F_{4} \\ F_{4} \\ F_{5}$</td>	$ \begin{array}{c} F_{1} \\ F_{1} \\ F_{1} \\ F_{1} \\ F_{2} \\ F_{3} \\ F_{4} \\ F_{1} \\ F_{4} \\ F_{4} \\ F_{4} \\ F_{5} $

 Instrument Manual
 9499 050 55000
 Edition 2
 24.07.2015

 for PR 5500
 Release 2.20
 Edition 2
 24.07.2015

Please note

Any information in this document is subject to change without notice and does not represent a commitment on the part of SARTORIUS INTEC unless legally prescribed. This product should be operated only by trained and qualified personnel. In correspondence concerning this product the type, name and release number as well as all license numbers in relation to the product have to be quoted.

Important

This product is partly copyrighted. It may not be modified or copied and may not be used without purchasing or written authority from the copyright owner (SARTORIUS INTEC). By using this product, you agree to be bound by the terms stated herein.

Table of Contents

1	Introd	luction	1
2	Safety	y Information	2
2.1	Elec	trical Protective Class	2
2.2	Inte	nded Use	2
2.3	Initi	al Inspection	2
2.4	Befo	pre Commissioning	3
	2.4.1	Installation	3
	2.4.2	Opening the Instrument	4
	2.4.3	Mains Connection and Protective Grounding Conductor for PR 5500	4
2.5	RF I	nterference Suppression	6
2.6	Failu	ure and Excessive Stress	6
2.7	Imp	ortant Note	6
2.8	Rep	airs and Maintenance	6
	2.8.1	Static Sensitive Components	6
	2.8.2	Replacing Fuses	6
3	Proce	ss Controller	7
3.1	Gen	eral Information	7
3.2	0ve	rview of the Instrument	7
3.3	Hou	ising	9
	3.3.1	Housing dimensions	9
	3.3.2	Housing Dimensions with Strain Relief and Reinforcing frame	10
	3.3.3	Control Panel Cut-Out	11
3.4	Disp	olay and Control Panel	12
	3.4.1	Overview	12
	3.4.2	Display	13
	3.4.3	Operating Elements	15
	3.4.4	Operation using the VNC Program	19
3.5	0ve	rview of Connections	20
	3.5.1	Plug-in Cards	21
	3.5.2	Application Licenses	23
3.6	Inst	rument Versions	24
	3.6.1	Combinatorics for the Options	24

4	Device	e Installation	
4.1	Gene	eral Information	
4.2	Mec	hanical Preparation	
4.3	Harc	Iware Construction	
	4.3.1	Main Board	
	4.3.2	Network Port	
	4.3.3	USB Connection	
	4.3.4	SD Card Slot	
	4.3.5	RS-232 Interface (built-in)	
4.4	Acce	ssories	
	4.4.1	PR 5500/04 2x RS-485 Interface	
	4.4.2	PR 5500/32 2x RS-232 Interface	
	4.4.3	PR 5500/07 Analog Inputs and Outputs	
	4.4.4	PR 5500/10 Weighing Electronics Board	
	4.4.5	PR 5500/12 Digital Inputs and Outputs	
	4.4.6	PR 5500/13 Digital Inputs and Outputs	
	4.4.7	PR 5500/17 Digital Inputs and Outputs	
	4.4.8	PR 1721/61 ProfiBus-DP	
	4.4.9	PR 1721/64 DeviceNet	
	4.4.10	PR 1721/65 CC-Link	
	4.4.11	PR 1721/66 ProfiNet I/O	
	4.4.12	PR 1721/57 EtherNet-IP	
5	Comm	issioning	
5.1	Pow	er Failure/Data Protection/Warm Start/Cold Start	
	5.1.1	General Information	
	5.1.2	Power Failure	
	5.1.3	Warm Start	
	5.1.4	Cold Start	
	5.1.5	Overwrite Protection	
5.2	Swit	ching on the Device	
5.3	Swit	ching off the Device	
5.4	War	m-up Time	
5.5	Cont	figuring and Calibrating via the Front Keys/PC Keyboard	
5.6	Cont	figuring and Calibrating via a Notebook/PC	
	5.6.1	Connecting the Device to the Network and Determining the IP Address	
	5.6.2	Activating the 'DHCP' Network	116
	5.6.3	Searching for Devices in the Network using 'IndicatorBrowser'	
	5.6.4	Operation using the VNC Client Program	
	5.6.5	Operation via a Web Browser	
	5.6.6	Resetting Network	
5.7	Help	Function	
5.8	Sele	cting the Operating Language	

5.9	User	Management	
5	5.9.1	General Information	
5	5.9.2	Activating User Management	
5	5.9.3	Deactivating User Management	
5	5.9.4	User Login/Logout	
5.10	Syste	۲۳ Menu	
5	5.10.1	System Setup: Connected Devices	
5	5.10.2	System setup: Date & Time	
5	5.10.3	System setup: Operating parameters	
		System setup: Network parameters	
5	5.10.5	System setup: Network share connections	
5	5.10.6	System setup: Fieldbus parameters	
5	5.10.7	System setup: Weighing point - Weighing point A	
5	5.10.8	System setup: Weighing point: Weighing point A: Internal weighing point	
5	5.10.9	System setup: Weighing point: Weighing point A: xBPI scale	
5	5.10.10	System setup: Weighing point: Weighing point A: SBI scale	
5	5.10.11	System setup: Weighing point: Weighing point A: Pendeo Truck	145
5	5.10.12	System setup: Weighing point: Weighing point A: Pendeo Process	
5	5.10.13	System setup: Weighing point: Weighing point A: PR-Net Weighing Point	
5	5.10.14	System setup: Weighing point: Weighing point A: Mettler-Scale	
5	5.10.15	System setup: Weighing point: Weighing point A: SMA scale	
5	5.10.16	System setup: Display settings	
5	5.10.17	System setup: License settings	
5	5.10.18	System setup: User management	
5.11	Calib	rating the Internal Weighing Point	
5	5.11.1	General Information	
5	5.11.2	Showing the Calibration Data	
5	5.11.3	Increased Resolution (10-fold)	
5	5.11.4	Selecting the Calibration Mode	
		Determining the Maximum Capacity [Max]	
5	5.11.6	Determining the Scale Interval [Scale interval]	
5	5.11.7	Determining the Dead Load [Dead load at]	
5	5.11.8	Calibrating with Weight [Max at]	
5	5.11.9	Calibrating with mV/V [Max at]	
5	5.11.10	Calibrating the Scale with Load Cell Data (Smart Calibration) [by data]	
5	5.11.11	Subsequent Dead Load Correction	
5	5.11.12	Linearity	
5	5.11.13	Saving the Calibration	
5	5.11.14	Canceling Calibration	
5	5.11.15	Display Units	
5	5.11.16	Parameter Input	

5.12.1 General Information 182 5.12.2 xBPI Parameter Input for Scale Function 183 5.12.4 Setting up an xBPI Platform 183 5.12.4 Setting up an xBPI Deal Load 189 5.12.5 xBPI Calibration with the User Weight 190 5.12.7 xBPI Calibration with Automatic Weight Detection 192 5.12.7 xBPI Calibration with Automatic Weight 193 5.12.7 xBPI Calibration with Internal Weight 194 5.12.7 xBPI Linearization 196 5.12.1 xBPI Display Units 196 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter Input for Serial Interface 200 5.14.4 General Information 201 5.14.5 Search for load Cells and set deal load 202 5.14.4 General Information 201	5.12	2 Conf	iguring a xBPI Scale	
5.12.3 xBPI Parameter Input for Scale Function 183 5.12.4 Setting up an xBPI Platform 186 5.12.5 Setting the xBPI Calibration with the User Weight 190 5.12.7 xBPI Calibration with Automatic Weight Detection 192 5.12.8 xBPI Calibration with Automatic Weight 193 5.12.8 xBPI Calibration with Internal Weight 194 5.12.0 xBPI Calibration with Internal Weight 194 5.12.1 xBPI Calibration with Internal Weight 194 5.12.1 xBPI Calibration with Internal Weight 194 5.12.1 xBPI Calibration with Internal Weight 194 5.13.1 General Information 196 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter of Serial Interface 200 5.14.4 General Information 201 5.14.3 General Information 201 5.14.4 General Information 201 5.14.4 General Information 201 5.14.4 Search for Load Cells 202 5.14.5 Search for Load Cells 203		5.12.1	General Information	
5.12.4 Setting up an xBPI Platform 185 5.12.5 Setting the xBPI Dead load 189 5.12.6 xBPI Calibration with the User Weight 190 5.12.7 XPI Calibration with Default Weight 193 5.12.9 xBPI Calibration with Internal Weight 193 5.12.9 xBPI Calibration with Internal Weight 194 5.12.1 XBPI Display Units 198 5.12.1 XBPI Display Units 198 5.13 Setting the SBI Scale 199 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 200 5.14 Calibrating Digital Weighbridge Load Cell Pendeo® Truck' 201 5.14.2 Parameter Input for Serial Interface 202 5.14.4 Search for Load Cells 203 5.14.5 Search for Load Cells 203 5.14.6 View and Assign Load Cells 203 5.14.4 Search for Load Cells 203 5.14.5 Search for Load Cells 203 5.14.6 View and Assign		5.12.2	xBPI Parameter Input for Serial Interface	
5.12.5 Setting the xBPI Dead Load		5.12.3	xBPI Parameter Input for Scale Function	
5.12.6 xBPI Calibration with the User Weight 190 5.12.7 xBPI Calibration with Default Weight Detection 193 5.12.8 xBPI Calibration with Default Weight 194 5.12.9 xBPI Calibration with Internal Weight 194 5.12.10 xBPI Calibration with Internal Weight 194 5.12.10 xBPI Calibration with Internal Weight 196 5.12.11 xBPI Calibration 196 5.12.11 xBPI Calibration with Internal Weight 198 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 200 5.14.4 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.3 Calibration Sequence 202 5.14.4 Search for Load Cells 203 5.14.4 Search for Load Cells 204 5.14.5 Search for Load Cells 204 5.14.4 Search for Load Cells 204 5.14.5 Search for Load Cells 204 5.14.6 View and Assign Load Cells 204 <		5.12.4	Setting up an xBPI Platform	
5.12.7 xBPI Calibration with Default Weight 192 5.12.8 xBPI Calibration with Internal Weight 193 5.12.9 xBPI Calibration with Internal Weight 194 5.12.10 xBPI Calibration with Internal Weight 194 5.12.11 xBPI Display Units 196 5.12.11 xBPI Display Units 199 5.13.2 Parameter for Serial Interface 199 5.13.2 Parameter for Serial Interface 200 5.14 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.1 General Information 201 5.14.2 Parameter Input for Serial Interface 201 5.14.3 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.4 Galibration Sequence 202 5.14.5 Search for load cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 204 5.14.8 Assign Load Cells 204 5.14.4 Parameter input 216 5.14.5 Search for load Cells 204 5.14.6		5.12.5	Setting the xBPI Dead Load	
5.12.8 xBPI Calibration with Default Weight 193 5.12.9 xBPI Calibration with Internal Weight 194 5.12.10 xBPI Display Units 196 5.13.1 Setting the SBI Scale 199 5.13 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 199 5.14.4 Calibrating Digital Weighbridge Load Cell, Pendeo® Truck' 201 5.14.4 Calibration Sequence 202 5.14.4 Parameter Input for Serial Interface 201 5.14.5 Scarch for Load Cells 202 5.14.4 Verameter Input for Serial Interface 202 5.14.5 Scarch for Load Cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 204 5.14.8 Assign Load Cells 204 5.14.4 Service Function 216 5.14.5 Scarch for Load Cells 204 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Digital Precision Compressio		5.12.6	xBPI Calibration with the User Weight	190
5.12.9 xBPI Calibration with Internal Weight. 194 5.12.10 xBPI Linearization 196 5.13 Setting the SBI Scale 199 5.13 Setting the SBI Scale 199 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 200 5.14 Calibrating Digital Weighbridge Load Cell Pendeo® Truck' 201 5.14.1 General Information 201 5.14.2 Parameter Input for Serial Interface 201 5.14.2 Parameter Input for Serial Interface 201 5.14.3 Calibration Sequence 202 5.14.4 Search for Load Cells 203 5.14.5 Search for Load Cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 204 5.14.8 Assign Load Cells 204 5.14.9 Service Function 210 5.14.10 Correction 211 5.14.10 Correction 217 5.15.1		5.12.7	xBPI Calibration with Automatic Weight Detection	192
5.12.10 xBPI Linearization 196 5.12.11 xBPI Display Units 198 5.13 Setting the SBI Scale 199 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 199 5.14.1 General Information 200 5.14.2 Parameter Input for Serial Interface 201 5.14.3 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.4 Search for load cells and set dead load 202 5.14.5 Search for load Cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 207 5.14.8 Assign Load Cells 207 5.14.8 Assign Load Cells 207 5.14.9 Service Function 212 5.14.10 Corner Correction 212 5.14.11 Parameter input 214 5.14.2 Subsequent Dead Load Correction 217 5.15.1 General Information 218 5.15.2 Parameter Input for Serial Interface 218 5.15.3 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process' 218 5.15.4 Search for Load Cells 220			-	
5.12.11 xBPI Display Units 198 5.13 Setting the SBI Scale 199 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameteringabe 200 5.14 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.1 General Information 201 5.14.2 Parameter Input for Serial Interface 201 5.14.3 Calibration Sequence 202 5.14.4 Search for load cells and set dead load 202 5.14.5 Search for Load Cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 207 5.14.8 Assign Load Cells 207 5.14.8 Assign Load Cells 207 5.14.8 Assign Load Cells 207 5.14.9 Service Function 212 5.14.10 Corner Correction 212 5.14.11 Parameter input 214 5.14.2 Subsequent Dead Load Correction 217 5.15.1 General Information 218 5.15.2 Parameter Input for Serial Interface 218 5.15.3 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process' 218 5.15.4 Search fo		5.12.9	xBPI Calibration with Internal Weight	
5.13 Setting the SBI Scale 199 5.13.1 General Information 199 5.13.2 Parameter for Serial Interface 199 5.13.3 Parameter for Serial Interface 199 5.14 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck' 201 5.14.1 General Information 201 5.14.2 Parameter Input for Serial Interface 201 5.14.3 Calibration Sequence 202 5.14.4 Search for load cells and set dead load 202 5.14.5 Search for Load Cells 203 5.14.6 View and Assign Load Cells 204 5.14.7 Calibrating Load Cells 207 5.14.8 Assign Load Cells 207 5.14.9 Service Function 210 5.14.7 Calibrating Digdal Cells 207 5.14.8 Assign Load Cell 200 5.14.9 Service Function 210 5.14.10 Corner Correction 212 5.15.1 General Information 216 5.15.2 Parameter Input for Serial Interface 218 <		5.12.10	xBPI Linearization	
5.13.1General Information1995.13.2Parameter for Serial Interface1995.13.3Parameter for Serial Interface2005.14Calibrating Digital Weighbridge Load Cell , Pendeo® Truck'2015.14.1General Information2015.14.2Parameter Input for Serial Interface2015.14.3Calibration Sequence2025.14.4Search for load cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2045.14.8Assign Load Cells2075.14.8Assign Load Cells2075.14.9Service Function2105.14.10Correction2105.14.2Parameter input2105.14.3Service Function2105.14.4Service Function2105.14.5Search for Load Correction2105.14.11Parameter input2115.15.1General Information2125.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.4Search for Load Cells2205.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Diad Cells2225.15.8Assign Load Cells2225.15.9<		5.12.11	xBPI Display Units	198
5.13.2Parameter for Serial Interface1995.13.3Parametereingabe2005.14Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck'2015.14.1General Information2015.14.2Parameter Input for Serial Interface2015.14.3Calibration Sequence2025.14.4Search for Load cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2045.14.8Assign Load Cells2075.14.8Assign Load Cells2075.14.9Service Function2105.14.10Correct Correction2115.14.11Parameter input2145.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.2Parameter Input for Serial Interface2195.15.4Search for Load Cells2205.15.5Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Sequence2185.15.8Search for Load Cells2205.15.6View and Assign Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2205.15.8Assign Load Cells2215.15.9Service Function2	5.13	8 Setti	ng the SBI Scale	199
5.13.3Parametereingabe2005.14Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck'2015.14.1General Information2015.14.2Parameter Input for Serial Interface2025.14.3Calibration Sequence.2025.14.4Search for Load Cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2045.14.8Assign Load Cells2045.14.9Service Function2105.14.9Service Function2105.14.10Corner Correction2125.14.11Parameter input2145.14.12Subsequent Dead Load Correction2175.15.13General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for Load Cells2205.15.5Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2215.15.7Calibrating Load Cells2205.15.8Assign Load Cells2205.15.9Service Function2275.15.0Corner Correction2275.15.10Corner Correction2295.15.11Parameter input2205.15.11Parameter input2205.15.11Parameter input2205.15.1		5.13.1	General Information	199
5.14Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck'.2015.14.1General Information2015.14.2Parameter Input for Serial Interface2015.14.3Calibration Sequence.2025.14.4Search for load cells and set dead load.2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells.2045.14.7Calibrating Load Cells.2045.14.8Assign Load Cells.2045.14.9Service Function.2105.14.10Corner Correction2125.14.11Parameter input2145.14.2Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for Load Cells2205.15.5Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2215.15.7Calibrating Load Cells2215.15.8Assign Load Cells2225.15.9Service Function2215.15.9Service Function2225.15.0Corner Correction2225.15.10Corner Correction2225.15.11Parameter input2245.15.11Parameter input2265.15.11		5.13.2	Parameter for Serial Interface	199
5.14.1General Information2015.14.2Parameter Input for Serial Interface2015.14.3Calibration Sequence2025.14.4Search for load cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2075.14.8Assign Load Cells2075.14.9Service Function2105.14.10Corner Correction2105.14.11Parameter input2145.14.2Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for Load Cells2205.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibration Sequence2185.15.8Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2215.15.8Assign Load Cells2225.15.9Service Function2225.15.0Corner Correction2225.15.10Corner Correction2225.15.11Parameter input2305.15.11Parameter input230		5.13.3	Parametereingabe	200
5.14.2Parameter Input for Serial Interface2015.14.3Calibration Sequence2025.14.4Search for load cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2075.14.8Assign Load Cells2075.14.9Service Function2105.14.10Corner Correction2105.14.11Parameter input2145.14.12Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2225.15.7Calibrating Load Cells2225.15.8Assign Load Cells2225.15.9Service Function2225.15.13Calibration Sequence2215.15.4Search for Load Cells2225.15.5Search for Load Cells2225.15.6View and Assign Load Cells2225.15.7Calibrating Load Cells2225.15.8Assign Load Cells2225.15.9Service Function2225.15.10Corner Correction2225.15.11P	5.14	l Calib	rating Digital Weighbridge Load Cell ,Pendeo® Truck'	201
5.14.3Calibration Sequence.2025.14.4Search for load cells and set dead load.2025.14.5Search for Load Cells.2035.14.6View and Assign Load Cells.2045.14.7Calibrating Load Cells.2075.14.8Assign Load Cells.2075.14.9Service Function.2105.14.10Corner Correction2125.14.11Parameter input2145.14.2Subsequent Dead Load Correction.2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2195.15.3Calibration Sequence.2195.15.4Search for load cells and set dead load2195.15.5Search for load Cells.2205.15.6View and Assign Load Cells.2205.15.7Calibrating Load Cells.2215.15.8Assign Load Cells.2215.15.6View and Assign Load Cells.2225.15.7Calibrating Load Cells.2245.15.8Assign Load Cells.2275.15.9Service Function.2275.15.0Corner Correction2275.15.10Corner Correction2295.15.11Parameter input230		5.14.1	General Information	201
5.14.4Search for load cells and set dead load2025.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2075.14.8Assign Load Cell Name2105.14.9Service Function2125.14.10Corner Correction2125.14.11Parameter input2145.14.2Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibrating Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2205.15.8Assign Load Cells2205.15.9Service Function2215.15.1Calibrating Load Cells2205.15.3Search for Load Cells2205.15.4Search for Load Cells2205.15.5Search for Load Cells2215.15.6View and Assign Load Cells2225.15.7Calibrating Load Cell Name2275.15.8Assign Load Cell Name2275.15.9Service Function2295.15.11Parameter input230		5.14.2	Parameter Input for Serial Interface	201
5.14.5Search for Load Cells2035.14.6View and Assign Load Cells2045.14.7Calibrating Load Cells2075.14.8Assign Load Cell Name2105.14.9Service Function2105.14.10Correction2125.14.11Parameter input2145.14.2Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2205.15.8Assign Load Cells2205.15.9Service Function2215.15.0Corner Correction2225.15.10Corner Correction2225.15.11Parameter input230		5.14.3	Calibration Sequence	202
5.14.6View and Assign Load Cells.2045.14.7Calibrating Load Cells.2075.14.8Assign Load Cell Name2105.14.9Service Function.2105.14.10Correction2125.14.11Parameter input2145.14.12Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2195.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2205.15.7Calibrating Load Cells2205.15.8Assign Load Cells2205.15.9Service Function2225.15.0Correction2225.15.10Correction2225.15.11Parameter input2225.15.11Parameter input230		5.14.4	Search for load cells and set dead load	202
5.14.7Calibrating Load Cells.2075.14.8Assign Load Cell Name2105.14.9Service Function2105.14.10Corner Correction2125.14.11Parameter input2145.14.2Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibratino Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2225.15.8Assign Load Cells2225.15.9Service Function2275.15.0Correc Correction2295.15.10Corner Correction2295.15.11Parameter input230		5.14.5	Search for Load Cells	
5.14.8Assign Load Cell Name2105.14.9Service Function2105.14.10Corner Correction2125.14.11Parameter input2145.14.12Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2225.15.8Assign Load Cells2225.15.9Service Function2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.14.6	View and Assign Load Cells	204
5.14.9Service Function2105.14.10Corner Correction2125.14.11Parameter input2145.14.12Subsequent Dead Load Correction2175.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cells2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.14.7	Calibrating Load Cells	207
5.14.10 Corner Correction2125.14.11 Parameter input2145.14.12 Subsequent Dead Load Correction2175.15 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1 General Information2185.15.2 Parameter Input for Serial Interface2185.15.3 Calibration Sequence2195.15.4 Search for load cells and set dead load2195.15.5 Search for Load Cells2205.15.6 View and Assign Load Cells2215.15.7 Calibrating Load Cells2225.15.8 Assign Load Cells2225.15.9 Service Function2275.15.10 Corner Correction2295.15.11 Parameter input230		5.14.8	Assign Load Cell Name	210
5.14.11 Parameter input.2145.14.12 Subsequent Dead Load Correction.2175.15 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'.2185.15.1 General Information.2185.15.2 Parameter Input for Serial Interface.2185.15.3 Calibration Sequence.2195.15.4 Search for load cells and set dead load.2195.15.5 Search for Load Cells.2205.15.6 View and Assign Load Cells.2215.15.7 Calibrating Load Cells.2245.15.8 Assign Load Cell Name.2275.15.9 Service Function.2275.15.10 Corner Correction.2295.15.11 Parameter input.230		5.14.9	Service Function	210
5.14.12 Subsequent Dead Load Correction2175.15 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1 General Information2185.15.2 Parameter Input for Serial Interface2185.15.3 Calibration Sequence2195.15.4 Search for load cells and set dead load2195.15.5 Search for Load Cells2205.15.6 View and Assign Load Cells2215.15.7 Calibrating Load Cells2245.15.8 Assign Load Cells2275.15.9 Service Function2275.15.10 Corner Correction2295.15.11 Parameter input230		5.14.10	Corner Correction	212
5.15Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'2185.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cells2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230			•	
5.15.1General Information2185.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cells2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.14.12	Subsequent Dead Load Correction	217
5.15.2Parameter Input for Serial Interface2185.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230	5.15	5 Calib	rating Digital Precision Compression Load Cell 'Pendeo® Process'	218
5.15.3Calibration Sequence2195.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.1	General Information	218
5.15.4Search for load cells and set dead load2195.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.2	Parameter Input for Serial Interface	218
5.15.5Search for Load Cells2205.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.3	Calibration Sequence	219
5.15.6View and Assign Load Cells2215.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.4	Search for load cells and set dead load	219
5.15.7Calibrating Load Cells2245.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.5	Search for Load Cells	220
5.15.8Assign Load Cell Name2275.15.9Service Function2275.15.10Corner Correction2295.15.11Parameter input230		5.15.6	View and Assign Load Cells	221
5.15.9 Service Function 227 5.15.10 Corner Correction 229 5.15.11 Parameter input 230		5.15.7	Calibrating Load Cells	224
5.15.10 Corner Correction		5.15.8	Assign Load Cell Name	227
5.15.11 Parameter input		5.15.9	Service Function	227
		5.15.10	Corner Correction	229
5.15.12 Subsequent Dead Load Correction233		5.15.11	Parameter input	230
		5.15.12	Subsequent Dead Load Correction	233

Net Weiging Point	234
General Information	234
Parameter Input	234
tler-Scale	
General Information	236
Parameter Input in Mettler-Scale Menu	236
Parameter Input for Serial Interface	236
Parameters Input for Scale Function	
ing the SMA Scale	240
General Information	240
Parameter for Serial Interface	240
Parametereingabe	241
eral Parameter Settings	242
Equipment Settings	242
Setting the Date and Time	253
Network Parameters	
Network Share Connections	
Fieldbus Parameters	
Display Settings	271
License Settings	272
em Information	274
Showing the Version	274
Showing the Status	275
Showing Alarm information	276
Showing Hardware Options	277
Showing Calibration Check Numbers	279
5	
) Printing Out Configuration Settings	
	Net Weiging Point General Information Parameter Input tter-Scale. General Information Parameter Input in Mettler-Scale Menu Parameter Input for Serial Interface Parameters Input for Scale Function ing the SMA Scale. General Information Parameter for Serial Interface Parameter Settings. Equipment Settings. Setting the Date and Time Setting the Operating Parameters Network Parameters Network Share Connections. Fieldbus Parameters Display Settings License Settings em Information. Showing the Version Showing Hardware Options. ModBus-TCP IO Modules Browsing the Alibi Memory Showing Pendeo data Displaying Even

6	Extend	led Functions	284
6.1	Syste	em Maintenance	284
	6.1.1	General Information	284
	6.1.2	Saving to selected Media (Backup)	284
	6.1.3	Restoring Backup Data from External Media	289
	6.1.4	Exporting to selected Media	295
	6.1.5	Importing Data from External Media	298
	6.1.6	Alibi Memory Maintenance	303
	6.1.7	SD Card Maintenance	314
	6.1.8	Creating a Service Report	316
	6.1.9	Switching Off the Device	317
	6.1.10	Updating the Software	318
	6.1.11	Resetting the Device to the Factory Settings	
	6.1.12	Hardware Test	330
	6.1.13	Functions via the WEB Site	338
6.2	Alibi	Memory	346
	6.2.1	General Information	346
	6.2.2	Erasing the Alibi Memory	346
	6.2.3	Browsing the Alibi Memory	348
	6.2.4	Exporting and Printing Alibi Data Records	351
6.3	BIOS	Menu	352
	6.3.1	General Information	352
	6.3.2	Accessing the BIOS Menu	352
	6.3.3	Troubleshooting Menu	354

7	ModBus Protocol	
7.1	General Description	
7.2	ModBus-RTU	
7.3	ModBus-TCP/UDP	
7.4	Functions	
7.5	Error Messages	
7.6	Word Addresses	
8	EW Com Protocol	
8.1	Weight Function Commands	
8.2	Other Commands	
8.3	SPM Commands	
8.4	Error Messages for EW Com Commands	
9	Repairs and Maintenance	
9.1	Battery for Date/Time	
9.2	Rechargeable Battery for Voltage Supply	
9.3	Solder Work	
9.4	Cleaning	
10	Disposal	
11	Error Messages	
11.1	1 Error Messages in Measuring Circuit	
11.2	2 Error Messages with xBPI Scales	
	11.2.1 Error Messages	
	11.2.2 Error during "Set zero" and "Set tare"	
11.3	3 Error Messages with Pendeo [®] Load Cells	
11.4	4 Error messages with PR-Net Weighing Point	
11.5	5 Error messages with Type ,Mettler-Scale' Weighing Point	
11.6	6 Error Messages during Calibration	
	11.6.1 Determining the Maximum Capacity (MAX)	
	11.6.2 Determining the Scale Interval	
	11.6.3 Determining the Dead Load	
	11.6.4 Calibrating with Weight	

Table of Contents


Note	on Using 'Free Software'	
Deco	ding the Serial Number	
Gene	ral Data	
12.3.1	Battery for Date/Time	
12.3.2	Rechargeable Battery for Voltage Supply	
12.3.4	Power Connection 230 V AC	
12.3.5	Power Connection 24 V DC	
Effec	t of Ambient Conditions	
12.4.1	Ambient Conditions	
12.4.2	Electromagnetic Compatibility (EMC)	
12.4.3	RF Interference Suppression	
Mech	nanics	
12.5.1	Design	
12.5.2	Dimensions	
12.5.3	Weights	
Docu	mentation on the Enclosed CD	
Appen	dix	
Conf	iguration Printout	
Test	Printout	
Alibi	Printout	
LEDs		
Term	inal Coding	
Exch	anging the Plug-In Cards	
13.6.1	Safety Information	
13.6.2	Optional and Fieldbus Cards	
Repla	acing the Device	
Repla	acing the SD Card	
	Deco Gene 12.3.1 12.3.2 12.3.3 12.3.4 12.3.5 Effec 12.4.1 12.4.2 12.4.2 12.5.1 12.5.2 12.5.3 Docu Append Conf Test I Alibi LEDs Term Exchi 13.6.1 13.6.2 Repla	Decoding the Serial Number

1 Introduction

- Please read all the instructions carefully and completely before using the instrument.
- ▶ Read the safety precautions carefully.
- ▶ These instructions are part of the product. Keep them in a safe and easily accessible location.

Symbols and Signs

The following symbols are used in this manual:



- Indicates a required action
- Describes the result of an action
- Indicates an item in a list
- [] Encloses menu items and soft keys

Hotline

Phone: +49.40.67960.444 Fax: +49.40.67960.474 E-mail: technical.support@sartorius.com

2 Safety Information

2.1 Electrical Protective Class



Warning!

This instrument has been built and tested in compliance with the safety regulations for measuring and control instrumentation for protective class I (protective grounding conductor) according to IEC 1010/EN 61010 or VDE 0411. The instrument was in perfect condition with regard to safety features when it left the factory. To maintain this condition and to ensure safe operation, the operator must follow the instructions and observe the warnings in this manual.

2.2 Intended Use

This instrument is only intended for use in weighing and metering systems, and is especially well-suited for tank and container scales, weigh bridges, platform weighers, crane weighers, dispensing systems and as a weighing indicator in intelligent control systems. Product operation, commissioning and maintenance must be performed by trained and qualified personnel who are aware of and able to deal with the related hazards and take suitable measures for self-protection.

The instrument reflects the state of the art. No warranty is given that the product is free of faults, especially not in conjunction with third-party software and hardware components required for operation.

The manufacturer does not accept any liability for damage caused by other system components or due to incorrect use of the product. The use of this product signifies recognition of the stipulations listed above.

2.3 Initial Inspection

Check the contents of the consignment for completeness. Check the contents visually to determine whether any damage has occurred during transport. If there are grounds for rejection of the goods, a claim must be filed with the carrier immediately. The Sartorius Intec sales or service organization must also be notified.

2.4 Before Commissioning



Visual inspection!

Before commissioning as well as after storage or transport, inspect the device visually for signs of mechanical damage.

2.4.1 Installation

Design	Protection class	Installation
Control cabinet housing	IP 65, back IP 20	Control Panel Cut-Out

To ensure proper cooling of the instrument, make sure air circulation around the instrument is not blocked. Avoid exposing the instrument to excessive heat; e.g., from direct sunlight. Ambient conditions must be taken into account at all times.

With outdoor mounting, make sure that adequate weather protection is provided (for temperatures, see Chapter 12.4.1).

2.4.2 Opening the Instrument

	High Voltage! Working on the instrument while it is switched on may have life-threatening consequences.
🛆 Danger	Disconnect the instrument from the supply voltage. When removing covers or parts using tools, live parts or terminals may be exposed.
	Please note that capacitors in the instrument may still be charged even after disconnecting the device from all voltage sources.

This instrument contains electrostatically sensitive components. For this reason, an equipotential bonding conductor must be connected when working on the open instrument (antistatic protection).

2.4.3 Mains Connection and Protective Grounding Conductor for PR 5500

2.4.3.1 Version 230 V AC



Mains connection

Safe interruption of both supply voltage conductors must be provided for, either by disconnecting the power connector or using a separate switch.

The instrument is protected via two fuses (see Chapter 12.3.4) on the back of the device (primary side).

The instrument is equipped with a wide range power supply and covers AC systems with a frequency of 50 Hz/60 Hz and a voltage range of 100 V AC to 240 V AC $\pm 10\%/-15\%$ automatically (without manual selection).

The power supply is protected against short circuits and overloads, and disconnects automatically in case of a fault.

If the electrical protection has triggered:

- Disconnect the device from all power sources and wait at least 1 minute.
- Determine and eliminate the cause of the error.
- Reconnect the device to the supply voltage.

Protective grounding conductor

The instrument must be connected to a protective ground via a protective grounding conductor (PE) in the power connector.

The power cable contains a protective grounding conductor which must not be interrupted inside or outside the device. The protective grounding conductor is connected to the back of the housing inside the instrument.

2.4.3.2 Version 24 V DC




Mains connection

This version is designed for 24 V direct current. The supply is established via three spring clamp terminals (+ PE -). The instrument is protected against incorrect polarity.

Protective grounding conductor

The protective grounding must be connected to the central terminal (PE).



Fuse

The instrument is protected in the + line via a fuse (see Chapter 12.3.5) inside the device (primary side).

2.5 **RF Interference Suppression**

The device is intended for use in the industrial sector and can cause RF interference if used in residential areas (see Chapter 12.4.3). In this case, the operator may be required to put suitable countermeasures in place.

2.6 Failure and Excessive Stress

If there is any reason to assume that safe operation of the instrument is no longer ensured, shut it down and make sure it cannot be used. Safe operation is no longer ensured if any of the following is true:

- The instrument is physically damaged.
- The instrument does not function.
- The instrument has been subjected to stresses beyond the tolerance limits (e.g., during storage or transport).

2.7 Important Note

Make sure that the construction of the instrument is not altered to the detriment of safety. In particular, leakage paths, air gaps (of live parts) and insulating layers must not be reduced. Sartorius Intec cannot be held responsible for personal injury or property damage caused by an instrument repaired incorrectly by an operator or installer.

2.8 Repairs and Maintenance

Repairs are subject to inspection and must be carried out at Sartorius Intec. In case of defect or malfunction, please contact your local Sartorius Intec dealer or service center for repair. When returning the instrument for repair, please include a precise and complete description of the problem.

Maintenance work must be carried out only by a trained technician aware of the involved hazards, whereby the relevant precautions must be taken in account.

2.8.1 Static Sensitive Components

This instrument contains electro-statically sensitive components. Therefore, potential equalization must be provided when working on the device (antistatic protection).

2.8.2 Replacing Fuses



Warning!

The use of repaired fuses and bypassing the fuse holder is prohibited. Only the fuses specified in Chapter 12.3 are allowed.

3 **Process Controller**

3.1 General Information

This instrument is equipped with a TFT color display, and a function/alphanumeric keypad. With the corresponding application, this device is a powerful system for managing/documenting weighing and dosing processes. It combines the functions of a user-friendly interface as well as a weighing and dosing instrument, PLC and interfaces.

The instrument is programmable according to the IEC 61131-3 standard (requires the PR 1750/60 development tool accessory).

3.2 Overview of the Instrument

- Accuracy 10.000 d at 0,5 μ V/d for the weighing electronics
- High-speed conversion with response times from 5 msec
- Weight display with status and weight unit on a TFT color display
- Housing for installation in a control cabinet. Protection type front IP 65, else IP 20
- Integrated LAN connection (10/100 Mbps) for data transmission
- USB 2.0 connection (Type A, i = 200 mA), integrated for printer, USB stick, PC keyboard, barcode scanner, external splitter (hub)
- SD card slot (incl. SD card)
- Integrated RS-232 interface, e.g. for connecting a PC, printer or remote display
- Can be expanded using the following plug-in cards:
 - 2x RS-485 interface card PR 5500/04
 - Analog E/A interface card PR 5500/07
 - Weighing electronics board PR 5500/10 (W1)
 - Digital E/A interface card PR 5500/12
 - Digital E/A interface card PR 5500/13
 - Digital E/A interface card PR 5500/17
 - 2x RS-232 interface card PR 5500/32
 - Fieldbus cards PR 1721/6x
- Wide range power supply for 100 to 240 V AC, protection class I (protective grounding conductor)
- Version for 24 V direct current
- Plug-in connections on the rear side of the device for load cells, inputs/outputs, LAN connection, serial interfaces
- Alternative operation using PC tool (Browser/VNC)
- Calibration using weights, by entering mV/V values, or directly, using load cell data (Smart Calibration)
- Software configuration of the interface cards, e.g. for remote display or printer
- Analog test for the weighing electronics
- Overwrite protection:
 - via a max. of 3 CAL switches (two on the main board and one on the weighing electronics board)
 - via software

Communication Protocols

For the internal RS-232:

- Remote display protocol
- Printer
- ModBus protocol
- xBPI protocol
- SBI protocol
- EW-Com protocol

For the internal LAN interface:

- ModBus-TCP
- Ethernet-TCP/IP
- OPC


Fieldbus slave (accessories):


- PR 1721/61 ProfiBus DP
- PR 1721/64 DeviceNet
- PR 1721/65 CC Link
- PR 1721/66 ProfiNet I/0
- PR 1721/67 EtherNet IP

3.3 Housing

3.3.1 Housing dimensions


The keypad and the display form one unit with the front. A rectangular cut-out is required for the installation. Cable connections are made at the back of the housing.





Side view





Back view





All dimensions in mm.

3.3.2 Housing Dimensions with Strain Relief and Reinforcing frame

The dimensions with the following options must be observed for installation:


Pos.	Designation
1	Reinforcing frame
2	Screen clamping rail
3	Cable clamps





Side view

Front view




Back view

Note All dimensions in mm.

3.3.3 Control Panel Cut-Out


The control panel cut-out must be made before installing the unit.





3.4 Display and Control Panel


3.4.1 Overview



3.4.2 Display

The TFT display shows weight values of up to 7 digits with a decimal point and a plus or minus sign. Available weight units are t, kg, g, mg, lb and oz.

The current weight value is displayed under the weight display as a bar graph in relation to the maximum capacity. When the maximum capacity (Max) reaches 100 %, the bar graph is located on the right.



info line

Value type/Polarity sign		Zero/Standstill/Dosing/Monitor.		Symbols		Mass unit
В	Gross weight		Weight value	\wedge	ld cell)	t
			standstill		in 10-fold load ce	kg
G	Gross weight in NTEP or NSC mode	→0←	The gross weight value is within ±1/4 d		ible i .g. 1 /ed lo	g
	NSC mode		of zero		not permissible metrology (e.g. ution, deactived	mg
				-	per rolog 1, de	lb
NET	Net weight	\diamond	Filling mode:		not meti itior	0Z
	(Net = gross - tare)		flashes when filling is "held"; rapid flashing - indicates "error"		Value not permissible in legal metrology (e.g. 10-fold resolution, deactived load cell)	
Т	Tare weight		- mulcates enor	R1	Range 1	
PT	Preset tare			R2	Range 2	
· ·	not tared			R3	Range 3	
no indi-			Pendeo load cells:	WP-A	Weighing p	ooint A
cation	- Gross, not tared	_	plausibility monito-			
			ring; average value deviation of each load cell			
User	additional weight value,	ш і	Pendeo load cells: Temperature control;	Max	Maximum (weighing	
Setp	application-specific - function		1n load cells are	Min	Minimum v	weight
Diff			above/below the per- missible temperature			
+	Positiv value	_				
	Negativ value					

lcon	Description
<u>₩</u> ⊄	Remote control via VNC (Virtual Network Computing) is active.
ø	The clock battery is empty.The standby battery is empty.
4	The standby battery is too hot and is not charging. If this does not go away, then the ambient temperature must be checked, see Chapter 3.4.3.2.
∿	 A USB device has been connected that is not supported. The max. current of i_{max} = 200 mA has been exceeded.
\$⊙	Check newly connected devices.
†	USB stick recognized and ready for use.
()	Stick is in use and may not be removed.
*	IP address conflict in network settings

3.4.3 **Operating Elements**

3.4.3.1 Front keys

The following table shows the basic meanings of symbols for the front keys. The keys could have additional meanings depending on the applications used.

→T←	Tare The current gross weight is stored in the tare memory if - the weight value is stable - the device is not in error status (function dependent on configuration)	Display gross/tare weight You switch to the next weight by pressing the key (only tared scale). During calibration, pressing this key switches the weight to a 10-fold resolution for 5 seconds.
→0 ←	 Sets gross weight to zero if the weight value is stable the weight is within the zero setting range 	
	(function dependent on configuration)	

Application keys



Starts an application-specific printout.

Navigati	ion/menu keys				
	Scroll up in the menu		ОК	Confirm entry/selection	
▼ Scroll down in the menu			EXIT	 Cancel entry/selection (after a security prompt), without saving the change. Exit the parameter/menu window 	
•	Cursor moves to the leftSelectionExit the menu window		С	Pressing the Delete key deletes individual characters (within an entry) or entire character sections, see also page 17.	
•	 Cursor moves to the right Selection Confirm entry/selection 	-	Soft key 1 5	Select corresponding menu functions, see also Chapter 3.4.3.2.	
			MENU	Switches to the Operating menu.	
Function keys					
F1 Assign with a defined function (Operating parameters menu).		START	Starts an application-specific function.		
F2	2 Assign with a defined function (Operating parameters menu).		STOP	Stops an application-specific function.	
?	Displays the corresponding Help window.				
LED					
Operatin	ng state	Color	LED status		
Normal o	operation		turned off		
Power failure <5 seconds red		flashing slowly	After 5 seconds, the unit will continue normally.		
Power failure >5 seconds red		red	flashing quickly	The device performs a data backup. Is then the power on, the unit returns to the normal operation (LED turned off).	
After bac existing	ckup the power failure is still		turned off	The unit turns off.	
Power voltage is on			turned off	The device performs a warm start see Chapter 5.1.3.	

Alphanume	ric keypad					
				Toggle k	key	
F1 #"()=	2 ABC	F2 3	START			ssing this will toggle between the following ut modes:
				≞ ◆ ▶	-	Cursor
4	5	6	STOP	™ ABC	-	Uppercase letters
GHI .	JKL	MNO		🖷 abc	-	Lowercase letters
MENU 7 PQRS ?	8 TUV 0	EXIT 9 WXYZ	ок	₩ IME	-	Pinyin When Chinese was selected or set under [Operating parameters] - [Input method]. Hepburn When Japanese was selected or set under [Operating parameters] - [Input method].
				₩ 1 23	-	Numbers
				≞∢) ≞≞ unit	-	Units Double-click on the toggle key opens a small selection window.
				mg kg t Ib oz		Select the unit with cursor keys $\blacktriangle/\checkmark$ and confirm with OK .
				Input wi	itho	ut character table
				ABC 2	e.g. wil tim	ssing this once will display the first character, 'A' in the cursor position. Pressing it twice display 'B' in the cursor position and three- es will display 'C.' iting approx. 2 seconds will complete the
						racter entry.
						nly numeric values are required for input, ers are not enabled.
				С		a can delete the character to the left of the sor by pressing the Delete key ${f C}$ during entry.
					Del	merical value input (e.g. weight value): ete the content of the input field by pressing Delete key C .

Double-clicking the key displays the character table.
The toggle function is turned off.
 Procedure Select the desired character with the cursor. The selected character is shown magnified in the field at the top right. Press the OK key to enter the character in the input field. Another double-click on the toggle key and other characters can be input as described

Input field

Enter user name and password User name Password	pimbe@ #########	Left of the input field is displayed whether numeric and/or alphabetical characters can be entered.
enter user name and password User name Password	₩ABC ₩ABC *******	— The respective setting is displayed.
Keyboard shortcuts		
STOP + EXIT Trigger a cold start, so	ee also Chapter 5.19.3.	

3.4.3.2 Operation Using Soft Keys

The functions of the five soft keys below the graphic display are indicated in the bottommost text line of the display. In the descriptions of operating sequences which entail the use of soft keys, the soft key function to be selected is shown in square brackets; the soft key symbol is not displayed, e.g. [Save].

Standard Save

3.4.3.3 Selection using the Navigation Keys

Menu

You can navigate menus using the cursor keys, the **OK** key and the **EXIT** key.

Parameters

Individual parameters are selected using the \mathbf{v}/\mathbf{A} keys.

The required values/texts are entered via the alphanumeric keys.

Checkmarks are set \blacksquare using the **OK** key.

If the list of parameters is long, a vertical bar graph on the left (black/gray) shows which part of the list is displayed.

Available selection lists are indicated by the following arrow \blacktriangleright .

The parameter is selected in the selection list via the **OK** key.

3.4.3.4 PC Keys


The device can also be operated via a PC keyboard. The corresponding key assignments can be viewed in the following table, see also Chapter 4.3.3.2.

PC keyboard	Front keypad
F1	F1
F2	F2
F3	?
F4	MENU
F5 to F9	Soft key 1 to 5
F10	:: :
F11	START
F12	STOP
ESC	EXIT
Cursor keys: ↑, ↓, ←, →	▲, ▼, ◀, ►
ENTER	OK
Backspace	С
Numeric keypad	Alphanumeric keypad

3.4.4 Operation using the VNC Program

User interface, see Chapters 3.4.1, 3.4.2 and 3.4.3.1.

3.5 Overview of Connections



3.5.1 Plug-in Cards

PR 5500/04The interface can be configured via the software. For more information, see Chapter 4.4.1.Option-1/FB and/or O OPR 5500/07Analog input: internal 14 bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.Option-1/FB and/or O Option-1/FB and/or O Option-1/FB and/or O Option-1/FB and/or O Option-1/FB and/or O Malog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.WP APR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4.Option-1/FB and/or OPR 5500/124 passive opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.6.Option-1/FB and/or OPR 4 digital inputs d digital inputs d digital inputs d digital inputs d digital inputs4 active opto-decoupled inputs option-1/FB and/or OPR 4 digital inputs d digital inputs d digital inputs d digital inputs4 active opto-decoupled inputs option-1/FB and/or OPR 5500/13For more information, see Chapter 4.4.6.Option-1/FB and/or OPR 5500/13For more information, see Chapter 4.4.6.Option-1/FB and/or O	Position	
2 serial RS-485 interfacesthe software. For more information, see Chapter 4.4.1.Option-1/FB and/or OPR 5500/07Analog input: internal 14 bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.Option-1/FB and/or OPR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4.WP APR 5500/124 passive opto-decoupled inputs connected. For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O		
Z scharko-405 mitchactsFor more information, see Chapter 4.4.1.Option-1/FB and/or O1 analog inputinternal 14 bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.WP APR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4.WP APR 5500/124 passive opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or O4 digital inputs 4 digital inputs4 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O4 digital inputs 4 digital inputs 4 digital inputs 4 relay outputs with potential-free change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, seeOption-1/FB and/or O4 digital inputs 4 digital inputs 4 digital outputs4 relay outputs with potential-free change-over contacts For more information, seeOption-1/FB and/or O	Option-2	
Chapter 4.4.1.Option-1/FB and/or OPR 5500/07Analog input: internal 14 bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.Option-1/FB and/or OPR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing electronics systems can be connected. For more information, see Chapter 4.4.4.WP APR 5500/124 passive opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 44 igital inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O		
1 analog inputinternal 14 bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA For more information, see Chapter 4.4.3.We analysisPR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.WP APR 5500/124 passive opto-decoupled inputs chapter 4.4.4.Option-1/FB and/or O4 digital inputs 4 digital outputs4 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/13 4 digital inputs 4 digital inputs4 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/13 4 digital outputs4 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or O		
Counting inputcounts, @ e.g. 0 to 20 mA/0 to 10 VAnalog outputinternal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mAFor more information, see Chapter 4.4.3.For more information, see Chapter 4.4.3.PR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.WP APR 5500/124 passive opto-decoupled inputs chapter 4.4.4.Option-1/FB and/or OPR 5500/124 relay outputs with potential-free chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 6500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O	Option-2	
I analog output@ e.g. 0 to 20 mA/0 to 10 VAnalog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mAFor more information, see Chapter 4.4.3.PR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4.WP APR 5500/124 passive opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or 04 digital inputs4 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or 0PR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or 0		
Analog output: internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mAFor more information, see Chapter 4.4.3.PR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.WP APR 5500/124 passive opto-decoupled inputs Chapter 4.4.4.Option-1/FB and/or O4 digital inputs4 relay outputs with potential-free Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs For more information, see Chapter 4.4.5.Option-1/FB and/or O		
resolution of 20,000 @ 20 mAFor more information, see Chapter 4.4.3.PR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.WP APR 5500/124 max. of two internal weighing electronics systems can be connected.Option-1/FB and/or O4 digital inputs4 relay outputs with potential-free chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O4 digital inputs 4 digital outputs4 relay outputs with potential-free change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O4 digital inputs 4 digital outputs4 relay outputs with potential-free change-over contacts For more information, seeOption-1/FB and/or O4 digital outputs500/134 relay outputs with potential-free change-over contacts For more information, seeOption-1/FB and/or O		
For more information, see Chapter 4.4.3.For more information, see Chapter 4.4.3.WP APR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4.WP APR 5500/124 passive opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, seeOption-1/FB and/or O4 digital inputs 4 digital outputs4 relay outputs with potential-free change-over contacts For more information, seeOption-1/FB and/or O4 digital inputs 4 digital outputs6 promore information, see change-over contacts For more information, seeOption-1/FB and/or O		
Chapter 4.4.3.PR 5500/10 (W1)Internal weighing electronics for connecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.WP APR 5500/124 max. of two internal weighing electronics systems can be connected.Option-1/FB and/or OPR 5500/124 passive opto-decoupled inputs chapter 4.4.4.Option-1/FB and/or OPR 5500/124 relay outputs with potential-free chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 4 digital inputs 4 digital outputs4 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O		
Weighing electronicsconnecting load cells or weighing platforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.PR 5500/124 passive opto-decoupled inputs chapter 4.4.4.Option-1/FB and/or O4 digital inputs4 relay outputs with potential-free chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 6500/134 active opto-decoupled inputs chapter 4.4.5.Option-1/FB and/or OPR 6100/134 active opto-decoupled inputs chape-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OPR 6100/134 active opto-decoupled inputs change-over contacts For more information, see chapter 4.4.5.Option-1/FB and/or OPR 6100/134 option-1/FB and/or OFor more information, see chapter 4.4.5.Option-1/FB and/or OPR 6100/134 option-1/FB and/or OFor more information, see chapter 4.4.5.Option-1/FB and/or OPR 6100/134 option-1/FB and/or OFor more information, seeOption-1/FB and/or OA digital outputs6 option-0For more information, seeFor more information, see		
Preighning electionicsplatforms in non-hazardous areas. A max. of two internal weighing electronics systems can be connected.PreventionFor more information, see Chapter 4.4.4.Option-1/FB and/or OPR 5500/124 passive opto-decoupled inputs change-over contactsOption-1/FB and/or O4 digital inputs4 relay outputs with potential-free Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs Chapter 4.4.5.Option-1/FB and/or O4 digital inputs4 relay outputs with potential-free change-over contactsOption-1/FB and/or OFor more information, see Chapter 4.4.5.For more information, seeFor more information, seePR 5500/134 relay outputs with potential-free change-over contactsFor more information, see		
A max. of two internal weighing electronics systems can be connected. For more information, see Chapter 4.4.4. PR 5500/12 4 passive opto-decoupled inputs Option-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital outputs change-over contacts For more information, see Chapter 4.4.5. PR 5500/13 4 active opto-decoupled inputs Option-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital inputs 4 relay outputs with potential-free 4 digital inputs 4 relay outputs with potential-free 4 digital outputs 5 For more information, see Chapter 4.4.5. PR 5500/13 4 active opto-decoupled inputs 0ption-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital outputs 5 For more information, see		
electronics systems can be connected. For more information, see Chapter 4.4.4. PR 5500/12 4 passive opto-decoupled inputs Option-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital outputs Change-over contacts For more information, see Chapter 4.4.5. PR 5500/13 4 active opto-decoupled inputs Option-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital inputs 4 relay outputs with potential-free 4 digital outputs Change-over contacts For more information, see Chapter 4.4.5.		
connected.For more information, see Chapter 4.4.4.PR 5500/124 passive opto-decoupled inputs 4 relay outputs with potential-free change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O Option-1/FB and/or O		
Chapter 4.4.4.PR 5500/124 passive opto-decoupled inputs 4 digital inputsOption-1/FB and/or O 4 relay outputs with potential-free change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or O Option-1/FB and/or OPR 5500/134 active opto-decoupled inputs 4 digital inputsOption-1/FB and/or O A digital inputs4 digital outputs4 active opto-decoupled inputs change-over contacts For more information, see Chapter 4.4.5.Option-1/FB and/or OFR 5500/134 active opto-decoupled inputs change-over contacts For more information, seeOption-1/FB and/or O		
PR 5500/124 passive opto-decoupled inputsOption-1/FB and/or O4 digital inputs4 relay outputs with potential-free change-over contactsOption-1/FB and/or O4 digital outputsFor more information, see Chapter 4.4.5.Option-1/FB and/or OPR 5500/134 active opto-decoupled inputsOption-1/FB and/or O4 digital inputs4 relay outputs with potential-free change-over contactsOption-1/FB and/or O4 digital inputs5 rom ore information, seeFor more information, see6 rom ore information, seeFor more information, seeOption-1/FB and/or O		
4 digital inputs 4 relay outputs with potential-free 4 digital outputs 4 relay outputs with potential-free 4 digital outputs For more information, see Chapter 4.4.5. For more information, see PR 5500/13 4 active opto-decoupled inputs Option-1/FB and/or O 4 digital inputs 4 relay outputs with potential-free 4 digital outputs Chapter contacts For more information, see For more information, see		
4 digital outputschange-over contactsFor more information, see Chapter 4.4.5.For more information, see Chapter 4.4.5.PR 5500/134 active opto-decoupled inputsOption-1/FB and/or O 4 digital inputs4 digital inputs4 relay outputs with potential-free change-over contacts For more information, see	Option-2	
For more information, see Chapter 4.4.5. PR 5500/13 4 active opto-decoupled inputs Option-1/FB and/or 0 4 digital inputs 4 relay outputs with potential-free 4 digital outputs change-over contacts For more information, see		
PR 5500/134 active opto-decoupled inputsOption-1/FB and/or O4 digital inputs4 relay outputs with potential-free change-over contactsFor more information, see		
4 digital inputs4 relay outputs with potential-free change-over contacts4 digital outputsFor more information, see		
4 digital outputs change-over contacts For more information, see	Option-2	
For more information, see		
Chapter 4.4.0.		
PR 5500/17 6 passive opto-decoupled inputs Option-1/FB and/or O	Ontion 2	
PR 5500/176 passive opto-decoupled inputsOption-1/FB and/or O6 digital inputs8 passive opto-decoupled outputs	ορτιστι-2	
8 digital outputs For more information, see		
Chapter 4.4.7.		
PR 5500/32 The interface can be configured via Option-1/FB and/or O	Option-2	
2 serial RS-232 interfaces the software.		
For more information, see Chapter 4.4.2.		

Product ID	Description	Position
PR 1721/61 ProfiBus-DP	ProfiBus-DP-V0 Slave with 9.6 kbit/s to 12 Mbps, Auto baud rate detection; For more information, see Chapter 4.4.8.	Option-1/FB (Carrier card installed in reversed position)
PR 1721/64 DeviceNet	DeviceNet Master-Slave with 125, 250 and 500 kbps For more information, see Chapter 4.4.9.	Option-1/FB (Carrier card installed in reversed position)
PR 1721/65 CC-Link	CC-Link Slave with 156, 625 kbps, 2.5, 5, 10 Mbps For more information, see Chapter 4.4.10.	Option-1/FB (Carrier card installed in reversed position)
PR 1721/66 ProfiNet I/O	ProfiNet I/O with 10 and 100 Mbps Autodetection (10/100, HalfDX/ FulIDX) For more information, see Chapter 4.4.11.	Option-1/FB (Carrier card installed in reversed position)
PR 1721/67 EtherNet/IP	EtherNet-IP with 10 and 100 Mbps Autodetection (10/100, HalfDX/ FulIDX) For more information, see Chapter 4.4.12.	Option-1/FB (Carrier card installed in reversed position)

3.5.2 Application Licenses

Examples of application licenses:

Туре	Function
PR 5500/92	PR 1792 OPC server (AccessIt 2.0 license incl.)
PR 5500/83	Batching

Examples of application packages:

Checkweighing

Automatic dosing and manual filling

For product details, see corresponding data sheets/manuals.

Applications purchased from Sartorius Intec may only be changed as per a source code agreement.

3.6 Instrument Versions

3.6.1 Combinatorics for the Options

Name	Accessory	Code no.	Description	Chapter
Housing:				
Control cabinet housing			Standard	3.3.1
Housing mounti	ng parts:			
Strain relief for	connecting cables	L14		3.3.2
Reinforcing frame		L15		3.3.2
Elektronik:				
Analog/digital converter	PR5500/10	W1	WPA: Weighing electronics board	4.4.4
Power supply:				
Power supply		LO	100-240 V Version; standard	2.4.3.1
		L8	24 V Version	2.4.3.2

Name	Accessory	Code no.	Description		Chapter	
Interface cards:						
2x RS-485 interface	PR 5500/04	B15	Option-1/FB:	2 serial interfaces	— 4.4.1	
		B25	Option-2:	2 serial interfaces		
Analog inputs and outputs	PR 5500/07	B16	Option-1/FB:	1 analog input and 1 analog output (0/4 to 20 mA)	- 4.4.3	
		B26	Option-2:	1 analog input and 1 analog output (0/4 to 20 mA)	- 4.4.3	
Digital inputs and outputs	PR 5500/12	B18	Option-1/FB:	4 passive opto-decoupled inputs and 4 relay outputs	4.4.5.1,	
		B28	Option-2:	4 passive opto-decoupled inputs and 4 relay outputs	4.4.5.2	
Digital inputs and outputs	PR 5500/13	B17	Option-1/FB:	4 active opto-decoupled inputs and 4 relay outputs	_ 4.4.6.1, 4.4.6.2	
		B27	Option-2:	4 active opto-decoupled inputs and 4 relay outputs		
Digital inputs and outputs	PR 5500/17	B19	Option-1/FB:	6 passive opto-decoupled inputs and 8 passive opto-decoupled outputs	_ 4.4.7.1, 4.4.7.2	
		B29	Option-2:	6 passive opto-decoupled inputs and 8 passive opto-decoupled outputs		
2x RS-232 interface	PR 5500/32	B14	Option-1/FB: 2 serial interfaces		4.4.0	
		B24	Option-2:	2 serial interfaces	- 4.4.2	
Fieldbus cards:						
ProfiBus-DP	PR 1721/61	C21	Option-1/FB	(carrier plate is mounted reversed)	4.4.8	
DeviceNet	PR 1721/64	C24	Option-1/FB (carrier plate is mounted reversed)		4.4.9	
CC-Link	PR 1721/65	C25	Option-1/FB	(carrier plate is mounted reversed)	4.4.10	
ProfiNet I/O	PR 1721/66	C26	Option-1/FB	(carrier plate is mounted reversed)	4.4.11	
EtherNet-IP	PR 1721/67	C27	0 1 1/50	(carrier plate is mounted reversed)	4.4.12	

Name	Accessory	Code no.	Description	Chapter
Applications/Alit	oi memory/OPC s	erver:		
Basic			Standard application	
Phase			Application (OPC license incl.)	
Batching	PR 5500/83	16	I6 Application	
IBC	PR 5500/86	11	Application	see corre- sponding manual
Tilt Correction	PR 5500/87	12	License (only ,Basic' application)	
Alibi Memory	PR 5500/91	E5	License	
OPC server	PR 5500/92	E6	Use of the PR 1792 OPC server (AccessIt 2.0 license incl.)	
Batch modes	PR 5500/93	E9	Special license for using in individual programming	

Device Model

The marking (e.g. PR 5500-W1-L0-C21-B15-B27-H0-E5) of the device model (basic device + options) is located on a label on the back of the instrument.

4 Device Installation

4.1 General Information

Before starting work, please read Chapter 2 and follow all instructions.

Further procedures:

- Check the consignment: make sure that all components are present.
- Safety check: inspect all components for damage.
- ▶ Make sure that the on-site installation is correct and complete including cables, e.g. power cable fuse protection, load cells, junction box, data cables, console/cabinet, etc.
- ▶ If necessary, install the plug-in cards (device must be disconnected from all voltage sources).
- ► Follow all device installation instructions related to application, safety, ventilation, sealing and environmental influences.
- Connect the cable from the junction box or platform/load cell.
- ▶ If applicable: connect other data cables, power cables, etc.
- ► Connect the power cable.
- ► Check the installation.

4.2 Mechanical Preparation

Have all required parts, technical documents and tools at hand for installation.

- Measurement cables should be kept away from power equipment.
- Signal cables and measurement cables should be installed separately from electric power lines.
- It is recommended to lay measurement cables in separate cable conduits.
- Data cables should be crossed at right angles.
- ▶ For the control panel cutout for the device made e.g. in the control cabinet door; see Chapter 3.3.3.
- Install device.
- Secure the cable at the place of installation; e.g., using cable ties.
- Remove the insulation from the cable ends and keep the strands short.
- Connect the screen to device grounding terminal or screen clamping rail; see Chapter 4.2.1.1
- Connect the ground or equipotential bonding conductor to the device grounding terminal; see Chapter 4.2.1.2.

4.2.1.1 Connecting the Screen to the Screen Clamping Rail

The screen must be connected to the screen clamping rail using delivered screen clamps as pictured below.




4.2.1.2 Connecting the Equipotential Bonding Conductor

The equipotential bonding conductor (1) must be connected as pictured below.



4.3 Hardware Construction

4.3.1 Main Board



The following elements are located on the main board:

Pos.	Name	Pos.	Name
1	Reset key	7	Slot for fieldbus and option cards, Option-1/FB
2	Ethernet port, internal	8	Weighing electronics board W1
3	USB connection	9	Stand-by battery (for data recovery)
4	Slot for option cards, Option-2	10	Clock battery (see Chapter 9.1)
5	Connection for RS-232 interface, internal	11	Color-graphic display
6	SD card slot	12	Power adaptor


Note LED list see Chapter 13.4.

4.3.2 Network Port

The device has an internal Ethernet port.

4.3.2.1 Ethernet Port

The Ethernet port contains a powerful TCP/IP interface connection with transfer rates of 10 or 100 Mbps. Function tests can be made via the LEDs (green and yellow) in the RJ-45 socket.



4.3.2.2 Notebook/PC Connection

Connect	tion details		×
V2	VNC server:	172.24.20.57:1	OK
<u> </u>		Use host:display	Cancel
		e.g. vessel 2 (Display defaults to 0 if not given)	Options

Remote operation of the device from a notebook/PC is possible (install VNC software version 3.3.7* on the notebook/PC).

For network address settings, see Chapter 5.6.1.

* Sartorius Intec guarantees the functionality only if this version is used.

4.3.3 USB Connection

The USB connection is located on the back of the device.

	Туре	USB 2.0, Type A
Concernance of the second seco	Max. current	i _{max} = 200 mA
USB	Possible Connection Devices	 USB stick External keyboard Barcode reader Printer (non-GDI) External splitter (hub)




Data integrity cannot be guaranteed in the case of a power failure when using a USB stick via a splitter (HUB).

4.3.3.1 USB Stick

All commercially-available USB sticks can be used.

4.3.3.2 External PC Keyboard

The device has an alphanumeric keypad and a USB connection for an external PC keyboard on the back of the device. Both operating functions are equivalent and either one can be used.




You can set the key assignment for the connected keyboard under [System Setup]-[Operating Parameters]-[USB keyboard layout]:

- [German QWERTZ]
- [French AZERTY]
- [Italian QWERTY]
- [Spanish QWERTY]
- [English QWERTY]
- [Russian QWERTY/йцукен]



Before connecting the keyboard, make sure: Current consumption i <200 mA. An electronic current limiting prevents overloads.




4.3.3.3 **Barcode scanner**

A barcode scanner can be connected to the USB interface on the back of the device as an alternative to an external keyboard.



Before connecting the barcode scanner, make sure: current consumption i <200 mA. An electronic current limiting prevents overloads.



Barcode scanner settings are made by scanning the corresponding code (see manual). We recommend setting 3 redundant read processes to ensure secure read values. To confirm each read process via the key field, the automatic CR function of the scanner must be switched off.


4.3.3.4 Printer

The following USB printers can be used:

- YDP14IS-OCEUV
- EPSON TM-U220 und EPSON LQ-300K
- Line printer
- Printer with ESC/P2 control
- Printer with PCL5 control

4.3.3.5 External HUB

All commercially-available HUBs can be used.



4.3.4 SD Card Slot

The internal SD card slot is located on the back of the device. It comes with an appropriate SD card. The SD card is only used for storage; it is not used for data transfers.

Note	Only Sartorius Intec-supplied SD cards may be used. There is no warranty for third-party
	cards.

The following data are saved to the SD card:

- The backup directory for the configuration and database
- A copy of the current version of the BIOS, firmware and application
- A copy of the delivery version of the BIOS, firmware and application
- Manuals


You also have the option of saving application data.

	The SD card is a fixed component of the device.
	- The SD card may only be removed together with the SIL chip during servicing (replacing a defective device, see Chapter 13.7).
A Caution	- The SD card may not be used for data transfers.
	- The SD card may not be used in Notebook/PC.
TI 65 II	

The SD card is protected by a battery in case of a power failure, i.e. the current process running (e.g. reading data) is carried out and completed.


4.3.5 RS-232 Interface (built-in)

The device is equipped with an integrated RS-232 interface. This interface is configurable, and can be used, for example, for data transmission to a remote display or printer.




Connection	Terminal, 5-pin	
Number of channels	1	
Туре	RS-232, full duplex	
Transmission rate	300 to 115k2 Bit/sec	
Parity	None, odd, even	
Data bits	7/8 bit	
Input signal level	Logic 1 (high) - 3 to - 15 V Logic 0 (low) + 3 to + 15 V	
Output signal level	Logic 1 (high) - 5 V to - 15 V Logic 0 (low) + 5 V to + 15 V	

Number of signals	Input: Rx, CTS Output: Tx, RTS
Potential isolation	none
Cable gauge	max. 1.5 mm ²
Cable length	max. 15 m
Cable type	Twisted pair, screened (e.g. LifYCY 3x2x0.20), 1 pair of wires for ground (GND).



4.3.5.1 Connecting a PR 5110 Remote Display via RS-232

The remote display can be connected via the built-in RS-232 interface.



PR 5500 Configuration


[System setup] – [Connected devices] – [Remote display] – [Interface] – [Built-in RS-232]

PR 5110 Configuration

- عنه) P ID LI nE r5232 (مار) - P I2 - LofiEn - off
- 😇 oP I3 SEndNodE SEnd
- 👾 op 14 BEI GHE Follob
- (1) OP IS UPREY SELECE

4.3.5.2 Connecting a YDP14IS Ticket Printer via RS-232

The YDP14IS-OCEUV ticket printer can be connected via the built-in RS-232 interface.



PR 5500 Configuration

[System setup]-[Connected devices]-[Printer]-[Interface]-[Built-in RS-232]:

- [Protocol] to 'RTS/CTS'
- [Baud Rate] to '9600'
- [Data Bits] to '8'
- [Parity] to 'none'
- [Stop Bits] to '1'
- [Printer Type] to [Unchanged]

4.3.5.3 Connecting Additional Printers

The following serial printers can also be used:


- Epson TM-U295
- Printer with ESC/P2 protocol

Printer Configuration

The printer must be set to Line Mode (the factory setting is Page Mode). Press the FEED button to change modes; please refer to the operating instructions delivered with the printer.


4.3.5.4 Connecting an IS Platform via RS-232

A platform using an xBPI or SBI protocol can be connected via the built-in RS-232 interface.




Configuration

[System setup] – [Weighing points] – [Weighing point X]: [xBPI scale] [Interface]: [Built-in RS-232]



4.3.5.5 Connecting a Mettler-Scale via RS-232

A Mettler-Scale using MT-SICS protocol can be connected via the built-in RS-232 interface. Example: Type XS6002SDR




Configuration PR 5500

[System setup] – [Weighing points] – [Weighing point X]: [Mettler-Scale] [Interface]: [Built-in RS-232]

Parameter settings Mettler-Scale

see Chapter 5.17.2.



4.4 Accessories

4.4.1 PR 5500/04 2x RS-485 Interface

The plug-in card contains two channels. One channel can be used for connecting an IS platform without an external power supply.

Note	Either the internal Weighingpoint or an IS platform without external power supply can be
	used.


The RS-485 interface can be selected and configured in the Setup menu.

Using the RS-485 interface is compulsory with a multi-point connection (Tristate status).

The RS-485 interface can also be used as a point-to-point connection.


The card is inserted in the Option 1/FB and/or Option 2 slot.

A max. of 2 PR 5500/04 cards can be installed!



Internal Connection	Contact strip	
Number of channels	2	
Туре	RS-485, full duplex (4-wire) RS-485, half duplex (2-wire)	
For external power supply	U= 24 V, 3 W (briefly up to 6 W)	
Transmission rate	300 to 115 K2 Bit/sec	
Signals	TxA, RxA, TxB, RxB	
Potential isolation	Yes	
Cable gauge	max. 1.5 mm ²	
Cable length	max. 1000 m	
Cable type	Twisted pair, screened (e.g. LifYCY 3x2x0.20), 1 pair of wires for ground (GND).	
External connection	2x terminal, 7-pin	
Dimensions (LxWxH)	50x45x18 mm	
Weight	Approx. 35 g	

PR 5500/04 2x RS-485 Interface




Coding of Option-1/Option-2

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note	The terminal coding is described in Chapter 13.5.
------	---

Block diagram 2x RS-485




Function	Settings for RS-485	
Rx bus termination	OFF: not connected	ON: (A-RxA 120 Ω A-RxB)
Tx pull-up resistor	OFF: not connected	0N: (A-TxB 1K6 Ω +V)
Tx pull-down resistor	OFF: not connected	0N: (A-TxA 1K6 Ω -V)
Tx bus termination	OFF: not connected	0N: (A-TxA 120 Ω A-TxB)
Rx bus termination	OFF: not connected	ON: (B-RxA 120 Ω B-RxB)
Tx pull-up resistor	OFF: not connected	0N: (B-TxB 1K6 Ω +V)
Tx pull-down resistor	OFF: not connected	0N: (B-TxA 1K6 Ω -V)
Tx bus termination	OFF: not connected	ON: (B-TxA 120 Ω B-TxB)
	Rx bus terminationTx pull-up resistorTx pull-down resistorTx bus terminationRx bus terminationTx pull-up resistorTx pull-up resistorTx pull-down resistor	Rx bus terminationOFF: not connectedTx pull-up resistorOFF: not connectedTx pull-down resistorOFF: not connectedTx bus terminationOFF: not connectedRx bus terminationOFF: not connectedTx pull-up resistorOFF: not connectedTx pull-up resistorOFF: not connectedTx pull-up resistorOFF: not connectedTx pull-down resistorOFF: not connected

Note See block diagram on page 44.

4.4.1.1 Connecting to a PC or RS-485/RS-232 Converter

Point-to-point connection for the EW Com protocol (4-wire)

Example



Switch settings

0N: S1 0FF: S2, S3, S4


Configuration

[System setup] – [Connected devices] – [PC via EW Com] – [Interface] – [Option-1 RS-485-A]

4.4.1.2 Connecting to a PLC or RS-485/RS-232 Converter

Point-to-point connection for the ModBus protocol (2-wire)

Example



Switch settings


0N: S2, S3, S4 0FF: S1

Configuration

[System setup] – [Connected devices] – [ModBus-RTU master] – [Interface] – [Option-1 RS-485-A]

4.4.1.3 Connecting several PR 5500 Devices to a PC or RS-485/RS-232 Converter Connection for the EW Com protocol.

Example




Configuration

[System setup] – [Connected devices] – [PC via EW Com] – [Interface] – [Option-1 RS-485-A]

4.4.1.4 Connecting a PR 5110 Remote Display via RS-485

Connection via the RS-485 interface, 4-wire transmission, point-to-point, full duplex (simultaneous sending and receiving possible) with the PR 5110 remote display.

Example



PR 5500 Switch settings

ON:	S1
OFF:	S2, S3, S4

PR 5500 Configuration

[System setup] – [Connected devices] – [Remote display] – [Interface] – [Option-1 RS-485-A]

PR 5110 Switch settings

ON:	S1, S2, S3
OFF:	S4, S5


PR 5110 Configuration

- Setup) oP 12 Łofien off
- 👻 oP 13 SEndNodE SEnd
- 👻 op 14 UEI GHE FolloU
- 👻 oP IS UPREY SELECE

4.4.1.5 Connecting multiple PR 5110 Remote Displays via RS-485

Connection of several remote displays via the RS-485 interface, 4-wire, full-duplex (simultaneous sending and receiving possible).

Example



PR 5500 Configuration

[System setup] – [Connected devices] – [Remote display] – [Interface] – [Option-1 RS-485-A]

PR 5110 Configuration


D - 0P 10 - L1 nE - r5485
 - 0P 12 - L0FEn - 0FF
 - 0P 13 - 5EndflodE - 5End
 - 0P 14 - 4E1 GHL - Follo4
 - 0P 15 - 4PFE4 - 5ELECE

4.4.1.6 Connecting the IS Platform via RS-485 (2-wire)

A platform using an xBPI or SBI protocol can be connected via the RS-485 interface.

Note Only one platform can be supplied with power from the PR 5500 and the weighing electronics board PR 5500/10 must not be connected.

Example




Switch settings


0N: S2, S3, S4 0FF: S1

Configuration

[System Setup] – [Weighing points] – [Weighing point A]: [xBPI scale]

[Interface]: [Option-x RS-485-A]





4.4.1.7 Connecting 4 Load Cells PR 6204 ,Pendeo[®] Process'/PR 6224 ,Pendeo[®] Truck' via RS-485 Example

Note

For more information, see the load cell and junction box manuals.


4.4.2 PR 5500/32 2x RS-232 Interface

The plug-in card contains two channels. One channel can be used for connecting **one** IS platform without an external power supply. The jumper (1) must then be plugged onto A-24 V or B-24V. When an IS platform is connected without an external power supply, no analog weighing electronics board or no load cells may be installed in the device.

The RS-232 interface can be selected and configured in the Setup menu.


The card is inserted in the Option 1 and/or Option 2 slot.

A max. of 2 PR 5500/32 cards can be installed!



Intern. connection	Contact strip		
Extern. connection	2x terminal, 7-pin		
Number of channels	2		
Туре	RS-232, full duplex		
Transmission rate	300115K2 Bit/sec		
Parity	None, odd, even		
Data bits	7/8 bit		
Input signal level	Logic 1 (high) - 3 15 V Logic 0 (low) + 3 + 15 V		
Output signal level	Logic 1 (high) - 5 V 15 V Logic 0 (low) + 5 V + 15 V		
Number of signals	Input: RxD, CTS Output TxD, RTS		
Number of signals Potential isolation	•		
	Output TxD, RTS		
Potential isolation	Output TxD, RTS none		
Potential isolation Cable gauge	Output TxD, RTS none max. 1.5 mm ²		
Potential isolation Cable gauge Cable length	Output TxD, RTS none max. 1.5 mm ² max. 15 m Twisted pair, screened (e.g. LifYCY 3x2x0.20), 1 pair of		
Potential isolation Cable gauge Cable length Cable type Power supply for	Output TxD, RTS none max. 1.5 mm ² max. 15 m Twisted pair, screened (e.g. LifYCY 3x2x0.20), 1 pair of wires for ground (GND).		
Potential isolation Cable gauge Cable length Cable type Power supply for IS platform Dimensions	Output TxD, RTS none max. 1.5 mm ² max. 15 m Twisted pair, screened (e.g. LifYCY 3x2x0.20), 1 pair of wires for ground (GND). switchable to channel A or B		

PR 5500/32 2x RS-232 Interface




Coding of Option-1/Option-2

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

```
Note The terminal coding is described in Chapter 13.5.
```

Block diagram 2x RS-232



4.4.2.1 Connecting peripheral devices via RS-232


- Connecting the PR 5110 Remote Display via RS-232 (see built-in RS-232, Chapter 4.3.5.1)
- Connecting a YDP14IS Ticket Printer via RS-232 (see built-in RS-232, Chapter 4.3.5.2)
- Connecting a Mettler-Scale via RS-232 (see built-in RS-232, Chapter 4.3.5.5)

4.4.2.2 Connecting the IS Platform via RS-232

Using these option cards, you can connect an IS platform using the xBPI or SBI protocol.

Note Only one platform can be supplied with power from the PR 5500 and no load cells may be connected to the weighing electronics board PR 5500/10.

Example



Jumper setting

Channel A A- +24 V

Configuration

[System Setup] – [Weighing points] – [Weighing point A]: [xBPI scale]

[Interface]: [Option-x RS-232-A]




4.4.3 PR 5500/07 Analog Inputs and Outputs


The plug-in card for the available analog channels has 1 analog output (active) and 1 analog input.

The card is inserted in the Option 1/FB and/or Option 2 slot.


A max. of 2 PR 5500/07 cards can be installed!



Output	1 active current output: 0/4 to 20 mA (max. 24 mA), 10 V output voltage via an external 500 Ω resistor				
Output function	Gross/Net/Display follows or application-dependent 0/4 to 20 mA, configurable Internal 16 Bits = 65536 counts, resolution of 20,000 @ 20 mA				
Output range					
Output resolution					
Linearity error output	@ 0 - 20 mA: 0.04 % @ 4 - 20 mA: 0.02 %				
Temperature error output	<100 ppm/K				
Zero point error output	0.05 %				
Max. error output	<0.1 %				
Load	max. 0 to 500 Ω				
Potential isolation	Yes				
Cable	<150 m screened				
Input	1 current or voltage input				
Input range	010 V or 020 mA				
Input resistance	100 k Ω for 10 V measuring input				
•	200 Ω for 20 mA measuring input				
Input resolution	internal 14 Bits binary = 20,000 counts, @ e.g. 0 to 20 mA/0 to 10 V				
Max. error input	0.2 %				
Linearity error input	<0.02 %				
Temperature error input	<75 ppm/K				
Reserve input	±15%, i.e1.5 V to +11.5 V				
Potenzialtrennung	Yes, joint inputs and outputs				
Cable	<150 m screened				
Intern. connection	Contact strip				
Extern. connection	2x terminal, 6-pin				
Dimens. (LxWxH)	50x45x18 mm Approx. 40 g				
Weight					



	l _{in} 020 mA AGND V _{in} 010 V AGND
Option-1/FB Image: Second s	
$\bigcirc \bigcirc $	



Coding of Option-1/Option-2

Device Installation

- Terminal block: Insert the coding pin into the slot of the position marked in gray.
- Terminal: Remove (pinch off) the corresponding coding ridge.

Note	The terminal coding is described in Chapter 13.5.
------	---

 \cap

I_{out} 0...20 mA

AGND


4.4.4 PR 5500/10 Weighing Electronics Board

4.4.4.1 Specifications

The weighing electronics board is inserted in the WP A slot.

The CAL switch A (1) are located on the board.

Adjustment data and parameters are saved to the EAROM (non-volatile memory) of the weighing electronics board.



Weight


approx. 60 g

General Information 4.4.4.2

There is one connection on the back of the housing for analog load cells or analog platforms (e.g. CAPP series) depending on the model. The supply voltage is protected against short circuit and overload.



Do not shorten the load cell cable. Connect the prepared cable end and roll up the remaining cable.



Terminal block Connection		nnection	Description		
+	М	+	Meas.	+	Signal/LC output
-	М	_	Meas.	_	Signal/LC output
+	V	+	Supply	+	Exitation
+	S	+	Sense	+	Sense
-	S	_	Sense	_	Sense
-	V	_	Supply	_	Exitation

▲ Caution

4.4.4.3 Connecting a Load Cell with a 4-Wire Cable

=

=

=

=

Black

Blue

Green

Gray

Color code:

bk

bu

gn

gy

The cable colors shown here are valid for Sartorius Intec load cells.

=

=

=

Red


White

Yellow

rd

wh

ye




Place the following links directly on the terminal block:

- between + Supply (+V) and + Sense (+S)
- between Supply (-V) and Sense (-S)

4.4.4.4 Connecting a Load Cell with a 6-Wire Cable

	Tł
	C
	b
A Caution	b
	0

The cable colors shown here an Color code:					id for Sartor	ius Intec load	cells.
bk	=	Black	rd	=	Red	-	
bu	=	Blue	wh	=	White	_	
gn	=	Green	ye	=	Yellow	_	
gy	=	Gray					



4.4.4.5 Connecting up to 8 Load Cells (650 Ω) using a 6-Wire Connecting Cable Connections are made via junction box PR 6130/.. using connecting cable PR 6135.



The cable colors shown above are valid for Sartorius Intec load cells and connecting cable PR 6135.

Color code:


bk	=	Black	rd	=	Red
 bu	=	Blue	wh	=	White
gn	=	Green	ye	=	Yellow
gy	=	Gray			

Recommendation

- Install cable in steel pipe connected to a ground potential.
- The distance between the measuring cables and the power cables should be at least 1 m.


Load cell supply circuit

- Load resistance of load cell circuit \ge 75 Ω , e.g. 8 load cells of 650 Ω each
- Supply voltage is 12 V DC, for further data, see Chapter 12.3.



4.4.4.6 Testing the Measuring Circuit

You can perform a simple test on connected load cells using a multimeter (The internal load cell power supply does not apply to load cells supplied externally.):



4.4.4.7 Connecting Load Cells to an External Supply

When the total resistance of the load cells is \leq 75 Ω (e.g. more than 4 load cells with 350 Ω), an external load cell supply is required. In this case, the internal supply is replaced by a potential-free external supply. The center of the external supply voltage (0 ext. supply) should be connected to the housing to ensure that the voltage reacts symmetrically to 0. The internal supply is not connected!

	The cable Color code		here are	valid fo	r the PR 6135	connecting cable.
	bk =	Black	rd =	= Red		
A Caution	bu =	Blue	wh =	= Wh		
	gn =	Green	ye =	= Yell	OW	
	gy =	Gray				
+ ext. supply + v1 out Power Supply + ext. Speisung			 + Sense - Sense - Supply screen/ 	Schirm Screen/ Schirm	0 0 0 0 0 0 0 0 0 or screen clamping rail/ oder Schirmklemmschiene	equipotential bonding conductor/ Potenzialausgleich

4.4.4.8 Connecting Weighing Platforms (CAP)


Up to 2 Combics analog platforms (CAP series) can be connected to the internal weighing electronics connections depending on the model.



The cable colors shown above are valid for a CAPP4 500 x 400 and a CAPP1 320 x 420, for example.


The assignments of cable colors are listed in the platform operating instructions.

The following example shows a platform with a 6-wire connection:



Cable screens should be connected to the device earthing terminals or screen clamping rail.

The following example shows a platform with a 4-wire connection:



Cable screens should be connected to the device earthing terminals or screen clamping rail.

The following links should be set directly on the terminal block for platforms with a 4-wire connection:

- between + Supply (+V) and + Sense (+S)
- ❷ between Supply (-V) and Sense (-S)


4.4.5 PR 5500/12 Digital Inputs and Outputs

The plug-in card has 4 passive opto-decoupled inputs for process control.

The plug-in card also has 4 digital outputs with potential-free two-way contacts for process control.


The card is inserted in the Option 1/FB and/or Option 2 slot.

A max. of 2 PR 5500/12 plug-in cards can be installed!



Internal connection	Contact strip
Digital inputs/ outputs	4 (CH1, CH2, CH3, CH4)
Input voltage	Logic 0: 0 to 5 V DC or open Logic 1: 10 to 28 V DC Passive, external power supply required
Input current	<7 mA @ 24 V <3 mA @ 12 V Protected against incorrect polarity
Input frequency	max. 200 Hz (50% ratio)
Output	Two-way contact Max. switching voltage 30 V DC/24 V AC Max. switching current: 1 A
Switching frequency	max. 0.5 Hz
Potential isolation	Inputs: Yes, via optocoupler Outputs: Free relay two-way contact
External connection	2x terminal, 6-pin 2x terminal, 4-pin Wire gauge max. 1.5 mm²
Cables	Screened Connect the cable screen to the device.
Cable length	max. 50 m
Dimens. (LxWxH)	60x106x22 mm
Weight	70 g

4.4.5.1 Digital Inputs (PR 5500/12)



Coding of Option-1

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.





Illustration: terminal coding and internal circuit

Coding of Option-2


- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.

Connection example for PR 5500/12: Digital Inputs








- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.


Note The terminal coding is described in Chapter 13.5.
--



- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.


Note	The terminal coding is described in Chapter 13.5.
------	---

Connection example for PR 5500/12: Relay control (current output)



The relay switches when the output is active (true). To When t protect the output circuit, relays must be equipped goes from with free-wheel diodes.

When the output is active (true), the output voltage goes from 24 V/12 V to 0 V. The load resistance must be 2.2 k Ω /1 k Ω .



Connection example for PR 5500/12:

Voltage output


4.4.6 PR 5500/13 Digital Inputs and Outputs

The plug-in card has 4 active opto-decoupled inputs for process control.

The plug-in card also has 4 digital outputs with potential-free two-way contacts for process control.


The card is inserted in the Option 1/FB and/or Option 2 slot.

A max. of 2 PR 5500/13 plug-in cards can be installed!



Internal connection	Contact strip
Digital inputs/ outputs	4 (CH1, CH2, CH3, CH4)
Input	Can be switched via a potential- free contact
Input frequency	max. 200 Hz
Output	Two-way contact Max. switching voltage 31 V DC/24 V AC Max. switching current: 1 A
Switching frequency	max. 0.5 Hz
Potential isolation	Inputs: Jointly supplied via potential-free voltage Outputs: Free relay two-way contact
External connection	2x terminal, 6-pin 2x terminal, 4-pin Wire gauge max. 1.5 mm²
Cables	Screened Connect the cable screen to the device.
Cable length	max. 50 m
Dimensions (LxWxH)	60x106x22 mm
Weight	70 g

4.4.6.1 Digital Inputs (PR 5500/13)



- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.		Note	The terminal coding is described in Chapter 13.5.
--	--	------	---





Illustration: terminal coding and internal circuit


- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note	The terminal coding is described in Chapter 13.5.	
------	---	--



Connection example for PR 5500/13: Digital Inputs

4.4.6.2 Digital Outputs (PR 5500/13)



- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note	The terminal coding is described in Chapter 13.5.
------	---





Illustration: terminal coding and internal circuit

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.



Connection example for PR 5500/13: Relay control (current output)



screen clamping rail/ Erdungsklemme oder Schirmklemmschiene CH4C CH4B ₿ ₿ CH 3 CH 2 CH 1

The relay switches when the output is active (true). To protect the output circuit, relays must be equipped with free-wheel diodes.

When the output is active (true), the output voltage goes from 24 V/12 V to 0 V. The load resistance must be 2.2 k $\Omega/1$ k Ω .

grounding terminal or

* 2.2 kΩ/1 kΩ with 24 V/12 V 2,2 kΩ/1 kΩ mit 24 V/12 V

Connection example for PR 5500/13: Voltage output

+

24 V DC 0.5 A PR 1624

+


4.4.7 PR 5500/17 Digital Inputs and Outputs

The plug-in card has 6 passive opto-decoupled inputs and 8 digital outputs for process control.

GND (-) for all inputs and outputs together.


The card is inserted in the Option 1/FB and/or Option 2 slot.

A max. of 2 PR 5500/17 plug-in cards can be installed!



Internal connection	Contact strip
Digital inputs	
Number	6 (CH1, CH2, CH3, CH4, CH5, CH6)
Voltage	Low: 05 V
	High: 1028 V
	Passive: external supply required
Current	≤7 mA @ 24 V
	≤3 mA @ 12 V
Digital outputs	
Number	8 (CH1, CH2, CH3, CH4, CH5, CH6, CH7, CH8)
Supply voltage	max. 24 V +10% external to plug
Voltage drop	I_Last * 55 Ω +1 V (Output, conducting)
Max. switching current	25 mA
Signals	GND (-) for all inputs and outputs together
Potential isolation	Yes, via optocoupler
External	2x terminal, 6-pin
connection	2x terminal, 4-pin
	Wire gauge max. 1.5 mm ²
Cables	Screened
	Connect the cable screen to the device.
Cable length	max. 50 m
Dimensions (LxBxH)	52x52x19 mm
Weight	50 g

4.4.7.1 Digital Inputs (PR 5500/17)



- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.	
--	--






Illustration: terminal coding and internal circuit

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note	The terminal coding is described in Chapter 13.5.	
------	---	--


Connection example for PR 5500/17: Digital Inputs






Connection example for PR 5500/17: Digital inputs without potential isolation

Connection example for PR 5500/17: Digital inputs with potential isolation



4.4.7.2 Digital Outputs (PR 5500/17)



Coding of Option-1

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.





Illustration: terminal coding and internal circuit

Coding of Option-2

- ▶ Terminal block: Insert the coding pin into the slot of the position marked in gray.
- ▶ Terminal: Remove (pinch off) the corresponding coding ridge.

Note The terminal coding is described in Chapter 13.5.



Connection example for PR 5500/17: Relay control (current output)

The relay switches when the output is active (true). To protect the output circuit, relays must be equipped with free-wheel diodes.

4.4.8 PR 1721/61 ProfiBus-DP

4.4.8.1 Specifications

Communication protocols and the syntax comply with the ProfiBus-DP standard according to IEC 61158/ EN 50170, with transfer rates up to 12 Mbps.

The card is inserted in the Option 1/FB slot, see Chapter 13.6.

Internal connection	Pin strip, 50-pin			
External connection	9-pin D-Sub socket (female) in module cover			
Transmission rate	9.6 kbps to 12 Mbps, baud rate auto-detection			
Connection mode	ProfiBus network, connections can be made/released without affecting othe stations			
Protocol	Profibus DP VO slave			
Configuration	GSD file 'SART_5500.gsd'			
Cables	Special ProfiBus color: violet, screened twisted pair cable			
Cable impedance	150 Ω			
Cable length	The max. distance of 200 m can be extended at 1.5 Mbps by means of an additional repeater.			
Bus termination	The bus termination in the last device is implemented via the integrated terminating resistor in the ProfiBus plug.			
Potential isolation	Optocoupler in lines A and B (RS-485)			
Dimensions (LxWxH)	55x50x22 mm			
Weight	Approx. 33 g			
Certificates	Profibus test center Comdec in Germany and PNO (Profibus User Organization). Industry-compatible CE, UL and cUL.			

Note	The GSD file is stored on the CD supplied with the device (Fieldbus directory of the respective device). The current file is also available for download via the Internet:
	http://www.sartorius-intec.com/en/products/software-tools/ More -> Fieldbus-files

4.4.8.2 LEDs


OP OP		51
	PROFIBUS DP	


Identification	Description	
OP	Operating mode LED	
ST	Status LED	

Operating mode (OP)

LED status	Description	Comments		
Off	Module is offline	No power		
Constant green	Module is online Data exchange is possible			
Flashing 1 Hz green	Module is online Module is ready for data exc			
Flashing 1 Hz red	Parameter error			
Flashing 2 Hz red	Module configuration error			
Module status (ST)				
LED status	Description	Comments		
Off	Module is not initialized	 No power Module is in the SETUP or NW. INIT status 		
Constant green	Module is initialized	Normal operation		
Constant red	Exception error	 Module is in the EXCEPTION status 		
		 The exception error monitorin system closes all open connections to the module. 		

4.4.8.3 Assignment of the 9-pin D-sub socket (female)





Connection assignment EN 50170	Signal	Color	Description
Housing	Screen		
1	n.c.		not connected
2	n.c.		not connected
3	B-line/D (P)	Green	Positive RxD/TxD according to RS-485 specification
4 if required	RTS		Request To Send (only when using a repeater)
5	GND Bus		Insulated GND to RS-485 side
6	VP Bus		Insulated +5 V to RS-485 side
7	n.c.		not connected
8	A-line/D (N)	Red	Negative RxD/TxD according to RS-485 specification
9	n.c.		not connected

You can only use plug connections with integrated terminating resistors.

The terminating resistor must be turned on in the last slave.

4.4.9 PR 1721/64 DeviceNet

4.4.9.1 Specifications

The fieldbus card contains all functionalities to make a complete DeviceNet slave with a CAN controller and transmission speeds up to 500 kbps.

The card is inserted in the Option-1/FB slot, see Chapter 13.6.

1 A 1 A			
Internal connection	Pin strip, 50-pin		
External connection	5-pin terminal block (plug-in) in the module cover		
Transmission rate	125, 250 and 500 kbps		
Protocol	DeviceNet Master Slave		
	Polling procedure (polled IO)		
	CRC error recognition according to IEC 62026 (EN 50325)		
	Max. 64 station nodes		
	Data width max. 512 byte input & output		
Configuration	EDS file 'sag_5500.eds'		
	MAC ID (162)		
Cables	DeviceNet, color: petrol green		
	2x 2 screened twisted pair		
Cable impedance	150 Ω		
Bus termination	120 Ω at the cable ends		
Bus load 33 mA			
Potential isolation	Optocoupler and DC/DC converter		
Dimensions (LxWxH)	55x50x22 mm		
Weight	Approx. 33 g		
Certificates/Conformi	ty Compatible with DeviceNet specification Vol. 1: 2.0, Vol 2: 2.0		
	ODVA Certificate according to conformity test software version A-12		
	Industry-compatible CE, UL & cUL.		

http://www.sartorius-intec.com/en/products/software-tools/

EN-94

More -> Fieldbus-files

4.4.9.2 LEDs

NS		
	DeviceNet	

Identification	Description	
NS	Network status LED	
MS	Module status LED	


Network status (NS)

LED status	Description	Comments	
Off	Module is offline	No power	
Constant green	Module is online	There are one or more connections	
Flashing 1 Hz green	Module is online	No connections	
Constant red	Critical connection error		
Flashing 1 Hz red	Connection time exceeded	for one or more connections	
Flashing red/green	Self-test running		
Module status (MS)			
LED status	Description	Comments	
Off	Module is not initialized	 No power Module is in the SETUP or NW_INIT status 	
Constant green	Module is initialized	Normal operation	
Flashing 1 Hz green	Missing or incomplete configuration	The device must be set up again.	
Constant red	Exception error	 Module is in the EXCEPTION status The exception error monitoring system closes all open connections to the module. 	
Flashing 1 Hz red	Error that can be corrected		
Flashing red/green	Self-test running		

I
1

	Signal	Color	Description
Cable sheath			Special DeviceNet cable (certified)
1	V –	Black	Negative power supply
2	CAN_L	Blue	CAN_L bus signal
3	S		Cable screen
4	CAN_H	White	CAN_H bus signal
5	V +	Red	Positive power supply

4.4.9.4 Connection Diagram for a Master with three Slaves



PR 5500/.. receives 33 mA from the DeviceNet bus supply.

4.4.10 PR 1721/65 CC-Link

4.4.10.1 Specifications

The fieldbus card contains all functions to provide a complete CC link slave with transfer rates up to 10 Mbps. The card is inserted in the Option-1/FB slot, see Chapter 13.6.

Internal connection	Pin strip, 50-pin
External connection	5-pin terminal block (plug-in) in the module cover
Transmission rate	156; 625 kbps; 2.5; 5; 10 Mbps
Protocol	CRC error detection, 128 I/O bits and 16 (32 bits) words, max. 64 stations
Configuration	CSP file 'PR1721_1.csp'
Cables	2x 2 screened twisted pair
Cable length	100 m @ 10 Mbps, 1200 m @ 156 kbps
Bus termination	110 Ω at the cable ends
Bus load	100 mA
Potential isolation	Optocoupler and DC/DC converter
Dimensions (LxWxH)	55x50x22 mm
Weight	Approx. 33 g
Certificates/Conformity	CLPA Report BTP 03047,
	CC-Link Version 1.10.

Note	The CSP file is stored on the CD supplied with the device (Fieldbus directory of the respective device). The current file is also available for download via the Internet:
	http://www.sartorius-intec.com/en/products/software-tools/ More -> Fieldbus-files

4.4.10.2 LEDs

RUN		O ERR
	CC-Link	

Pos.	Description
RUN	Process LED
ERR	Error LED

Operation (1)

LED status	Description	Comments
Off	Module is offline	No network connectionNo power
Constant green	Module is online	There is a network connectionNormal operation
Constant red	Exception error	- Module is in the EXCEPTION status
		 The exception error monitoring system closes all open connections to the module.

Error (2)

LED status	Description	Comments
Off	No error	No power
Constant red	Exception error	 Module is in the EXCEPTION status The exception error monitoring system closes all open connections to the module.
Flickering red	CRC error	
Flashing 1 Hz red	Address errorBaud rate error	After any changes: - No allowed addresses - No allowed baud rates

4.4.10.3 5-Pole Terminal Block Allocation

	Signal	Description
1	DA	Communication RS-485 RxD/TxD (+)
2	DB	Communication RS-485 RxD/TxD (-)
3	GND	Digital ground
4	S	Cable screen
5	PE	Housing ground

4.4.11 PR 1721/66 ProfiNet I/O

4.4.11.1 Specifications

The fieldbus card is equipped with a standard RJ-45 socket for the network connection and contains a powerful UDP/IP connecting circuitry with transfer rates of 10 and 100 Mbps.

The card is inserted in the Option-1FB slot, see Chapter 13.6.

Internal connection Pin strip, 50-pin	
External connection RJ-45 connection socket in the module cover	
Transmission rate	10 Mbps and 100 Mbps
	Autodetection (10/100, HalfDX/FullDX)
Connection mode	Network
Protocol	ProfiNet I/O
Configuration	HTML file
	'GSDML-xxx-Sartorius-PR5500-xxx.html'
Cables	Twisted pairs, screened e.g. patch cable CAT5 Autolink (straight or crossover)
Cable impedance150 Ω	
Cable length to HUBMax. 115 m	
Potential isolation	Yes
Dimensions (LxW)	I) 55x50x22 mm
Weight	Approx. 33 g
Certificate	ProfiBus Nutzerorganisation e.V. for HMS Industrial Networks AB
	Certificate No: Z10006
	Report: PN005-1, 12.02.2007.

11000	
	Chapter 5.19.6).
	The HTML file is stored on the CD supplied with the device (Fieldbus directory of the respective device). The current file is also available for download via the Internet:
	http://www.sartorius-intec.com/en/products/software-tools/ More -> Fieldbus-files

4.4.11.2 LEDs

NS O		O MS Link
	ProfiNet I/O	

Identification	Description	
NS	Network status LED	
MS	Module status LED	
Link	Link/Activity LED	

Network status (NS)

LED status	Description	Comments
Off	Module is offline	No powerNo connection to the I/O controller
Constant green	Module is online (RUN)	 There is a connection to the I/O controller
		 I/O Controller is operational (RUN status)
Flashing 1 Hz green	Module is online (STOP)	 There is a connection to the I/O controller
		 I/O Controller is not operational (STOP status)

Module status (MS)

Status	Description	Comments
Off	Module is not initialized	 No power Module is in the SETUP or NW_INIT status
Constant green	Module is initialized	Normal operation
Flashing 1 Hz green	Error after test	Error occurred after test.
Flashing 2 Hz green		This is used for node identification in the network.
Constant red	Exception error	 Module is in the EXCEPTION status The exception error monitoring system closes all open connections to the module.
Flashing 1 Hz red	Configuration error	Expected identification deviates from the available identification.
Flashing 2 Hz red	IP address error	IP address was not defined.
Flashing 3 Hz red	Device name error	Device name was not defined.
Flashing 4 Hz red	Internal error	Module has caused an unrecoverable internal error.

Link/Activity


LED status	Description	Comments
Off	Module has no connection	No connectionNo communication
Constant green	Module has a connection	There is an Ethernet connectionNo communication
Flickering green	Activity	There is an Ethernet connectionCommunication is available

4.4.11.3 Fieldbus parameters

Slave/Master device names

Caution!	A unique device name must be assigned from the master. This name is given highest priority when establishing the communication.
	When replacing devices/servicing, please note: Along with the IP address, the device name must correspond to the one of the replacement device. Explicit assignment out of the master is required.

Example



4.4.12 PR 1721/57 EtherNet-IP

4.4.12.1 Specifications

The fieldbus card is equipped with a standard RJ-45 socket for the Ethernet connection and contains a powerful TCP/IP and EtherNet IP connecting circuitry with transfer rates of 10 and 100 Mbps.

The card is inserted in the Option-1/FB slot, see Chapter 13.6.

Internal conne	ection Pin strip, 50-pin
External conn	RJ-45 connection socket in the module cover
Transmission r	rate 10 Mbps and 100 Mbps Autodetection (10/100, HalfDX/FullDX)
Connection m	ode Network
Protocol	EtherNet IP
Configuration	EDS file 'sag_5500 ethernetip.eds'
Cables	Twisted pairs, screened e.g. patch cable CAT5 Autolink (straight or crossover)
Cable impeda	nce 150Ω
Cable length t	to HUB Max. 115 m
Potential isola	ation Yes
Dimensions (L	xWxH) 55x50x22 mm
Weight	Approx. 33 g
Certificates	EtherNet IP Specification ODVA File No. 10286
	Test Date: 06.09.2005
	Vendor ID 90
	See also: www.odva.org
	Tested according to: CE, UL & cUL
Note	The IP address and the Subnet mask are set via the Fieldbus parameters (see also Chapter 5.19.6).
	The EDS file is stored on the CD supplied with the device (Fieldbus directory of the respective device). The current file is also available for download via the Internet:

http://www.sartorius-intec.com/en/products/software-tools/ More -> Fieldbus-files

4.4.12.2 LEDs

NS O		MS Link
	EtherNet/IP	

Identification	Description
NS	Network status LED
MS	Module status LED
Link	Link/Activity LED

Network status (NS)

LED status	Description	Comments
Off	Module is offline	No powerNo IP address
Constant green	Module is online	One or more connections exist (chip class 1 or 3)
Flashing 1 Hz green	Module is online	No connections
Constant red	Critical connection error	Duplicate IP address
Flashing 1 Hz red	Connection time exceeded	For one or more connections (chip class 1 or 3)

Module status (MS)

Status	Description	Comments
Off	Module is not initialized.	 No power Module is in the SETUP or NW_INIT status.
Constant green	Module is initialized.	Normal operation
Flashing 1 Hz green	Error after test	Error occurred after test.
Flashing 2 Hz green		This is used for node identification in the network.
Constant red	Exception error	 Module is in the EXCEPTION status. The exception error monitoring system closes all open connections to the module.
Flashing 1 Hz red	Configuration error	Expected identification deviates from the available identification.
Flashing 2 Hz red	IP address error	IP address was not defined.
Flashing 3 Hz red	Device name error	Device name was not defined.
Flashing 4 Hz red	Internal error	Module has caused an unrecoverable internal error.

Link/Activity

LED status	Description	Comments
Off	Module has no connection.	No connectionNo communication
Constant green	Module has a connection.	There is an Ethernet connection.No communication
Flickering green	Activity	There is an Ethernet connection.Communication is available.

5 Commissioning

5.1 Power Failure/Data Protection/Warm Start/Cold Start

5.1.1 General Information

The calibration data and parameters of the internal weighing electronics system are saved to the EAROM on the weighing electronics board. Additional write protection is also available for calibration data and parameters as well as application programs (see Chapter 5.1.5.1).

The event logger is saved to the SPI flash memory.

The flash PROM include

- BIOS
- firmware
- application program
- alibi memory
- XML configuration files (for user management, setup, calibration, and application data)

Backups are saved to the SD card (secure digital card) (see Chapter 4.3.4).

5.1.2 Power Failure

The entire content of the SD-RAM is stored to a Nand flash memory and remains there permanently when the power is interrupted or the device is disconnected from the power. When power is restored, all data are reloaded from the Nand flash memory to the SD-RAM and the device is restored to the operating status before the interruption. Dosing programs are stopped/started depending on user settings.

The SD card and the USB stick are both buffered by a battery.

If a HUB (splitter) is inserted into the USB slot and turned off, the USB stick is not buffered by a battery.

5.1.3 Warm Start

After a warm start all data remain unchanged, behaviour as after power failure, see Chapter 5.1.2.

5.1.4 Cold Start

5.1.4.1 General Information

There are several options executing a cold start:

- After power-on (see Chapter 5.1.4.2)
- With STOP+EXIT keys (see Chapter 5.1.4.3)
- With reset key (see Chapter 5.1.4.4)

5.1.4.2 Menu-driven Power Off

The menu-driven power off (see Chapter 6.1.9) does **not** save the entire content of the SD-RAM into a Nand flash memory. However during the cold start the last saved database is automatically loaded into the device.

5.1.4.3 With STOP+EXIT Keys

During the cold start with STOP+EXIT keys (see Chapter 5.19.3) the database will be emptied and current process steps are deleted. The device automatically searches for an existing database on the SD card and ask to load it.

If ,disabled' is selected under [System setup]-[Operating parameters]-[Coldstart with STOP+EXIT], the STOP key must be pressed while the power cord is being connected to
execute a cold start.

5.1.4.4 With Reset Key

The device re-started (cold start) by a short-time (<1 sec.) actuating of the reset key (see Chapter 3.3.1).

- LED will flash once.
- No settings will be changed.
- The database will be emptied.
- Current process steps are deleted.
- Application must be restarted.
- The database must be restored.
- No network settings will be changed.

5.1.5 Overwrite Protection

5.1.5.1 Via a CAL Switch

The device can have up to t CAL switches. CAL switches 1 and 2 are located on the main board.

CAL switch A is located on the weighing electronics board (see Chapter 4.4.4). These switches are accessible on the back device.

The exact function of individual switches is listed in the table below.

Note In general, we recommend activating the overwrite protection features via the software after calibration to prevent accidental overwrite/data loss (see Chapter 5.1.5.2).


	Write protection active	No write protection
CAL switch A, 1 and 2		□■I + opened geöffn.
back device	CAL-A CAL-1 CAL-2	CAL-A CAL-1 CAL-2

CAL switch	Meaning of 'Write Protection Active'
А	Prevents the calibration data and parameters of weighing electronics A from being changed
1	The following changes are prevented: - Calibration data and parameters of changed weighing points - Alibi settings
2	 The following is prevented: Loading/flashing of firmware, BIOS, and application programs to the device, see also Chapter Changing of license settings
	This CAL switch is sealed in legal for trade mode.
Note	Changing means:

Note	Changing means:
	Input changes in the input fields as well as changes via the 'Restore' and 'Import' functions.

5.1.5.2 Via Software

Note	A unique check number is created every time a calibration or changed parameters are saved.
	This can be viewed under [System information]-[Show calibration check numbers] (see
	Chapter 5.20.7) and noted; if necessary.



The weighing point has a 'Settings locked' parameter in the [Parameters] menu item.

If this parameter is set for the weighing point,

- the calibration data and parameters of the weighing point are only viewed as if the corresponding CAL switch were closed.
- Only the 'Settings locked' parameter can be changed.
- Restoring/importing a weighing point is locked.

Note

If 'Settings locked' and 'W&M' were selected for at least one weighing point, this has the same effect as a closed CAL 1 and CAL 2 switch, see Chapter 5.1.5.1.

5.2 Switching on the Device

The device can be set up as follows:

- Via keys on the front of the device
- Via an external PC keyboard
- Via a notebook/PC using the VNC software (included on the CD)
- Via a notebook/PC using an internet browser

When the device is powered up, the following appears:

Checking Booting Restore	The device runs up.
No signal	Error message: no load cells are connected (see also Chapter 11.1).
No values from scale	Error message: no communication with the xBPI scale (see also Chapter 11.2). Error message: no weight values are read from ADC (analog-digital converter) (see also Chapter 11.1).
Scale not ready	Error message: no load cells or no scale is connected (see also Chapter 11.3).

₩P-A	Max	30009		0.01g	The weight disp User login, see (
		U.	UU.	9	Note	Default: user management is not activated.
.	22.1	0.2014 09:18	8:20			
Login	· · ·					

Application menu Weighing Check weighing Device employed as t Configuration System menu System setup System information System maintenance	Operating erminal	The operating menu is displayed. The application and system menus are selected here. Select and confirm [System setup] using the cursor.
Connected devices Date & Time Operating parameters Network parameters Network share connec Fieldbus parameters Weighing point Display settings License settings User management Alibi memory		The setup menu is displayed. The date and time are set first, see Chapter 5.19.2.

5.3 Switching off the Device

See Chapter 6.1.9.

5.4 Warm-up Time

The device requires a warm-up time of 30 minutes before calibration.

5.5 Configuring and Calibrating via the Front Keys/PC Keyboard

The following options are possible:

- Via keys on the front of the device
- Via an external PC keyboard (USB connection)

Go to Chapter 5.7.

5.6 Configuring and Calibrating via a Notebook/PC

The following options are possible:

- Via VNC Viewer (on the enclosed CD-ROM), see Chapter 5.6.4.
- Via web browser (Microsoft Internet Explorer or Mozilla Firefox), see Chapter 5.6.5. Java (Sun) must be installed and activated for this option.

5.6.1 Connecting the Device to the Network and Determining the IP Address

The DHCP server is active in the network

An IP address is assigned to the device automatically.

The DHCP server is not active in the network

If the device is connected to a notebook/PC via a point-to-point connection, an IP address is assigned via the 'AutoIP' function. This can take up to two minutes.

IndicatorBrowser

The IP address can be determined using 'IndicatorBrowser' (included on the CD-ROM) and via the 'host name' of the device (see also Chapter 5.6.3). The host name is composed of the device name and the last three bytes of the MAC ID. A label with the complete MAC ID is located on the outside of the device.


MAC:	00:90:6C:6B:6A:5E		sartorius
IP: .		•)

Default host name: PR5500-6B6A5E

UPnP view with Microsoft Windows XP


The IP address can also be determined using the 'Microsoft Internet Explorer' under 'Network' if the 'UPnP' view is turned on (default: off).

Procedure:



- ▶ Click 'Start' -> 'Control Panel' -> 'System'.
- ▷ The 'System Settings' window opens.

	Note	'Service Pack 2' or higher must be installed.
• (Click 'OK'.	



Click 'Yes'.

Elle Edit View Fguorites Loois	Help:		2
Que - 0 1 22	nch 👔 Tokiens 🖽.		
di - 9 My Network Places			- E 60 1000
Network Tasks	PR-5200 "Skote4E"	PRS230 785230 688744"	1000
Add a remotive www.reduced correction address in and	INSCO PRISON EXCERT	145230 145230 40007"	
diffurnithings	PRS230 '985210-4891-156"	105230 "Want 1 kng name 123856"	

- \triangleright The icons for the devices are displayed.
- Click on the relevant icon using the right mouse button and select the 'Properties' menu item.
- ▶ Read the IP address.

UPnP View with Microsoft Windows 7

If the network was **not** configured as a 'public network', the device icons are shown automatically under 'Network'.

5.6.2 Activating the 'DHCP' Network

Requirement

'Use DHCP' has been selected under [System setup]-[Network parameters].

This ensures that a valid address for device network identification can be assigned to the device; see Chapter 5.19.4.

Note	The last three bytes of the MAC ID are displayed in default host name. A label with the complete MAC ID is located on the outside of the device.
	A device with DHCP 'on' (default factory setting) and connected to an IT network (company network) with a DHCP server does not require any further action, but there will be a delay of 2–3 minutes. A network connection is then established automatically (device <-> workstation/PC).

Notebooks/PCs connected temporarily must have the following network adaptor properties (DHCP/DNS automatic):

eneral Advanced	General	
Connect using:	You can get IP settings assigned a supports this capability. Otherwise administrator for the appropriate	e, you need to ask your network
This connection uses the following items:) Obtain an IP address autom	atically
Client for Microsoft Networks	Use the following IP address	6
File and Printer Sharing for Microsoft Networks	IP address:	
☑ 월 QoS Packet Scheduler ☑ 3 Internet Protocol (TCP/IP)	Subnet mask:	
Install Uninstall Properties	Default gateway:	9-9-6
Description	Obtain DNS server address a	automatically
Transmission Control Protocol/Internet Protocol. The default	Use the following DNS serve	r addresses
wide area network protocol that provides communication across diverse interconnected networks.	Preferred DNS server:	
Show icon in notification area when connected	Alternate DNS server:	
$\overline{\mathbf{v}}$ Notify me when this connection has limited or no connectivity	Validate settings upon exit	Advanced

For setup, the first network contact is possible only by determining the IP address/subnet mask automatically under 'Obtain an IP address automatically' (default factory setting) or 'Use the following IP address'.

5.6.2.1 MAC ID

The MAC ID or (6-digit) hardware address, e.g., 00:90:6C:6B:6A:5E, is a unique number for network adaptor identification.

A label with the complete MAC ID is located on the outside of the device.

MAC:	00:90:6C:6B:6A:5E		sartorius	
IP:		•)	

The last three bytes ensure that the initialized host name (in this case: PR5500-6B6A5E) is always unique.

5.6.2.2 DHCP

Normally, DHCP servers are only used in IT-supported company networks and not on local (directly) connected notebooks/PCs.

Nevertheless, 'DHCP' must be activated on the PC. 'DHCP' devices detect each other after a cyclical automatic 'DHCP' server search is run with a timeout (approx. two to three minutes) because they use an 'auto-IP' address within a range of 169.254.0.1 to 169.254.255.254.

Note	When the IT/DHCP network cable is temporarily connected between the notebook/PC and a device, the DHCP server is lost and the notebook/PC returns to the auto-IP address within approx. two minutes.
	Reason: At every network cable connecting the DHCP server/client relationship is checked newly.

Example

If the search time is exceeded (because there is 'no server found'), the PR 5500 is assigned an IP address automatically (e.g., 169.254.0.123). The same applies to the notebook or PC (e.g., 169.254.0.54). These IP addresses are different on both sides:

- the same in terms of the first two octets of the IP address (e.g., network ID 169.254.)
- different in terms of the last two octets of the IP address (e.g., host ID 0.123.)

5.6.2.3 Host name (device name)

The host name must always be unique.

If names are user-defined (host name is editable)

- the same host name must not exist twice within the network ID.

For example: correct assignment would be host name device 1: PR5500 scale1; device 2: PR5500 scale2 The 'default' (PR5500-6B6A5E) is always correct, whereby the last three bytes of the MAC ID are unique.

- This is limited to 2–24 characters.

Permitted are

- letters A-Z, a-z
- numbers 0–9, but these must not constitute the first or last character
- hyphens ('-'), but these must not constitute the first or last character

5.6.3 Searching for Devices in the Network using 'IndicatorBrowser'

The address can be determined using the 'IndicatorBrowser' program (on the enclosed CD-ROM).

Install and start the 'IndicatorBrowser'. IndicatorBrowser Indicator Browser 01.00.00 203706 2014-02-10-08/01-51 The 'IndicatorBrowser' searches within the current Hostname PR5500 967EA9 PR5410-707C97 network ID, e.g., 169.254. and 172.24., on all available DevType PR5500 Status Valid until IP-Addr 14:19:03 14:19:03 14:19:03 14:19:03 14:19:03 O#onli... O#onli... 172.24.24.50 network adaptors in the notebook/PC (several possible/ X3 PR5900 172.24.21.26 PR5900-96762F O#onli.. Wanni-D61026 PR5410-705AA8 PR5230 O#onli. recommended, e.g., LAN global/LAN local). 14:19:03 14:19:03 14:19:03 14:19:03 14:19:03 14:19:03 172.24.24.45 172.24.21.22 172.24.22.43 O#onli. Vanni-TSG-47 Wanni-TSG-47 PB5900-36C518 X3 0#onli PB5220 **Result:** PR5800 PR5900 172.24.22.47 172.24.20.145 PR5500 List of all connected devices with status: Model name 5500 Model number search??? - online - byebye - lost??? 362184361 Serial number d3df08ff-f949-1000-2224-00906c967ea9 GUID I¥ Beep Search Ping . Open Click the button to open the default web browser, e.g., Microsoft Internet Explorer, directly using the marked IP address. Click the button to re-start the network Click the button to localize the associated device. Shortterm visual feedback from the device: search. You must wait 2-3 minutes. Display background flashes. Acoustic signal for each device that was detected as "online.

If the browser window remains empty after the minimum wait time, or if the expected device is not listed, the network ID of the local notebook/PC must be checked and changed, if necessary.

Note Only certain Sartorius Intec devices are supported by the 'IndicatorBrowser'.

5.6.4 Operation using the VNC Client Program

VNC (on the enclosed CD) stands for "Virtual Network Computing" and is a program for the remote operation of computers.

The program distinguishes between the VNC server and VNC client (viewer). The server program is part of the device software. The client program (viewer) must be run on the notebook/PC in order to operate the device.

NoteThe VNC version provided on CD must be used.More recent VNC versions (freeware) from the internet are not supported by the device.

Connect	tion details		\sim
V2	VNC server:	172.24.20.57:1	ОК
		Use host:display	Cancel
		e.g. vessel 2 (Display defaults to 0 if not given)	Options

 Maxxis 4
 ●
 Sattorius

 +0+
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0

 00
 0.000
 0
 0
 0

 00
 0.000
 0
 0
 0
 0

 000
 0.000
 0
 0
 0
 0

 000
 0.000
 0
 0
 0
 0

 000
 0.000
 0
 0
 0
 0
 0

 000
 0.000
 0
 0
 0
 0
 0
 0

 1.000
 0.000
 0
 0
 0
 0
 0
 0
 0

 0.000
 0


For direct operation using the VNC program, the IP address (extended by [1]) must be specified when you run the program, e.g., 172.24.20.57:1.

VNC access can be limited to specific notebooks/PCs in the network; see Chapter 5.19.4. The VNC user interface appears.

5.6.5 Operation via a Web Browser

Note	Instead of the VNC viewer, a web browser, e.g., Microsoft Internet Explorer, Mozilla Firefox, can be used directly.
	The disadvantage is that an additional Java installation is required.
	In addition to VNC, this includes:
	- Easy configuration printout.
	– Easy display of
	- database tables
	- Alibi memory content
	- manuals
	– event logs
	- log files
	– error logs
	- Easy download of language files.

▶ Enter and confirm the [IP address] for the internet browser.



Configuration

- [Remote Configuration (VNC)]
- [Remote Configuration (VNC) Pop-up Window]
- [Configuration Printout]

View

- [Weighing Points]
- [Weighing Points Pop-up Window]
- [Browse Database]
- [Browse alibi memory]
- [Manuals]

Service level

- [Browse eventlog]
- [Browse logfiles]
- [Show last fatal system error]
- [Screenshot]
- [Export database]
- [Export Alibi memory]
- [Export service report]
- [Backup and restore setup data]
- [Upload language files]

For device operation using the VNC program without additional installation of VNC client.

,Java' installation is necessary, see page 122. Can be used for printing the configuration data as a text file, see Chapter 13.1.

Displays the weighing points in a table, see Chapter 6.1.13.1.

,Java' installation is necessary, see page 122.

Browse the application-specific database, see Chapter 6.1.13.2.

Browse the alibi memory, see Chapter 6.1.13.3.

PDF files are saved to the SD card (SD cards supplied with device by Sartorius Intec only), see Chapter 6.1.13.4.

Browse event log, see Chapter 6.1.13.5. Browse, display, copy, print log files, see Chapter 6.1.13.6.

Browse, display, copy, print the error log, see Chapter 6.1.13.7.

Saves a screenshot, see Chapter 6.1.13.8.

Export the database as an XML file, see Chapter 6.1.13.9.

Export the alibi memory as an XML file, see Chapter 6.1.13.10.

Export the service report as an XML file, see Chapter 6.1.13.11.


Create backup of the setup data and restore setup data, see Chapter 6.1.13.12.

Uploads the language files to the device, see Chapter 6.1.13.13.

Note

Example: Microsoft Internet Explorer in Windows XP

With Internet Explorer, first check that the required Java (Sun) applet is installed and activated.



- Start Internet Explorer.
- ► Click [Tools] [Internet Options...]
- Click on the [Advanced] tab.
- Iava (Sun)]: Check whether entries are provided.
- ▶ If so, check ☑ [IRE 1.6.xxx ...] (not activated by default).
- If no entries are provided, download the 'Java (Sun) applet' as freeware from the internet and install it.

In earlier Windows installations, Java was provided as standard, but not activated.

Example: Microsoft Internet Explorer in Windows 7



With Internet Explorer, check if the required Java (Sun) applet is installed. If it is not installed, the link for a Java download is suggested automatically.

	······································				
	Note	e Pressing the reset key during a long time (>5 sec.) triggers a cold start.			
	- The settings will not be changed.				
	- The database will be emptied.				
	 Current process steps are deleted. 				
- Application must be restarted.		- Application must be restarted.			
		- The database must be restored.			

5.6.6 Resetting Network

Pressing the reset switch during a long time (>5 sec.) resets the network settings to default/factory settings.

That means:

- LED will be switched on a second time.
- ,DHCP' is activated.
- Web server is enabled.
- VNC access is enabled.
- ,Host name' is initialized e.g. PR5500-6B6A5E (device type-MAC-ID).

Example of MAC-ID: 00-90-6C-6B-6A-5E

This ensures that a valid address for identification of the instrument in the network can be assigned to the device, see Chapter 5.19.4.

Note	The last 3 bytes of the MAC ID are displayed. A label with the complete MAC ID is fitted to the outside of the device.
	A device set to DHCP \square (default/factory setting) and connected to an IT network (company network) with a DHCP server does not require further actions except for a 23-minute waiting time . Subsequently, a network connection is established automatically (device <-> workstation/PC).

5.7 Help Function

The help function can be accessed from any parameter window using the ? key. A window appears in which you can scroll up and down through the content using the cursor keys (1, \downarrow , \blacktriangle , \checkmark). The window can be closed using the ESC/EXIT key.

Note

The help text is given in English as a default if the corresponding language is unavailable.

5.8 Selecting the Operating Language

Factory settings: system language = operating language (display language)

The operating language can be changed as follows:

- In the System menu [System setup]-[Operating parameters]-[Operating language], select the desired language using the cursor keys, confirm the selection and press the [Save] soft key, see also Chapter 5.19.3.
- In the System menu [System setup]-[User management]-[Create/Copy/Change user]-[Operating language] select with the cursor keys, confirm the selection, and save via the [Save] soft key, see also Chapter 5.9.2.1.
- You can also assign the F1 or F2 function keys with the [Change language] function, see Chapter 5.19.3. The operating language can be changed from any menu.

When user management is active,

- only the language assigned to the logged-in user will be displayed after the operating language is changed in the system menu.
- the changed operating language is displayed after the user logs in.

5.9 User Management

5.9.1 General Information

By means of the user management, the access to various menu levels of the instrument can be limited, if the necessity arises. This includes e.g. system set-up, system maintenance, access via the website and the various levels of the application (application-specific).


Note The user management can be activated optionally. However, it is not required for normal operation.

During system installation and set-up, we recommend leaving the user management de-activated. This facilitates the access to the various menus and to the website.

Always activate the user management, if

- several persons work with the unit or have access to it.
- the target is to prevent unauthorized persons from making changes to the unit or from influencing the processes controlled by the unit.

5.9.2 Activating User Management




User management is not activated by default.

 Select and confirm the [System setup]-[User management] menu item.

- User management

 Image: Constraint of a constrai
- \triangleright A prompt window appears.
- Press the corresponding soft key.



The users 'admin' and 'default' are created automatically and cannot be deleted.

The administrator is always created with all rights authorized. These cannot be restricted.

The 'default' user has restricted rights.

If the 'admin' user (administrator) is logged in, this user can


- _ create new users
- copy users
- change user settings
- remove users
- deactivate user management.

The administrator can create new users with all rights.

5.9.2.1 **Creating new Users**

User name

Password



Navigate to [System setup]-[User management] and confirm the [Create user] menu item.

BABC.. Enter user name and password *******

An input window appears. \triangleright

- Note Special characters are not allowed! Default: user name: ,admin' password: admin
- Enter the user name using the keyboard and confirm.
- Enter a password (access code) using the keyboard and confirm.
- \triangleright The user settings window appears.
- \triangleright The user name is displayed with an automatically generated user ID.
- Select the corresponding lines with the cursor and confirm.

[User activated]

 \blacktriangleright Check the appropriate box \blacksquare .

An activated user can now log in.

⊲∲ ¶	Change user settings	@admin	
User ID		10	
User name	2	operator	
User activ	ated		
Password		******	
Language		System default	
Screensav	er	System default	
Logout aft	er	no auto logout	
Force logir	after screensaver		
Change us	er at relogin		
Need pass	word to logout		
^U System rights			
		Save	

	I.ID_A	May	2000-	0-		10.	
	Please login	I					
	User name				opera	tor	
	Password		C BL		*****	**	
						.	
1			стор				
			STOP				
1							i
<u> </u>			Login failed				J
1		(Us	er is deactivate	d.)			
			Cancel				
٦.							1

[Password]

The password can be changed here if desired.

[Language]

Select the desired operating language and confirm.

[Screensaver]

Selection:

[no screensaver], after 1 minute, after 5 minutes, after 10 minutes, after 30 minutes, system default

[Logout after]

Selection:

<no auto logout>, after 1 minute, after 5 minutes, after 10 minutes, after 30 minutes

[Force login after screensaver]

► Check the box ☑ when the screensaver is activated.

Once the screensaver is switched on, operation is only possible once a password has been entered.

[Change user at relogin]


• Check the box \blacksquare .

Once the screensaver is switched on, operation is also possible when a different password has been entered.

[Need password to logout]

• Check the box \blacksquare .

A password is required in order to log out.



▷ A deactivated user cannot log in. The following error message is displayed.

	Change user settings	@admin		
User ID		10		
User name		operator		
Setup				
Import				
Export				
Calibrate				
Operating				
User managem	User is allowed to browse			
I/O test	database/alibi memory on			
Maintenance	web page.			
Use functions	on the website			
Application rights				
		Save		

System rights:

[Setup]

• Check the box \mathbf{U} .

User is permitted to change settings in the system setup.

[Import]

• Check the box \mathbf{U} .

User is permitted to import data from the USB/SD memory to the device.

[Export]

• Check the box \blacksquare .

User is permitted to export data from the device to the USB/SD memory.

[Calibrate]

• Check the box \mathbf{V} .

User is permitted to calibrate weighing points.

[Operating]

► Check the box ☑. User is permitted to use the indicator keys.

[User management]

• Check the box \mathbf{V} .

User is permitted to create, change, and remove other users.

[I/O test]

• Check the box \square .

User is permitted to start, stop, and test the inputs and outputs.

[Maintenance]

Check the box I.
 User is permitted to use the system maintenance functions, including software updates.


[Use functions on the website]

• Check the box \blacksquare .

User is permitted to use functions on the website.

	Change user settings	@admin	
User ID User name Operator	User is allowed to edit application settings and order specific data.	10 operator Ø	
Supervisor			
Administrato	r		
-			
		Save	

Sample application rights:



[Operator]

• Check the box \blacksquare .

User is permitted to start weighing and change order-specific data.

[Supervisor]

• Check the box \blacksquare .

User is permitted to change application settings and order-specific data.

[Administrator]

• Check the box \blacksquare .

User is permitted to change firmware/application settings and order-specific data.

[Simulation]

• Check the box \blacksquare .

User is permitted to simulate tipping error correction.

▶ Press the [Save] soft key to save the settings.

5.9.2.2 Copying Users

This function is used among other things to create more than one user at a time with the same rights.

Create user Copy user Change user set Remove user Deactivate user		<u>@</u> admin	Navigate to [System setup]-[User manager and confirm the [Copy user] menu item.	ment]
Select user to admin default operator	Select user		 A selection window appears. Select and confirm the appropriate user. An input window appears. Enter and confirm the user name and pass see Chapter 5.9.2.1. Change the user settings if necessary, see Chapter 5.9.2.3. 	sword,

5.9.2.3 Changing User Settings

This function is used to change user settings.

Create user Copy user Change user se Remove user Deactivate user		@admin ►	•
Select user to admin default operator	Select user	@admin >	
4 01	Change user settings	©admin	⊳

 Navigate to [System setup]-[User management] and confirm the [Change user settings] menu item.

- > A selection window appears.
- Select and confirm the appropriate user.

_ 4∲ ¶	Change user settings	@admin		
User ID		10		
User name		operator		
User activated				
Password		******		
Language		System default		
Screensaver		System default		
Logout after		no auto logout		
Force login aft	er screensaver			
Change user at	: relogin			
Need password	j to logout			
¹ System rights				
		Save		

If the changes are made by the user "admin", only one entry is required for changing passwords.

Change user settings	Osupervisor
User ID	10
User name	operator
User activated	
Old Password	******
New Password	******
Language	System default
Screensaver	System default
Logout after	no auto logout
Force login after screensaver	
Change user at relogin	
Need password to logout	
System rights	
	Save

Change the corresponding parameters.
 Press the [Save] soft key to save the changes.

 \triangleright

If the changes are made by another user, two

entries are required for changing passwords.

5.9.2.4 Removing Users

Cop Cha Rer	User management @admin tate user by user ange user settings move user > activate user management	use	s function can be used to remove one or more rs from the user management. e users "admin" and "default" cannot be deleted. Navigate to [System setup]-[User management] and confirm the [Remove user] menu item.
adı suj det	Select user Osupervisor ect user to remove min pervisor fault erator		A selection window appears. Select and confirm the appropriate user.
4⊉∰	Remove user @supervisor		A prompt window appears. Press the corresponding soft key.

5.9.3 Deactivating User Management

Сор Cha Reп	User management ate user y user nge user settings nove user ctivate user management	(Dadmin)		er management can be deactivated again only by e user "admin". Navigate to [System setup]-[User management] and confirm the [Deactivate user management] menu item.
	Deactivate user management	@admin	\land	A prompt window appears. Press the corresponding soft key.
	Do you want to deactivate user managemen All user records will be permanently remove Yes No			

5.9.4 User Login/Logout

5.9.4.1 User Login

	 An authorized user must log in to start the application or enter parameters. Press the [Login] soft key to log in as a specific user. 			
09 <u> </u>	Note	pas em	he user "default" is active, a sword must be entered. The pty entry window only needs to confirmed to log in.	
Login Enter user name and password User name Password XXXXXXXXXX	A login window appears. Enter and confirm the user name. Enter and confirm the password (access code).			
	Note		Default: user name: "admin" password: "admin"	
System setup Oadmin Connected devices > Date & Time > Operating parameters > Network parameters > Network share connections > Fieldbus parameters > Weighing point > Display settings > License settings > User management Alibi memory			urrently logged in is shown in nd corner of the display.	

5.9.4.2 User Logout

🙀 Operating	l b
Application menu	1
Weighing	
Check weighing	l b
Device employed as terminal	
Configuration	
System menu	
System setup 🔸	
System information	
System maintenance	
Logout	

- Press the MENU key to switch to the operating menu.
- Press the [Logout] soft key to log out the user who is currently logged in. If a password is required to log out the user (option activated in the user settings), the entry window appears accordingly.

5.10 System Menu

5.10.1 System Setup: Connected Devices

System setup

– Connected	d devices	
	General devices:	
	– Remote display	
	– Interface	<not assigned="">, Built-in RS-232, Option-1/FB or Option-2 RS-485-A, Option-1/FB or Option-2 RS-485-B</not>
		varies according to interface
	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.
	– ModBus-RTU master	
	- Interface	<not assigned="">, Built-in RS-232, Option-1/FB or Option-2 RS-485-A, Option-1/FB or Option-2 RS-485-B</not>
		varies according to interface
	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.
	– PC via EW-Com	
	- Interface	<not assigned="">, Built-in RS-232, Option-1/FB or Option-2 RS-485-A, Option-1/FB or Option-2 RS-485-B</not>
	– Protocol	EW-Com V1, EW-Com V2, EW-Com V3
		varies according to interface
	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.
	– Printer	
	- Interface	<not assigned="">, Built-in RS-232, Option-1/FB or Option-2 RS-485-A, Option-1/FB or Option-2 RS-485-B, Network printer, Network share connection, USB printer, USB folder</not>
		varies according to interface
	– Default	Settings are reset to factory settings.
	- Test printout	The printer configuration is printed out.
	– Save	The settings are saved.
	– Add. application devices	S:
	– Ticket printer	

Note	Application-specific devices are listed under "Add. application devices," see corresponding
	manual.

5.10.2 System setup: Date & Time

System setup

– Date & Time
' I

ime		
– Tim	e zone	Berlin, Germany
– Loca	al date	Current date
– Loca	al time	Current time
– Cloo	ck source	Local hardware clock, Remote NTP (Network Time Protocol)
– Ren	note NTP server	IP address; only displayed when "Remote NTP" is selected as the clock source.
– Last	t update	Last updated time on the remote NTP server; only displayed when "Remote NTP" is selected as the clock source.
– onli	ne	Status; only displayed when "Remote NTP" is selected as the clock source.
– Fori	mat	
	Date format:	
	 Date of order 	mmddyyyy, ddmmyyyy, yyyymmdd, yyyyddmm
	 Date separator 	Slash "/", Hyphen "-", Period ".", Space, Japanese 年月日, None
	– Month	2 digits, 3 characters
	– Year	2 digits, 4 digits
	 Date/Time separator 	Hyphen "-", Space, None
	Time format:	
	– Clock type	12 h, 24 h
	- Time separator	Hyphen "-", Japanese 時分秒, Colon ":", None
	– Default	The format settings are reset to factory settings.
	– Save	The format settings are saved.
– Sav	e	The settings are saved.

5.10.3 System setup: Operating parameters

System setup

– Operating parameters

	51	
	Operation:	
	— Display language	<(en) English>, (de) Deutsch, et al.
		User management activated: This setting is only applied once the user has logged off.
 Display language External keyboard layout Input method Screensaver Keyclick sound Coldstart with STOP+EXIT Programming: 		<english qwerty="">, german QWERTZ, french AZERTY, italian QWERTY, spanish QWERTY, Russian QWERTY/йцукен</english>
 Input method Screensaver Keyclick sound Coldstart with STOP+EXIT 		<by language="">, Hepburn (transfer japanese syllabary ,Hiragana' to latin script), Pinyin (phonetic notation on the basis of roman alphabet)</by>
		[no screensaver], after 1 minute, after 5 minutes, after 10 minutes, after 30 minutes
 Input method Screensaver Keyclick sound Coldstart with STOP+EXIT 		no key click, <short click="" key="">, medium key click, long key click</short>
	 Coldstart with STOP+EXIT 	disabled, immediately, for 3 seconds
		<disabled>, enabled</disabled>
		<disabled>, enabled</disabled>
Operational keys:		
– Keys require logged		Check the box ${f Q}$, if keys have to be disabled for a logged out user.
	– Tare key	disabled, <set &="" reset="" tare="">, set tare & set tare again</set>
	– Set zero key	disabled, <only not="" tared="" when="">, reset tare on zero set</only>
	– F1 key	no function, Change language, Change user, Lock device, Toggle weight
	– F2 key	unit, Set tare, Reset tare, set tare & reset tare, set tare & zero set, Analog test, Show 10-fold resolution, application-specific options are available
	– Keyboard test	Keyboard test, Enter text and click OK .
	— Default	Settings are reset to factory settings.
	– Save	The settings are saved.
 Screensaver Keyclick sound Coldstart with STOP+EXIT Programming: Software download Label/Language download Operational keys: Keys require logged in user Tare key Set zero key F1 key F2 key Keyboard test Default 		

5.10.4 System setup: Network parameters

System setup

- Network parameters

- HW address	xx:xx:xx:xx:xx, displayed only
— Device name (hostname):	e.g.: Hopper 01, Entry: 2-24 alphanumerical characters
– use DHCP	Check the box $oldsymbol{B}$, if the IP address is to be automatically assigned to a network.
– IP address	nnn.nnn.nnn.nnn; current values are displayed when DHCP has been selected.
– Subnet mask	nnn.nnn.nnn.nnn; current values are displayed when DHCP has been selected.
— Default gateway	nnn.nnn.nnn.nnn; current values are displayed when DHCP has been selected.
Remote access:	
- Webserver enabled	Check the box $oldsymbol{\overline{M}}$, if the functions are to be shared via web server.
– VNC-Zugang enabled	Check the box $oldsymbol{B}$, if the functions are to be shared via VNC.
– VNC client	nnn.nnn.nnn.nnn; enter the corresponding number.
– VNC password	********* (max. 8 characters); protect the device from unauthorized access.
– Default	Settings are reset to factory settings.
- Save	The settings are saved.

5.10.5 System setup: Network share connections

System setup

– Network share connections

Configure Network share connection	ns Connected network share are displayed.
– Add	Add a new network share connection.
- Connection name	Unique name in the device, Entry: max. 16 alphanumerical characters
– Server	Server name (max. 64 characters, valid Hostname acc. to RFC 952) or IP address can be entered.
- Share name on server	Unique name on server, Entry: max. 64 characters (Must match the share name.)
— Folder path	Path to folder relative to share. Folder must exist.
	Entry: max. 128 characters
	Not allowed are: ,/' (slash) or , ' (space) at beginning or end, ,.' (dot) at end and some specific combinations of ,.', '/', and , ' (space).
– Domain	(Optional) Name of Windows domain, Entry: Max. 64 characters
– User name	(Optional) User name, Entry: Max. 64 alphanumerical characters
- Password	(Optional) Password, Entry: Max. 64 characters
— Test	Connects temporary to the share and tries to create a file in the specified folder.
– Save	The settings are saved.
– Change	Change a network share connection.
– Remove	Remove a network share connection.

5.10.6 System setup: Fieldbus parameters



— Fieldbus	parameters	
	Fieldbus protocol:	The name of the installed fieldbus card is displayed.
		varies according to fieldbus card
	— Default	Settings are reset to factory settings.
	– Save	The settings are saved.

5.10.7 System setup: Weighing point – Weighing point A

System setup

– Weighing points

- Weighing point A

<not assigned>, Internal weighing point, xBPI scale, SBI scale, Pendeo Truck, Pendeo Process, PR-Net weighing point, Mettler-Scale, SMA scale

5.10.8 System setup: Weighing point: Weighing point A: Internal weighing point

orroro bystem	secupi rreigning pointi rr	eighnig point in internal weighnig point
System setup		
– Weighing poin	nt	
– Weighir	ng point A	Internal weighing point
– Calit	0	Calibrate weighing electronics
1 - 1	Vew	
	 Reset SPAN and dead load 	<continue>, Cancel</continue>
	— Max (Maximum capacity)	Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz</kg>
	– Scale interval (1 d)	Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal places at Max and the weight unit
	– Dead load at	by load, by mV/V, Save
	– Max at	by load, by mV/V, by date, Linear, Save
	 calibrated with mV/V 	displayed only
	 Sensitivity 	displayed only
	– Save	The calibration is saved.
- 1	Modify	For small modifications only, such as resetting the dead load. Otherwise selected "New."
	— Max (Maximum capacity)	Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz</kg>
	– Scale interval (1 d)	Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal places at Max and the weight unit
	– Dead load at	by load, by mV/V, Save
	– Max at	by load, by mV/V, by date, Linear, Save
	 calibrated with mV/V 	displayed only
	 Sensitivity 	displayed only
	– Save	The calibration is saved.


– Units	1, 2, 3; additional weight units for display
– Units 13	kg, t, lb, g, mg, oz
— Display accuracy	<same>, 1 level lower, 2 level lower, 3 level lower, 3 level higher, 2 level higher, 1 level higher</same>
– Default	Settings are reset to factory settings.
– Save	The settings are saved.
– Parameter	Parameter settings
– Settings locked	When selected settings are displayed only. No changes possible (as when CAL switch is closed).
– W&M	<none>, [OIML] (not possible when range mode "multi-interval" is selected or Max has been set with more than three decimal places), NSC, NTEP</none>
– Measurement time	5 ms, 10 ms, 20 ms, 40 ms, 80 ms, <160 ms>, 320 ms, 640 ms, 960 ms, 1280 ms, 1600 ms, [≤1 s]
– Digital filter	<off>, Bessel, aperiodic, Butterworth, Tschebyscheff</off>
	The digital filter can only be switched on if a measurement time is set to ≤160 ms; see Section "[Digital filter]" on page 176.
– Cutoff frequency	The cutoff frequency for the low pass filter can be set from 0.01 to 40.00 Hz; only when the digital filter is selected. The Hz range depends on the measurement time; see Section "[Cutoff frequency]" on page 175.
 External load cell sup- ply 	≤8 V, >8 V
– Standstill time	0.00 s<0.50 s>2.00 s (The range depends on the measurement time.)
– Standstill range	0.00 d1.00 d10.00 d (The range depends on the measurement time.)
– Tare timeout	0.0 s<2.5 s>25.0 s; timeout when there is no standstill
– Zeroset range	0.00 d<50.00 d>10000.00 d [<4% and <20% of Max], timeout duration when there is no standstill
– Zerotrack	<yes>, no; when "yes" is selected values for the next three parameters must be entered.</yes>
– Zerotrack range	0.01 d0.25 d10000.00 d (only if "Zerotrack" is set to "yes")
– Zerotrack step	0.01 d0.25 d10.00 d (only if "Zerotrack" is set to "yes")
– Zerotrack time	0.1 s1.0 s25.0 s [<0.5 e/s] (only if "Zerotrack" is set to "yes")
- Overload	0 d9 d99999999 d [≤9 e]
– Minimum weight	0 d20 d99999999 d [20 e for class III]
– Range mode	<single range="">, multiple range, multi-interval</single>
	See also Chapters 5.11.16.2 and 5.11.16.3.
— Range limit 1	0max. weight, transition from small to medium scale interval; only when multiple range or multi-interval has been selected.
– Range limit 2	0max. weight, transition from medium to large scale interval; only when multiple range or multi-interval has been selected.
— Default	Settings are reset to factory settings.
– Save	The settings are saved.

5.10.9 System setup: Weighing point: Weighing point A: xBPI scale

System setup

– Wei	ighing	point			
	– Weighing point A		point A	xBPI scale	
		– Para	ameters	see Chapter 5.12.3	
		– Cali	b	Calibrate weighing point	
		Pre	eload/dead load:		
			– Set	Accept, error reset, cancel	
			– Delete	Accept, error reset, cancel	
			SPAN:		
			– Adjust with user weight	Calibrate with user-defined weight.	
			 Adjust with automatic weight 	Calibrate with automatic weight detection	
			 Adjust with default weight 	Calibrate with default weight	
			 Adjust with internal weight 	Calibrate with internal weight	
		Lin	earity:		
			– Default linearisation	Accept, error reset, cancel	
			– User linearisation	Accept, error reset, cancel	
		– Unit	ts		
			Number of units	1 weight unit, 2 weight units, 3 weight units	
			– Units 1-3	Gram g, Kilogram kg, Carat ct, Pound Ib, Unze oz, Troy unze ozt, Tael Hongkong tlh, Tael Singapur tls, Tael Taiwan tlt, Grain GN, Pennyweight dwt, Milligram mg, Parts/pound /lb, Tael china tlc, Momme mom, Karat k, Tola tol, Baht bat, Mesghal m, Tonne t	
			– Display accuracy	<basic accuracy="">,-1 at load cycle, 1 level lower, 2 level lower, 3 level lower, 3 level higher, 2 level higher, 1 level higher</basic>	
		– Seti	dr	Once the scale is connected, all important data is loaded from the scale on the device.	
		-	Configuration	See xBPI parameter tables on page 187.	

5.10.10 System setup: Weighing point: Weighing point A: SBI scale



5.10.11 System setup: Weighing point: Weighing point A: Pendeo Truck

System setup

leighin	g point	
1	leighing point A	Pendeo Truck
' I	– Parameters	Parameter settings
	– Settings locked	When selected settings are displayed only. No changes possible (as wher CAL switch is closed).
	– WEtM	<none>, [OIML] (not possible when range mode "multi-interval" is selected or Max has been set with more than three decimal places), NSC NTEP</none>
	- Ambient conditions	very stable condition, Stable condition, Unstable condition, Very unstable condition
	– Detect a defect load cell	Select \blacksquare if max. simulation of a faulty load cell should be automatic.
	 Unbalanced check deviation 	The plausibility check is activated when the average deviation is >0%. Setting range: 0–100%
	– Standstill time	0.00 s<0.50 s>2.00 s (The range depends on the measurement time.)
	– Standstill range	0.00 d1.00 d10.00 d (The range depends on the measurement time.)
	– Tare timeout	0.0 s<2.5 s>25.0 s; timeout when there is no standstill
	– Zeroset range	0.00 d<50.00 d>10000.00 d [<4% and <20% of Max], timeout duration when there is no standstill
	– Zerotrack	<yes>, no; when "yes" is selected values for the next three parameters must be entered.</yes>
	– Zerotrack range	0.01 d0.25 d10000.00 d (only if "Zerotrack" is set to "yes")
	 Zerotrack step 	0.01 d0.25 d10.00 d (only if "Zerotrack" is set to "yes")
	– Zerotrack time	0.1 s1.0 s25.0 s [<0,5 e/s] (only if "Zerotrack" is set to "yes")
	– Overload	0 d<9 d>99999999 d [≤9 e]
	– Minimum weight	0 d<20 d>99999999 d [20 e for class III]
	– Range mode	<single range="">, multiple range, multi-interval See also Chapters 5.11.16.2 and 5.11.16.3.</single>
	— Range limit 1	0max. weight, transition from small to medium scale interval; only when multiple range or multi-interval has been selected.
	— Range limit 2	0max. weight, transition from medium to large scale interval; only when multiple range or multi-interval has been selected.
	— Default	Settings are reset to factory settings. If "Settings locked" is selected, the [Default] soft key is not active.
	– Save	The settings are saved.

|-

Calib		
Setup	Pendeo:	
	ick install with search d cells and set dead	 Search for a new network and reset the load cell data to the factory settings.
loa	d	- Enter local gravity.
		- Set dead load with load.
– Sea cell	rch for connected load s	- Search for a new network and reset the load cell data to the factory settings.
– Vie	w and assign load cells	
-	Info	View selected load cell data.
-	Assign	Assign load cells.
-	by name	Change the display from "by ID" (LC 1n + serial number) to "by name" of load cells; only possible if a load cell name has been assigned.
-	by ID	Change the display from "by name" to "by ID" of load cells.
-	Accept	Accept the load cell assignment; only possible if load cell assignment is active.
-	Save	The settings are saved.
– Cal	ibrate the scale	
-	New	Carry out a new calibration.
	– Local gravity	<9.81379 m/s²> (Hamburg)
	 Number of platforms 	Only appears if the number of load cells is ≥ 8 .
	– Max (Max. capacity)	Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz</kg>
	– Scale interval (1 d)	Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal places at Max and the weight unit
	– Dead load	by load, by value
	– Calibration weight	user weight
	- Corner correction	Platform 1, platform 2 (Only appears if the number of load cells is ≥ 8 .)

– Ca	alib		
	– Cal	ibrate the scale	
	-	Modify	Modify calibration.
		– Local gravity	<9.81379 m/s²> (Hamburg)
		— Max (Max. capacity)	Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz</kg>
		— Scale interval (1 d)	Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal places at Max and the weight unit
		– Dead load	by load, by value
		– Calibration weight	user weight
		- Corner correction	Platform 1, platform 2 (Only appears if the number of load cells is ≥ 8 .)
		– Save	Save calibration.
	– Ass	ign load cell name	Give each load cell a name.
	-	Load cell 1-n	e.g.: PR 6224-xx
	-	Default	Settings are reset to factory settings.
	-	Save	The settings are saved.
	– Ser	vice function for LCs	Deactivate/activate load cell.
	-	Load cell 1-n	Select the faulty load cell and reset \blacksquare to \Box .
			Select the new (replaced) load cell and select \mathbf{v} .
	-	Accept	After deactivation the simulation for the deactivated load cell starts. Once the replaced load cell has been activated the search process starts.
- U	nits		1, 2, 3; additional weight units for display
	– Uni	ts 1-3	kg, t, lb, g, mg, oz
	— Dis	play accuracy	<basic accuracy="">, 1 level lower, 2 level lower, 3 level lower, 3 level higher, 2 level higher, 1 level higher</basic>
	– Def	ault	Settings are reset to factory settings.
	– Sav	re	The settings are saved.

5.10.12 System setup: Weighing point: Weighing point A: Pendeo Process

System setup

– We	ghing point	
	– Weighing point A	Pendeo Process
	- Parameters	Parameter settings
	– Settings locked	When selected settings are displayed only. No changes possible (as when CAL switch is closed).
	— WEtM	<none>, [OIML] (not possible when range mode "multi-interval" is selected or Max has been set with more than three decimal places), NSC, NTEP</none>
	- Ambient conditions	very stable condition, Stable condition, Unstable condition, Very unstable condition
	- Detect a defect load cell	Select 🗹 if max. simulation of a faulty load cell should be automatic.
	 Unbalanced check deviation 	The plausibility check is activated when the average deviation is >0%. Setting range: 0–100%
	- Standstill time	0.00 s<0.50 s>2.00 s (The range depends on the measurement time.)
	- Standstill range	0.00 d1.00 d10.00 d (The range depends on the measurement time.)
	- Tare timeout	0.0 s<2.5 s>25.0 s; timeout when there is no standstill
	– Zeroset range	0.00 d<50.00 d>10000.00 d [<4% and <20% of Max], timeout duration when there is no standstill
	– Zerotrack	<yes>, no; when "yes" is selected values for the next three parameters must be entered.</yes>
	– Zerotrack range	0.01 d0.25 d10000.00 d (only if "Zerotrack" is set to "yes")
	– Zerotrack step	0.01 d0.25 d10.00 d (only if "Zerotrack" is set to "yes")
	– Zerotrack time	0.1 s1.0 s25.0 s [<0,5 e/s] (only if "Zerotrack" is set to "yes")
	– Overload	0 d<9 d>99999999 d [≤9 e]
	– Minimum weight	0 d<20 d>9999999 d [20 e for class III]
	– Range mode	<single range="">, multiple range, multi-interval See also Chapters 5.11.16.2 and 5.11.16.3.</single>
	– Range limit 1	0max. weight, transition from small to medium scale interval; only when multiple range or multi-interval has been selected.
	– Range limit 2	0max. weight, transition from medium to large scale interval; only when multiple range or multi-interval has been selected.
	– Default	Settings are reset to factory settings. If "Settings locked" is selected, the [Default] soft key is not active.
	– Save	The settings are saved.

	Pendeo:	
	ick install with search d cells and set dead d	 Search for a new network and reset the load cell data to the factory settings. Enter local gravity. Set dead load with load.
– Sea cel	arch for connected load Is	- Search for a new network and reset the load cell data to the factory settings.
– Vie	w and assign load cells	
-	Info	View selected load cell data.
-	Assign	Assign load cells.
-	by name	Change the display from "by ID" (LC 1n + serial number) to "by n of load cells; only possible if a load cell name has been assigned.
-	by ID	Change the display from "by name" to "by ID" of load cells.
-	Accept	Accept the load cell assignment; only possible if load cell assignment; active.
-	Save	The settings are saved.
– Cal	ibrate the scale	
_	New	Carry out a new calibration.
		<9.81379 m/s²> (Hamburg)
	– Local gravity	
	 Local gravity Number of vessel feet 	Enter number.
	- Number of vessel	•
	 Number of vessel feet Max (Max. 	Enter number. Upper limit of weighing range
	 Number of vessel feet Max (Max. capacity) 	Enter number. Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal</kg>
	 Number of vessel feet Max (Max. capacity) Scale interval (1 d) 	Enter number. Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal at Max and the weight unit</kg>
	 Number of vessel feet Max (Max. capacity) Scale interval (1 d) Dead load 	Enter number. Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal at Max and the weight unit by load, by value</kg>

— Ca	lib		
	– Cali	ibrate the scale	
	-	Modify	Modify calibration.
		— Local gravity	<9.81379 m/s²> (Hamburg)
		— Max (Max. capacity)	Upper limit of weighing range 0.000010<3000>9999998 <kg>, t, lb, g, mg, oz</kg>
		– Scale interval (1 d)	Selection <1>, 2, 5, 10, 20, 50 displayed according to the decimal places at Max and the weight unit
		– Dead load	by load, by value
		– Calibration weight	user weight
		– Corner correction	
		– Save	Save calibration.
	– Ass	ign load cell name	Give each load cell a name.
	-	Load cell 1-n	e.g.: PR 6224-xx
	-	Default	Settings are reset to factory settings.
	-	Save	The settings are saved.
	– Ser	vice function for LCs	Deactivate/activate load cell.
	-	Load cell 1-n	Select the faulty load cell and reset \blacksquare to \square .
			Select the new (replaced) load cell and select $oldsymbol{arsigma}$.
	-	Accept	After deactivation the simulation for the deactivated load cell starts.
			Once the replaced load cell has been activated the search process starts.
– Un	nits		1, 2, 3; additional weight units for display
	– Uni	ts 1-3	kg, t, lb, g, mg, oz
	— Disj	olay accuracy	<basic accuracy="">, 1 level lower, 2 level lower, 3 level lower, 3 level higher, 2 level higher, 1 level higher</basic>
	– Def	ault	Settings are reset to factory settings.
	– Sav	e	The settings are saved.

5.10.13 System setup: Weighing point: Weighing point A: PR-Net Weighing Point

System setup

– Weighing point	
– Weighing point A	PR-Net weighing point
– Parameters	Parameter settings
- Settings locked	When selected settings are displayed only. No changes possible (as when CAL switch is closed).
— WEtM	<none>, [OIML], NSC, NTEP</none>
– Serial number	<0>9999999999
 Network address 	Numeric input: IP address (nnn.nnn.nnn)
	or
	Alphanumeric input:
	Device name (host name)
— Default	Settings are reset to factory settings.
– Save	The settings are saved.

5.10.14 System setup: Weighing point: Weighing point A: Mettler-Scale

System setup

- Weighing point AMettler-Scale- ParamParameter settings- Settings lockedWhen selected settings are displayed only. No changes possible (as when CAL switch is closed) W&tM <none>, [OIML], NSC, NTEP- Max (Maximum capacity)0.000001 mg<1000 kg>9999999 t- Scale interval<1>, 2, 5, 10, 20, 50- Weight per0.000001 mg<1 kg>9999999 t- Minimum weight0 d9999999 d- Update time0.1 s<0.3 s>2.0 s- DefaultSettings are reset to factory settings SaveThe settings are saved.</none>	- Weighing point	
- Settings lockedWhen selected settings are displayed only. No changes possible (as when CAL switch is closed) W&tM <none>, [OIML], NSC, NTEP- Max (Maximum capacity)0.000001 mg<1000 kg>9999999 t- Scale interval<1>, 2, 5, 10, 20, 50- Weight per0.000001 mg<1 kg>9999999 t- Minimum weight0 d9999999 d- Update time0.1 s<0.3 s>2.0 s- DefaultSettings are reset to factory settings.</none>	– Weighing point A	Mettler-Scale
CAL switch is closed) W&M- Max (Maximum capacity)0.000001 mg<1000 kg>9999999 t- Scale interval- Scale interval- Weight per0.000001 mg<1 kg>9999999 t- Minimum weight0 d9999999 d- Update time0.1 s<0.3 s>2.0 s- DefaultSettings are reset to factory settings.	– Param	Parameter settings
 Max (Maximum capacity) 0.000001 mg<1000 kg>99999999 t Scale interval <1>, 2, 5, 10, 20, 50 Weight per 0.000001 mg<1 kg>9999999 t Minimum weight 0 d9999999 d Update time 0.1 s<0.3 s>2.0 s Default Settings are reset to factory settings. 	– Settings locked	
- Scale interval <1>, 2, 5, 10, 20, 50 - Weight per 0.000001 mg<1 kg>9999999 t - Minimum weight 0 d9999999 d - Update time 0.1 s<0.3 s>2.0 s - Default Settings are reset to factory settings.	— W&M	<none>, [OIML], NSC, NTEP</none>
- Weight per 0.000001 mg<1 kg>99999999 t - Minimum weight 0 d99999999 d - Update time 0.1 s<0.3 s>2.0 s - Default Settings are reset to factory settings.	– Max (Maximum capacity)	0.000001 mg<1000 kg>99999999 t
- Minimum weight0 d9999999 d- Update time0.1 s<0.3 s>2.0 s- DefaultSettings are reset to factory settings.	– Scale interval	<1>, 2, 5, 10, 20, 50
- Update time0.1 s<0.3 s>2.0 s- DefaultSettings are reset to factory settings.	– Weight per	0.000001 mg<1 kg>9999999 t
 Default Settings are reset to factory settings. 	– Minimum weight	0 d9999999 d
	— Update time	0.1 s<0.3 s>2.0 s
- Save The settings are saved.	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.

5.10.15 System setup: Weighing point: Weighing point A: SMA scale

System setup

– Weigh	ing point	
-	Weighing point A	SMA scale
	– Parameters	Parameter settings
	- Settings locked	When selected settings are displayed only. No changes possible (as when CAL switch is closed).
	– W&M	<none>, [OIML], NSC, NTEP</none>
	– Max (Maximum capacity)	0.000001 mg<1000 kg>99999999 t
	– Scale interval	<1>, 2, 5, 10, 20, 50
	— Minimum weight	0 d9999999 d
	— Update time	0.1 s<0.3 s>2.0 s
	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.

5.10.16 System setup: Display settings

System setup

_

– Dis	play settings	
	 Color set 	daylight, night shade
	- Luminance	0100 % <80 %>
	– Default	Settings are reset to factory settings.
	– Save	The settings are saved.

5.10.17 System setup: License settings

System setup System setup - License settings Board number: displayed - ... Function and application licenses can be added, activated, and deleted. - Default Settings are reset to factory settings. - Demo mode Operation is possible without a license for a limited time or with limited functionality. - Save The settings are saved.

5.10.18 System setup: User management

System setup

– User management

– Create user	Users "admin" and "default" have already been created.
– User name	Entry only allows alphanumerical characters.
– Password	Entry only allows alphanumerical characters.
 Select user settings 	Selection via checkboxes.
– Save	The settings are saved.
— Copy user	The settings for the selected user are copied.
– User name	Entry only allows alphanumerical characters.
– Password	Entry only allows alphanumerical characters.
 Select user settings 	Selection via checkboxes.
– Save	The settings are saved.
– Change user settings	The settings for the selected user are changed.
– Save	The settings are saved.
– Remove user	Users "admin" and "default" cannot be deleted. A prompt window appears.
– Deactivate user management	Any users created are deleted. A prompt window appears.

5.11 Calibrating the Internal Weighing Point

5.11.1 General Information

With applications for use in legal metrology, the legal requirements and the conditions given on the test/ approval certificate must be taken into account when selecting the settings.

There are two ways to save the calibration data:

- Via a CAL switch
- Via software

During calibration, the instrument must be set to gross weight display (reset tare, if necessary).

5.11.1.1 CAL Switch

The calibration data can be protected with CAL switch A and the weighing electronics with CAL switch 1 (see Chapter 5.1.5.1).

5.11.1.2 Software

A unique check number is created every time a calibration or changed parameters are saved. This can be viewed under [System information]-[Show calibration check numbers] (see Chapter 5.20.7) and noted.

5.11.2 Showing the Calibration Data

5.11.2.1 Overwrite Protection via a CAL Switch

WP-A	Max	3000g	e=	1g
→0←][] _
∢ ∳¶	CAL s	witch A is close	d	@admin
Weighing po	int A	Inter	nal wei	ighing point 🕨
Parameters WP-A	Calib Max	Units 3000g	e=	
			e=	
			<u></u>	, , ,
₩P-A →0←	Мах][19 J g @admin
₩P-A →0←	Мах	3000g][] _
WP-A →O← ► ▲ 4∱1 C.	Max Max	3000g AL switch is clo][) @admin 3000.0 g 1.0 g
WP-A →O← Max Scale interv Dead load a	Max Max alibration (C	3000g 3000g AL switch is clo 3000 d 1 d 103.310 g][D @admin 3000.0 g 1.0 g 0.040538 %
WP-A →O← Max Scale interv Dead load a Max at	Max Alibration (C Val	3000g 3000g AL switch is clo 3000 d 1 d 103.310 g 3000.000 g][O admin 3000.0 g 1.0 g 0.040538 % 1.177196 %
WP-A →O← Max Scale interv Dead load a	Max Alibration (C Val	3000g 3000g AL switch is clo 3000 d 1 d 103.310 g][D @admin 3000.0 g 1.0 g 0.040538 %

If the CAL switch is closed, a tool tip appears. The data under [Parameters], [Calib], [Units] is displayed only.

- E.g., press the [Calib] soft key.
- The calibration data is displayed: Scale interval and maximum capacity (Max)
 Scale interval(s)
 Dead load in weight and mV/V
 Weight and mV/V for maximum capacity
 Test load* and corresponding mV/V
 Number of internal counts and voltage per scale interval

The calibration data and parameters (press [Parameters]) are displayed in the format entered/determined during calibration.

* After input with mV/V, the maximum capacity and the mV/V value entered are displayed.

5.11.2.2 Overwrite Protection via Software

WP-A	Max	3000g	e=	19		Setti ordi
→0←				Ja	The	e dat playe
	'Setti	ings locked' is	set	 @admir	1	
Weighing poin	t A	Int	ernal W	eighing point 🕨		
Parameters	Calib	Units				
	Callo	Units				
WP-A	Max	3000g	e=	19	•	E.g
					•	E.g The
WP-A			•= 0 .() g	• •	
WP-A →O←	Max			19 D g @admir		
WP-A →O← ▲ Max	Max alibration	3000g (Settings loc) 3000		D @admir 3000.0 g	1	
WP-A →O← ▲ Max Scale interval	Max alibration	3000g (Settings loc) 3000 1		D <u>@admir</u> 3000.0 g 1.0 g	1	
WP-A →O← Max Scale interval Dead load at	Max alibration	3000g (Settings loc) 3000 1 103.310	(ed)	0 g 0 admir 3000.0 g 1.0 g 0.040538 %	 ;	
WP-A →O← Max Scale interval Dead load at Max at	Max alibration	3000g (Settings loc) 3000 1 103.310 3000.000	(ed)	0 g @admir 3000.0 g 1.0 g 0.040538 % 1.177196 %	 ;	
WP-A →O← Max Scale interval Dead load at	Max alibration	3000g (Settings loc) 3000 1 103.310		0 g 0 admir 3000.0 g 1.0 g 0.040538 %	 ; ;	

If 'Settings locked' is active, a tool tip appears accordingly.

The data under [Parameters], [Calib], [Units] is displayed only.

- E.g., press the [Calib] soft key.
- > The calibration data is displayed.

5.11.3 Increased Resolution (10-fold)

In the [Weighing points] menu, the weight is displayed with increased resolution (10-fold) for five seconds after a weighing point is selected, using the following keys:

- Key 🍯
- Function key F1 or F2 (when function has been assigned previously in the [Operating parameters] menu)

If the parameter "W&M" is selected for the weighing point, the weight value is marked as an invalid weight with the symbol \triangle . Switch to normal resolution after 2-3 seconds.

5.11.4 Selecting the Calibration Mode

Note The menu item 'Modify' is only used for small changes (e.g., changing the dead load/preload, changing the mV/V values for dead load/preload and/or Max, changing the scale interval). Otherwise selected 'New'.

WP-A	Max	3000g	e=	19
→0 ←				0,
₩ .	Ca	alibration		@admin
Max		3000	d	3000.0 g
Scale interval		1	d	1.0 g
Dead load at		103.310	9	0.040538 🛩
Max at		3000.000	9	1.177196 🖄
calibrated at		1000.0	9	0.392399 🖄
Sensitivity		981.00 🤊	4	4.708786 🖄
New N	1odify			

5.11.4.1 New Calibration

WP-A	Max	3000g	e=	1g
→o←			ΠΠ	
<mark>▶</mark> -		?		J
Ma Sca	SPAN and de	ad load will	be reset.	0.1 9 0.1
De: Ma				8 ∞×⊽ 6 ∞×⊽
cəl Ser	Cancel		Continue	9 ≫⊽ 5 ⊮⊲

Go to [System setup]-[Weighing point]-[Weighing point A]-[Calib] and use the soft keys to choose between [New] and [Modify].

- Select and confirm [System setup]-[Weighing point]-[Weighing point A]-[Calib].
- Press the [New] soft key.
 When you press [New], the default settings are restored and then calibration is started.
- \triangleright You are prompted to confirm.
- Press [Continue] for the default settings or [Cancel] to cancel the selection.

5.11.4.2 Modifying a Calibration

Example

Resetting the Dead Load

WP-A	Max	3000g	e=	1g
→0← ► ∡] _
4 0	C	alibration		@admin
Max		3000	d	3000.0 g
Scale interval		1	d	1.0 g
Dead load at		103.310	g	0.040538 🖄
Max at		3000.000	9	1.177196 🖄
calibrated at		1000.0	9	0.392399 🖄
Sensitivity		981.00 😕	3	4.708786 🖄
New 1	1odify			

WP-A	Max	3000g	e=	1g
→o←		().()	9
4 00	C,	alibration		@admin
Max		3000 d		3000.0 g
Scale interva	əl	1 d		1.0 g
Dead load at		103.310 g	Į O .	040538 🖄
Max at		3000.000 g	1.	177196 🖄
calibrated at	:	1000.0 g	0.	392399 🖄
Sensitivity		981.00 🕬	4.	708786 🖄
by load t	y mV/V			Save

Select and confirm [System setup]-[Weighing point]-[Weighing point A]-[Calib].
 Press the [Modify] soft key.

- Select the menu item [Dead load at].
- Either press the [by mV/V] soft key to enter the value again or clear the scale/hopper and press the [by load] soft key to reset the dead load.
- ▶ Press the [Save] soft key to save the calibration.
- ▷ The reference value is calculated for the electronics test.

5.11.5 Determining the Maximum Capacity [Max]

The maximum capacity (Max) determines the maximum weight without dead load of the weight to be measured and the displayed number of digits behind the decimal point. Normally, Max is less than the load cell capacity (nominal capacity x number of load cells).

WP-A	Max	3000g	e= 0.1g
+		121	.7 。
. ∢ ∲ ¶		Calibration	@admin
Max		30000 d	3000.0 g
Scale interval		1 d	0.1 g
Dead load at			0.000000 🛩
Max at			1.000000 🖄
not calibrated			
Sensitivity		83.33 🕫	0.400000 Ma
			Save

Permissible values for the maximum capacity are: Max weight value from 0.00010 to 9999999 in t, kg, g, mg, lb or oz.

Max weight value must be an integer multiple of the scale interval (1 d). It may have up to 6 digits and is entered as a numeric value with or without a decimal point.

- Enter the maximum capacity with decimal places (in this example: 3000.0).
- ▶ Double click key to select the weight unit.
- Confirm the entries.
- ▷ The confirmation is displayed with "setting Max...".
- ▶ Press the [Save] soft key to save the calibration.
- ▷ The reference value is calculated for the electronics test.

Note	If linearization is active (see Chapter 5.11.12): After selection of the line "Max at" the following tip is displayed:
	"cannot be changed here while linearization is active" Only deletion of linearization points deactivates linearization!

WP-A

→0←

.

4**4**9

Ma

Sca

Dea

Ma cal

Ser

Possible Error Messages



The maximum capacity of the scale can be increased retrospectively.

This message appears when the measurement signal for the given maximum capacity would exceed the permissible input voltage.

4000g 2g The maximum capacity of the scale can be increased retrospectively. When the capacity is reduced, however, a message appears when the new maximum capacity falls below the calibration weight ('calibrated ať). dmin).0 g 1.0 g] ≫∛⊽ | ≫∛⊽

WV V

些了

amin

).O g

1.0 g

) 📈

l °¥⊽

þ ȴ⊽ Ь 岁る This message appears if the selected resolution is too

2g low, e.g., 5 kg.

WP-A Max 4000g **2**g **→**0← Ľ **STOP** dmin 4**0** Set Max failed. Ma).0 g too many d 1.0 g Sca Dea ס≫ נ Ma °¥⊽ cal 14 Ser Ok

STOP

Set Max failed.

not enough d


Ok

This message appears when the selected resolution is so high that less than 0.8 internal counts per scale interval (d) are available.



Max

WP-A Max



This message appears if the maximum capacity [Max] of the scale range (weighing range) is not an integer multiple of the scale interval (1 d).

Weight units do not match, e.g., subsequent change of [Max] from kg to mg.

This message appears if the selected resolution is so high that less than 0.8 $\mu V/e$ are available when "OIML/ NSC" has been selected.

After [OK] is pressed, the input value for the maximum capacity [Max] is canceled.

→0←	<u> </u>	
<mark>▶</mark> .	STOP	J
Ma Sca Dea Ma cal	Set Max failed. Cannot align weight to scale.	1 mg 2.0 g 1 ॐv 3 ॐv
Ser	0k V	1 🖄

3000g

e=

2g 👘

WP-A	Max	4500g	e=	5g
→o←			Π	
<mark>▶ -</mark>		STOP		J
Ma Sca Dea		t Max failed. ugh µV∕d for		00 g 5 g) %
Ma cal				3 ∞⊻ ⊽ 8 ∞⊻⊽
Ser	T	Ok T		e 3 🖄

Sartorius

5.11.6 Determining the Scale Interval [Scale interval]

The scale interval (d) is the difference between two successive display values.


With a scale used in legal metrology, this value is called the "verification scale interval," which corresponds to the scale interval: d = e.

Example

Max = 6000 kg Scale interval (1 d) = 2 kg Calculation for scale interval for Max (automatic):

d = Max / Scale interval (1 d) d = 6000 kg / 2 kg d = 3000

Vorgehensweise



The weight unit is taken from [Max]. The number of digits behind the decimal point is also automatically determined when [Max] is entered.

- Select the scale interval (1 d).
- The scale interval (d) is then calculated, based on the Max weight value.
- Confirm the entries.
- ▷ The confirmation is displayed with "setting scale interval...".

This message appears if the maximum capacity [Max] of the scale range is not an integer multiple of the scale interval.

Note	If a liniarization was executed (see Chapter 5.11.12): After selection of the line "Dead load at" the following tip is displayed:
	"cannot be changed here while linearisation is active"
	Only deletion of linearization points deactivates linearization!

5.11.7 Determining the Dead Load [Dead load at]

NP-A 1	Мах	3000g	e=	2g
+	1	2	2.0] 。
	Calibr	ation		@admin
Max		1500	d	3000.0 g
Scale interval		1	d	2.0 g
Dead load at			1	0.000000 🖄
Max at				1.000000 🖄
not calibrated				
Sensitivity		1666.67 p	5	8.000000 Ma
by load by i	mV/V			Save

To use the empty scale/hopper as dead load (normal case):

- Clear the scale/hopper.
- Press the [by load] soft key.
- ► Confirm the entries.
- The confirmation is displayed with "setting dead load..."

If the mV/V value of the dead load was calculated, or if it is known from the previous calibration, the value can be overwritten by pressing [by mV/V].

Possible Error Messages





The dead load entered in mV/V plus maximum capacity in mV/V is higher than 3 mV/V (= 36 mV).

This message appears when the scale is not stable.

Remedy

- Check the mechanical function of the scale.
- Adapt the filter setting; reduce the resolution.
- Adapt the stability conditions.

WP-A	Max	3000g	e=	2g
_	7	יאף	7	
<mark>▶</mark> -		STOP		J
Ma Sca Dea		ead load fail load < - 0.1 mV).0 g }.0 g } ≫√
Ma not Ser		Ok) ™v] ⊮₁

This message appears if the measurement signal is negative (load cells connected with wrong polarity or defective) when determining the dead load with [by load].

Cause

Load cell connected with wrong polarity, or defective, or mechanical problem of the scale.

WP-A Max 3000g 2g \mathbb{A} О **4‡**¶ Imin Set dead load failed.).0 g Ma overflow in arithmetics l.0 g 3 ≫⊽ Sca Dea Ma h °¥⊽ not Ser h 些了 Ok by

This message appears if the dead load entered in mV/V is higher than 5 mV/V.

5.11.8 Calibrating with Weight [Max at]

WP-A	Max	3000g	e=	2g
→0←			0.0] g
4 00	C	alibration		@admin
Max		1500	d	3000.0 g
Scale interva	эl	1	d	2.0 g
Dead load at				0.040793 🖄
Max at			1	1.000000 🖄
not calibrate	:d			
Sensitivity		1666.67 s	<u>nt 3</u>	8.000000 M
by load b	y mV/V	by data	Linear.	Save

WP-A	Max 3000g d=	0.01g
+	2962.70	9
₩ .	Calibration	Madmin
Ma	place CAL weight	D0 g
Sca	on the scale and	😬 123
Dea	enter value.	🕮 unit
Ma	2516.9	9] 🖄
not		
Ser –	Ok Cancel	— Þ 🖄
by		e

To calibrate the scale with weights:

▶ Press the [by load] soft key.

- ▶ Place the calibration weight on the scale.
- ▶ Enter the weight of the calibration weight.
- ► Confirm the entries.

The weight unit for the calibration weight (double click to change) may differ from the unit in the device; conversion is automatic.

WP-A	Max	3000g	e=	2g
→o←].(] 。
4 0	C	alibration		@admin
Max		1500	d	3000.0 g
Scale interval		1	d	2.0 g
Dead load at		103.960	9	0.040793 🛩
Max at		3000.000	9 1	1.177284 🖄
calibrated at		2516.5 g		0.987545 🖄
Sensitivity		1962.14 😕	4	9.418273 🖄
by load il	y mV/V	by data	Linear.	Save

Afterward, the following message is displayed: "setting SPAN by load..."

The weight value of the calibration weight, weight unit, and measuring signal in mV/V corresponding to this value are displayed in the [calibrated at] line.

Possible Error Messages





This message appears when the scale interval is too small, if ,W&M' has been selected. Remedy:

Enter larger scale interval.

This message appears when the scale is not stable. Remedy:

- ▶ Check the mechanical function of the scale.
- Adapt the filter setting; reduce the resolution.
- Adapt the stability conditions.

This message appears if the load has been removed from the scale rather than added.



WP-A Max 3000a 1g +OP **4‡**¶ dmin Set SPAN failed.).0 g Ma weight >Max Sca .0 g B ≫√√ Dea Ma] 🖄 cal m¥ t b Ser 此日 Ok by

This message appears when an attempt is made to calibrate the scale with a weight heavier than the Max.

5.11.9 Calibrating with mV/V [Max at]

The scale can be calibrated without weights. During input of the load cell mV/V value, the acceleration of gravity at the place of installation can be taken into account. The STAR load cell data is based on the acceleration of gravity in Hamburg, Germany: 9.81379 m/s².

5.11.9.1 SPAN

SPAN indicates the equivalent input voltage in mV/V related to the maximum capacity (Max) of the scale. It is calculated as follows:

SPAN [mV/V] = load cell capacity x load cell sensitivity Cn* [mV/V] load cell capacity (nominal load Emax x number of load cells)


* Load cell sensitivity Cn = rated output Cn (see technical data of the load cell)

5.11.9.2 Dead Load

The input voltage in mV/V equivalent to the dead load can be calculated by using the dead load rather than the maximum capacity in the formula specified above.


Normally, calculation of the dead load (scale without load/empty hopper) is not necessary.

Subsequent dead load correction (as described in Chapter 5.11.11) can be used for later re-determination of the dead load, when the scale/hopper is empty.



Example

- 1 load cell with rated output $C_n = 2 \text{ mV/V}$
- at nominal load of 2,000 kg
- Maximum capacity 1,000 kg
- Dead load 500 kg
- Load cell supply voltage 12 V DC



- Press the [by mV/V] soft key to enter the value for Max and to correct the dead load if necessary (see Chapter 5.11.11).
- Confirm the entries.

5.11.10 Calibrating the Scale with Load Cell Data (Smart Calibration) [by data]

If the scale is not used in legal metrology, calibration without weights can be performed. The easiest method is the one using load cell data without calculation.

Procedure

WP-A	Мах	3000g	d=	2g
→0←			0.0	g
4 0	Load cell	configuration	п	@admin
Number of	load cells	Þ		4 load cells
тах. сара	city of load c	ell		3000 kg
Gravity		9	.81379 m/s	
Hysteresis error		п	ot specified	
Certified data		all load	cells same	
LC rated output		1	.000000 🖄	
Enter	Calc			

[Number of load cells]

Number of load cells connected in parallel (1, 2...<4>...9, 10)

[max. capacity of load cell]

Max. capacity Emax of a load cell (not the overall nominal weight of the scale!)

[Gravity]

Acceleration of gravity at the place of installation; default is the value for Hamburg, Germany: 9.81379 m/s².

[Hysteresis error]

If [not specified] is switched to [specified], values for [Correction A] and [Correction B] must be entered. This data must be taken from the load cell certificate.

[Certified data], [LC rated output], [LC output impedance]

When [all load cells same] is set, only one value each must be entered for [LC rated output] and the output impedance [LC output impedance].

For [each load cell specific] press the [Enter] soft key to enter individual data for each load cell.

- Press the [by data] soft key. Select the 'Number of load cells' line.
- \triangleright A selection window appears.
- Select the appropriate option.
- Take the next values from the technical data of the load cells (see below).
- ▶ Press the [Calc] soft key to start the calculation.
- Confirm the calculation to save the calculated mV/V value to the calibration data.

5.11.11 Subsequent Dead Load Correction

If the hopper/platform weight changes by an amount that is higher than the zero-setting range; e.g., due to dead load reduction, dead load increase, or mechanical changes, the functions for automatic zero tracking and manual zero setting no longer work.

The range currently used by zerotrack or zeroset is displayed in the menu [System information]-[Show HW options]-[WP A]-[Monitor].

Press the key to switch on increased resolution (10-fold) for the weight value.

If the full zero-setting range is already being utilized, you can still correct the dead load (overwrite protection must be deactivated, see Chapter 5.1.5) without affecting other calibration data/parameters.

Calibration is then accessed via [Calib]-[Modify] and the dead load is specified with 'Dead load at' [by load] (see Chapter 5.11.7).


Note	If a linearization was executed (see Chapter 5.11.12) the dead load can not be subsequently corrected! After selection of the line "Dead load at" the following tip is displayed:
	"cannot be changed here while linearization is active"
	Only deletion of linearization points deactivates linearization!

5.11.12 Linearity

The measurement range for a straight can be optimized by setting the linearization points.

Requirement

Max and dead load calibration was executed.



Procedure

► Go to the [Calib]-[New]/[Modify] menu, select the 'Max at' line and press the [Linear] soft key.

- ▷ The linearization menu is displayed.
 - Press the [Add] soft key to set a linearization point.

- \triangleright The following input window appears.
- ▶ Enter the desired value using the keyboard.
 - Press the [OK] soft key.
- Repeat these steps to set up to three linearization points in succession.
- ▷ The window shows the set linearization points.

After pressing [mV/V], the value can be entered directly.

After pressing [Change] the selected linearization point can be changed.

After pressing [Delete] the selected linearization point can be deleted.

Max

WP-A

+		75	<u>4.(</u>] _	
4 0	Lin	earisation		Qadmin	
1.Lin. point			0 g 🛔	0.295598 🖄	
2.Lin. point		150	-	ȴv	
3.Lin. point	it is a second	225	Ug	≫√ 1.177004 ≫√	
Add	Change	Delete	by mV/V	by load	
000	chonge	Delete	0/ 11107 0	07 1080	
WP-A	Max	3000g	d=	2g	
			0.0] _	
∢ ‡¶	Lin	earisation		@admin	
1.Lin. point		75	0 g	0.295598 🖄	
2.Lin. point		150	0 g	0.589210 🖄	
3.Lin. point		225	0 g į	0.882494 🖄	
calibrated µ	uith ≫∕⊽			1.1 77004 🖄	
Add	Change	Delete	by mV/V	by load	
WP-A	Max	3000g	d=	2g	

3000g

d=

2g 👘

	1107	3000g		<u>~9</u>
][] g
	Ca	libration		@admin
Max		1500 c	<u> </u>	3000.0 g
		e changed here	: while	2.0 g
Dead load at	linearisat	ion is active		0.040844 🖄
Max at		3000.000 <u>c</u>)	1.177004 🖄 🗸
calibrated wit	h ≫∛⊽			1.177004 🖄
Sensitivity		1961.67 😕	â	9.416032 🖄
by load by	′ mVZV i	by data	Linear.	Save

Select a linearization point, place the corresponding weight on the scale, and press the [by load] soft key.

- > The value corresponding to the weight is automatically entered in mV/V.
- Repeat these steps to automatically enter the corresponding values for the weights of all set linearization points in mV/V.
- Press the EXIT key to switch to the previous window.
- A message appears, indicating that the value for Max cannot be changed as long as linearization is active.

5.11.13 Saving the Calibration

→0←	Max	3000g		2 <u>9</u>	Press the [Save] soft key.
	Calib	ration		©admin	
Max Scale interval Dead load at Max at calibrated at Sensitivity		1500 1 104.100 3000.000 2516.5 1961.67 \$ by data	d g 0.0 g 11.1 g 0.9	3000.0 g 2.0 g 040844 % 177004 % 187310 % 416030 % Save	
Sca Dea Ma calibrated wit Sensitivity	¯ elect h ≫v	3000g	1.1	2g dmin 1.0 g 1.0	This window appears for a short time. The maximum capacity (Max) is displayed with the ID 'TST' and without a weight unit. The confirmation is displayed as follows: 'saving calibration' After exiting calibration, go to the menu [Param] and set the parameter 'Settings locked' to activate overwrite protection via the software (see Chapter 5.1.5.2).

Note

A unique check number is created every time a calibration or changed parameters are saved.

WP-A	Max	3500g	d=	2 g
			пп	
► -		?		J
 Ma	Evit uit	thout save d	ata?	dmin
Sca		es will be rev).0 g).0 g
De: Ma				+ ≫√⊽ ≫∕⊽
cal				+ °×⊽
	Yes	1	N₀	e 2 194

5.11.14 Canceling Calibration

- Press the EXIT key to finish calibration.
- \triangleright You are prompted to confirm.
- Press the [Yes] soft key to exit calibration without saving.
- Calibration is finished without saving with the following display:

'undoing calibration...'

5.11.15 Display Units

The device is calibrated with a selected weight unit. Up to two more units can also be displayed.

The weight display is switched using the function keys (F1 or F2). This must be assigned beforehand, see Chapter 5.19.3.


When three units are displayed, they are shown in the following sequence: from 1 to 2, 3, 1, 2, and so on.

If unit 2 or 3 is displayed, the symbol \triangle is also shown on devices used for legal metrology, when the non-legal weights are displayed.

In the following example, a second unit is set in [oz]. The display accuracy is set to [raw]. This means that the scale interval in weight roughly corresponds to the calibrated scale interval.

The third unit [Ib] has a display accuracy that is one level higher, meaning that the scale interval is roughly one level smaller than the calibrated scale interval. The values for Max and Min for the additional units are (roughly) calculated taking the associated scale intervals into account.

WP-A	Max	3000g	e=	1 <u>g</u>		Go to the menu [System setup]-[Weighing point]
→0← ►			0.0	g		[Weighing point A] and press the [Units] soft key to select additional units and the associated display accuracy.
. ∢∰		ning point		Dsupervisor		
Weighing poi			nternal weigh	ing point ▶		
Parameters	Calib	Units				
WP-A	Max	3000g	d=	2g	\triangleright	The following window appears.
			0.0	g	•	Confirm the selection.
Number of u		Units		Oadmin weight unit		
Default				Save		
1 weight u 2 weight u 3 weight u	nits	3000	d-	20 1 1		Select and confirm the line '3 weight units'.
				2946		



 \triangleright The following window appears.

- Select the desired units and their display resolution.
- Press the [Save] soft key to save the settings.

5.11.16 Parameter Input

WP-A	Max	3000g	d=	2g
→0← ► ◀			0.0	g
- 4 ∲¶	Weig	hing point		@admin
Settings lo	cked			
W&M				none
Measureme	ent time			320 ms
Digital filte	r			no filter
External lo	ad cell supply		above 8 V	
Standstill t	ime			0.50 s
Default				Save

Access the menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Parameters].

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[W&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

[Measurement time]

The duration of a measurement can be selected. Possible values include: 5 ms, 10 ms, 20 ms, 40 ms, 80 ms, 160 ms, 320 ms, 640 ms, 960 ms, 1280 ms, 1600 ms.

[Cutoff frequency]

The smaller the cutoff frequency, the slower the measurement and the more stable the measurement result.

The cutoff frequency for the low pass filter can be selected. The permitted range is 0.01...40.00 Hz. The available options depend on the measurement time.

The line 'Cutoff frequency' only appears if the digital filter is switched on.


[External load cell supply]

The external supply voltage is selected. Possible values: less than or equal to 8 V, higher than 8 V.


[Digital filter]


The following includes examples of interference signals for the different filter types:

Bessel filter




Butterworth filter





Tschebyscheff filter



A digital filter can be switched on only with the measurement time set to \leq 160 ms. The following filter types can be selected: no filter, Bessel, aperiodic, Butterworth, Tschebyscheff. If no particularly frequent fluctuations are expected in ongoing operation, the following settings are recommended:

[Measurement time]: ≤160 ms [Digital filter]: aperiodic [Cutoff frequency]: 2.00 Hz

WP-A	Max	3000g	d=	2g
→0← ►			0.0	g
- 4 ∲¶	Weig	hing point		Qadmin
Standstill tim	e	1		0.50 s
Standstill ran	ige			1.00 d
Tare timeout				2.5 s
Zeroset rang	e			50.00 d
Zerotrack				Yes
Zerotrack ra	nge			25.00 d
Default				Save

[Standstill time]

The parameters [Standstill time] and [Standstill range] can be used to define the stability of the scale (stable balance).

The [Standstill time] parameter is entered in seconds. The permitted range is 0.00...2 s.

The time can be entered from 0.00 to 2.00 seconds, but makes up at least one measurement time.

[Standstill range]

As long as the weight fluctuations remain within this range, the device is determined to be stable. The [Standstill range] parameter is entered in "d." The permitted range is 0.01...10.00 d.

[Tare timeout]

Timeout for a tare/zeroset command that cannot be executed (e.g., due to mechanical instability of the scale, incorrect filter setting, resolution too high, standstill condition too strict).

This parameter is given in seconds. The permitted range is 0.0...<2.5>...25 s.

At 0.0 s taring is only carried out when the scale is already stable.

[Zeroset range]

Determine a ±range around the zero point determined by the dead load during calibration; within this range

- the displayed gross weight can be set to zero by pressing the zero-setting key (or by a corresponding external command), and
- automatic zero tracking is active.

Setting range: 0.00...10000.00 d

[Zerotrack]

The zero display is automatically maintained within set limits.

Possible values: no/yes

When "No" is selected, the next three parameters are not shown.

When "Yes" is selected values for the next three parameters must be entered.

[Zerotrack range]

Range within which the automatic zerotrack is balanced. Setting range: 0.25...10000.00 d

WP-A	Max	3000g	d=	2 g
→0← ► ⊿			0.0	9
	Weig	hing point		@admin
Zerotrack s	step	1		0.25 d
Zerotrack (ime .			1.0 s
Overload				50 d
Minimum W	eight			20 d
Range mode	2		sir	igle range
Default				Save

[Zerotrack step]

If a weight change exceeds the adjusted value, automatic tracking does not function any more. Setting range for automatic tracking increments: 0.25... 10 d

[Zerotrack time]

Time interval for automatic zero tracking. Setting range: 0.1...25 s

[Overload]

Weighing range above the maximum capacity (Max) without error message. Setting range: 0...99999999 d.

[Minimum weight]

Minimum weight at which a print command can be triggered. Setting range: 0...9999999 d.

[Range mode]

Possible values: single range, multiple range, multi-interval. For scale range selection, see Chapter 5.11.16.2.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.11.16.1 Operation in Legal Metrology

Note	The following settings are available; but the Maxxis 4 is not legal for trade!
------	---

Go to [System setup]-[Weighing point]-[Weighing point A]-[Parameters]-[W&M] and choose between: [none] and the legal metrology modes [OIML], [NTEP], or [NSC].

	[none]	[OIML]	[NTEP]	[NSC]
Gross weight display	В	В	G	G
Recommended min. measurement signals	0.2 mV/V @ 30,000 d	0.2 mV/V @ 3,000 e	0.2 mV/V @ 3,000 e	0.2 mV/V @ 3,000 e
	0.4 mV/V @ 60,000 d	0.4 mV/V @ 6,000 e	0.4 mV/V @ 6,000 e	0.4 mV/V @ 6,000 e

If operation for legal metrology is switched on, the parameter settings (zero tracking etc.) must be selected accordingly. The device does not carry out a check of this.

A unique check number is created every time a calibration or changed parameters are saved. This can be viewed under [System information]-[Show calibration check numbers] (see Chapter 5.20.7) and noted. See also Chapter 5.11.1.

5.11.16.2 Multiple Range Scale (Class III or single range scale Class I and II with variable interval)

The multiple range scale is a scale with two or more weighing ranges with different maximum capacities and scale intervals. There is only one load receptor, with each range covering zero to its maximum capacity. With [Range mode] = [Multiple range], the scale has up to three ranges with different resolution.

The weight display header includes the current range (R1, R2, and R3), Max, Min, and d (or e with instruments used in legal metrology) (Example: multiple range scale in range 2):

WP A	R2	Max	2000 kg	d=	
		Min	40 kg	e=	2 kg

The switch points [Range limit 1] and [Range limit 2] are the range limits. As soon as the gross weight exceeds range 1, the next highest range with the next highest interval becomes valid (1->2->5->10->20->50). When reducing the weight, the interval of the previous range is kept. When the gross weight is ≤ 0.25 d of range 1 and the scale is stable and not tared, the scale returns to range 1 with the corresponding interval.

Example

Range mode: Multiple range

Range 1: 0...1000 g (when calibrating set scale interval: 0.1 g)

Range 2: 0...2000 g (next highest scale interval: 0.2 g)

Range 3: 0...3000 g (next highest scale interval: 0.5 g)

WP-A	Max	3000g	d=	0.1g
→0← ►			0.0	g
.	Weig	hing point		@admin
Zerotrack	time			1.0 s
Overload				50 d
Minimum w	eight			20 d
🛛 Range mode	2		mul	tiple range
Range limit	1			1000.0 g
Range limit	2	127		2000.0 g
Default				Save

- Go to [System setup]-[Weighing point]-[Weighing point A]-[Parameters]-[W&M] and choose 'Range mode'.
- Select and confirm 'multiple range'.
- Set the switch point from range 1 to 2: enter '1000.0 g' for range limit 1.
- Set the switch point from range 2 to 3: enter '2000.0 g' for range limit 2.
- Save the settings.

5.11.16.3 Multi-interval Scale (Class III or single range scale Class I and II with variable interval)

The multi-interval scale is a scale with a weighing range that is divided into intervals. Each interval range has a different scale interval, where the weighing range is automatically switched depending on the load on the scale and also when the load is placed on/removed from the scale.

When [Range mode] = [Multi-interval], the scale has up to three ranges with different resolution. The weight display header includes the current interval range (R1, R2, or R3), Max, Min, and d (or e with instruments used in legal metrology) (Example: multi-interval scale in range 2):

WP-A	R2	Max	2000 kg	d=	
		Min	40 kg	e=	2 kg

The parameters [Range limit 1] and [Range limit 2] are the interval ranges. As soon as the gross weight exceeds range 1, the next highest range with the next highest interval becomes valid (1->2->5->10->20->50).

Note	During calibration, the multi-interval function is always switched off.
------	---

Example

Range mode: Multi-interval

Interval range 1: 0...1500 g (when calibrating set scale interval: 0.1 g)

Interval range 2: 1500...2900 g (next highest scale interval: 0.2 g)

WP-A	Max	3000g	d=	0.1g
→0← ►			0.0) g
	Weig	hing point		@admin
Zerotrack	time			1.0 s
Overload				50 d
Minimum w	eight			20 d
Range mod	2		m	ulti-interval
Range limit				1500.0 g
Range limit	2	1		2900.0 g
Default				Save

- Go to [System setup]-[Weighing point]-[Weighing point A]-[Parameters]-[W&M] and choose 'Range mode'.
- Select and confirm 'multi-interval'.
- Set interval range 1: enter '1500.0 g' for range limit 1.
- Set interval range 2: enter '2900.0 g' for range limit 2.
- Save the settings.


5.12 Configuring a xBPI Scale


5.12.1 General Information

The PR 5500 can communicate with scales (e.g., Combics1) or weighing modules via the xBPI protocol. The scale can be connected via serial interface (PR 5500/04; see Chapter 4.4.1). Communication is serial.

Note It's possible to use the internal weighing point or an IS platform without external power supply.

The determination and transmission of weight depends strongly on the scale/weighing module. Weight values up to seven digits plus preceding +/- sign can be displayed. The maximum capacity (Max) must be set in the scale or already set for a platform and cannot be changed via the xBPI protocol.





5.12.3 xBPI Parameter Input for Scale Function

The following parameters must be entered for this menu item:

- Timeout for tare function depending on the application
- SBN address for each xBPI scale, if bus operation is active
- Serial number of xBPI scale or weighing module, if used in legal metrology

WP-A	Max	12000g	d=	0.1g
			U.L	JU
419	11-1			
√∲ ¶		ghing point		<u>@admin</u>
Weighing poi	nt A		>	⟨BPI scale ►
Parameters	Calib	Units	Setup	
1 of officiers	28110	onics	JELOP	
WP-A	Max	12000g	d=	0.1g
WF-A	TIAX	120009		0.19
				7
			/	-
			U ./	Ч
410		ahina aaint		Qadmin
4 0		ghing point		
Weighing po				×BPI scale
Settings loci	Keu			none
Tare timeou	+			2.0 s
WP serial nu	-			2.0 3
SBN address				ŏ
Default				Save

▶ Press the [Paramet] soft key.

- \triangleright The following window appears.
- Enter and confirm the following parameters.

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[M&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

[Tare timeout]

Timeout for a zeroset or tare command to be executed. If the xBPI scale has not executed the command in the specified time, the action will be aborted.

Setting range: 0...9.9 s

[WP Serial number]

Serial number of the connected xBPI scale/weighing module. With serial number 0, checking is omitted. Setting range: 0...999999999

[SBN address]

When the address is not set to 0, bus operation is active. Possible addresses: 1 - 31, i.e., max. $31 \times BPI$ scales can be operated on an RS-485 branch. The SBN Address is shown on the display.

Example: Address 31 at WP-A

WP-A.31	Max	2000 kg	d=	2 kg
	Min	40 kg		

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.12.4 Setting up an xBPI Platform

WP-A	Max	12000g	d=	0.1g		Press the [Setup] soft key.
_			ΠΟ			
			U. 0	Q		
		ghing point		@admin		
Weighing poi	nt A		×E	IPI scale ▶		
Parameters	Calib	Units	Setup			
WP-A	Max	12000g	d=	0.1g	\triangleright	The PR 5500 is reading the parameters from the
			07	1		xBPI scale.
—				_	\triangleright	Ticks indicate the progress.
			U ./	y	\triangleright	An error message appears if communication with
₩		scale setup		<u>@</u> admin		the xBPI scale is not possible!
Reading pa read xBPI m	odel			V		
read xBPI m	-	ata		2 2		
read ×BPI se						
	······					
						TI 6 II
WP-A	Max	12000g	d=	0.1g	\triangleright	The following window appears.
			N 7			Select and confirm [Device information] using the
				0		cursor.
			U ./	9		
Configuratio		scale setup		<u>@</u> admin		
Select group	of specific	ations				
Device infor	mation	_	_	•		
WP-A	Max	12000g	d=	0.1g	⊳	The following window appears.
			\mathbf{n}			Change the user ID and SBN (see Chapter 5.12.3)
						if necessary.
			U ./	Q		Press the [Save] soft key to save the settings.
	×BPI	device info		 @admin	P	These are [surve] sole key to surve the settings.
Manufacture	er ID			RTORIUS		
Model name Version			151201	E -SOCE		
WP serial nu User ID	mber	A B		12809189 Operator1		
SBN		<u>s</u>		Uperator I 2		
				Save		

Configuration Select group Device inform	of specific	12000g da	.19 .79 (@admin		Note	sub	e following is required for the osequent specification group ection: Write down the model name of the scale. Write down the number of the corresponding specification block; this can be found in the operating instructions.
					Select and co using the cur		m [Select group of specifications]
WP-A Specification Specification Specification Specification Specification Specification	group group group group group	12000g d=	■ 0.1g 0.1g 0.1g 0 admin 0 admin 0 admin 0 0 0 0 admin 0 0 0 0 admin 0 0 0 0 admin 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	'spe	ecification blo eration (single Select and co group.	cks' rang onfir	ns have what is known as for selecting various modes of ge, multiple range, etc.) m the desired specification soft key to save the settings.
WP-A	of specific	12000g d=	.19 .7 .0.19 		Select and co cursor.	onfir	m [Configuration] using the
WP-A	Max	12000g d:	.7 g	•	the cursor.	par	m [Weighing parameters] using rameters are listed as an overview
		scale setup	@admin		Note		Only from the connected scale

[Weighing parameters] - Ambient conditions - Tare parameters Power-on zero range - very stable condition - At any time - Factory settings - Stable condition - Not until stable - 2 % of max. load - Unstable condition - 5 % of max. load - Very unstable condition - Auto zero function - 10 % of max. load – On - 20 % of max. load - Application/filter - Off - Standard mode Power-on tare/zero - Adjustment function - manual filling Active - automatic dosing - Ext.adj.w.fact.wt. Inactive - Check weighing - Ext.adj.w.user wt. - Only for zeroing - Ext.adj.w.pres.wt. - Standstill range Internal adjust - Measuring rate - 0.25 digit - Ext.lin.w.fact.wt. - Normal output - 0.5 digit - Ext.lin.w.user wt. - Fast output - 1 digits - Confirm preload/dead load - 2 digits - Delete preload/dead load Calibration check - 4 digits - Adjust disabled - No calibration prompt - 8 digits - Calibration prompt - Confirming adjustment - Stability symbol delay - automatically External Adjustment No delay - manual – enabled - disabled - Short delay - Average delay – Zero range - Long delay - 1 % of max. load Application Tare - 2 % of max. load enabled - 5 % of max. load disabled - 10 % of max. load Maximum capacity - Reduced by pre-/dead load Constant

WP-A	Max	12000g	d=	0.1g
_			0.7	, 9
- 4 ∯¶	xBPI weigt	ning paramete	ers	@admin
Calibration	check	Þ	Calibra	tion prompt
External A	djustment			Accessible
Application	1 Tare			Blocked
				Save


▶ Press the [Save] soft key to save the settings.

WP-A	Max	12000g	d=	0.1g
-			0.7	g
	×BPI	scale setup		<u>O</u> admin
	parameters			
Interface	parameters			Þ

Select and confirm [Interface parameters] using the cursor.

The interface parameters are listed as an overview in the following.

[Interface parameters]



WP-A	Max	12000g	d=	0.1g
-			0.7	, 9
- 4 ∯¶	×BPI inter	face paramet	ers	Qadmin
Communica	ition type	Þ	×	BPI protocol
Data outpu	t interval		each di	splay cycle
Parameters	s change		Can	be changed
				Save


▶ Press the [Save] soft key to save the settings.

5.12.5 Setting the xBPI Dead Load

5.12.5 Sett	ing the xBPI Dead I	Load		
Note	Both terms 'dead le	oad' and 'preload' ar	e us	ed by Sartorius.
WP-A	Max 12000g	d= 0.19 D.B g @admin xBPI scale >		Press the [Calib] soft key to calibrate the xBPI platform.
Parameters	Calib Units	Setup		
WP-A		d= 0.19].7 g @admin	$\land \land \land$	The PR 5500 is reading the parameters from the xBPI scale. Ticks indicate the progress. An error message appears if communication with the xBPI scale is not possible!
· · ·	· ·			
HP-A →O← Dead load Set Delete SPAN	Max 12000g	d= 0.1g D.O g @admin	Set	ting the Dead Load Remove the weight from the scale. Select and confirm [Set] using the cursor.
Adjust with u Adjust with a	ser weight utomatic weight			
WP-A →O← MET input	Max 12000g KBPI scale setup	d= 0.19),0 g @admin 0.0 g _0.01 g		After the command is sent, the gross weight display shows "0".
Accept Re:	set error Cancel			

Max

WP-A




5.12.6 xBPI Calibration with the User Weight

Requirements

- The xBPI protocol has been selected (see Chapter 5.12.2). _
- The 'xBPI scale' weighing point has been selected.
- The platform has been set up (see Chapter 5.12.4). _
- In menu [Weighing point A] 'manual' is set under [Configuration]-[Weighing parameters]-[Confirming adjustment] (see page 187).
- The communication between the device and platform is active. _

Procedure



Deleting the Dead Load

- Remove the weight from the scale.
- Select and confirm [Delete] using the cursor.

The stored dead load is deleted. The current dead load is shown on the weight display.

Select and confirm [Adjust with user weight] using the cursor.


WP-A Max 12000g d= 0.1g	An input window appears. The previously stored user weight is displayed.
→O← Enter user weight ②516.5 g Jmin De: Set De! SPAN Adjust with user weight Adjust with automatic weight	Change the weight value if necessary using the keyboard and confirm.
HP-A Max 12000g d= 0.1g	 The calibration process is carried out without a weight. The calibration status is displayed. Place the weight on the scale.
WP-A Max 12000g d= 0.1g Image: Constraint of the second sec	 The deviation is displayed in the last line with increased resolution (10-fold). Press the [Accept] soft key.
WP-A Max 12000g d= 0.1g + 25165 g **** xBPI scale setup @admin Calibration status complete 2516.5 g NET 2516.5 g input Reset error Cancel	 The data are saved and the instrument generates a corresponding message. The weight is displayed in the last line with increased resolution (10-fold). Remove the weight. Press the ESC/EXIT key to return to the previous window.


5.12.7 xBPI Calibration with Automatic Weight Detection

Requirements

- The xBPI protocol has been selected (see Chapter 5.12.2).
- The 'xBPI scale' weighing point has been selected.
- The platform has been set up (see Chapter 5.12.4).
- In menu [Weighing point A] 'manual' is set under
 [Configuration]-[Weighing parameters]-[Confirming adjustment] (see page 187).
- The communication between the device and platform is active.

Procedure





 Select and confirm [Adjust with automatic weight] using the cursor.

- The calibration process is carried out without a weight. The calibration status is displayed.
- \triangleright The value is specified automatically.

In this example, a weight of 10 kg is put onto the scale.

- The following window is displayed after applying the weight.
- The deviation is displayed in the last line with increased resolution (10-fold).
- Press the [Accept] soft key.


WP-A	Max	12000g	d=	0.1g
+	10		0.0) g
	×BPI s	cale setup		Qadmin
Calibration NET input	n status			complete 10000.0 g 9999.98 g
Accept	Reset error	Cancel		

5.12.8 xBPI Calibration with Default Weight

Requirements

- The xBPI protocol has been selected (see Chapter 5.12.2).
- The 'xBPI scale' weighing point has been selected.
- The platform has been set up (see Chapter 5.12.4).
- In menu [Weighing point A] 'manual' is set under [Configuration]-[Weighing parameters]-[Confirming adjustment] (see page 187).
- The communication between the device and platform is active.

Procedure



WP-A	Max	12000g	d=	0.1g
-	5	00	0.0) <u>^</u>
_ 4∲ ¶	×BPI	scale setup		Qadmin
Calibration input input	status		L	.oad to small -5000.0 g 0.00 g
Accept	Reset error	Cancel		

Select and confirm [Adjust with default weight] using the cursor.

▷ The data are saved and the instrument generates a

Press the ESC/EXIT key to return to the previous

 \triangleright The weight is displayed in the last line with

corresponding message.

Remove the weight.

window.

increased resolution (10-fold).

- ▷ The calibration process is carried out without a weight. The calibration status is displayed.
- Place the weight on the scale.


WP-A	Max	12000g	d=	0.1g
-			0.1	_∧ g
	×BPI s	cale setup		@admin
Calibratio input input	n status		Differ	ence display —0.1 g 4999.93 g
Accept	Reset error	Cancel		
WP-A	Max	12000g	d=	0.1g
+	5		0.0) _g
₩	×BPI s	cale setup		@admin
Calibratio NET input	n status			complete 5000.0 g 4999.99 g
Accept	Reset error	Cancel		

5.12.9 xBPI Calibration with Internal Weight

Requirements

- The xBPI protocol has been selected (see Chapter 5.12.2).
- The 'xBPI scale' weighing point has been selected.
- The platform has been set up (see Chapter 5.12.4).
- In menu [Weighing point A] 'manual' is set under [Configuration]-[Weighing parameters]-[Confirming adjustment] (see page 187).
- The communication between the device and platform is active.

Procedure



- ▷ The deviation is displayed in the last line with increased resolution (10-fold).
- Press the [Accept] soft key.

- ▷ The data are saved and the instrument generates a corresponding message.
- ▷ The weight is displayed in the last line with increased resolution (10-fold).
- Remove the weight.
- Press the ESC/EXIT key to return to the previous window.

Select and confirm [Adjust with internal weight] using the cursor.

WP-A	Max	??	d= -	??	\triangleright	The procedure is shown, e.g., with the following message:
No weight value						message.
₩ .	×BPI s	scale setup		@admin		
Calibratio	n status		Mot	or in motion		
input				0.00 g		
Accept	Reset error	Cancel				
WP-A	Max	12000g	d=	0.1g	\triangleright	The deviation is displayed in the last line with
→0← ► ⊿		(][) 🖄		increased resolution (10-fold). Press the [Accept] soft key.
₩ .		scale setup		Qadmin		
Calibratio input input	n status		Differ	ence display 0.0 g 1212.74 g		
Accept	Reset error	Cancel				
		10000			•	The data and the late in terms of a second s
WP-A	Max	12000g	<u> </u>	0.1g	⊳	The data are saved and the instrument generates a corresponding message.
→0←			JL	n	\triangleright	The weight is displayed in the last line with increased resolution (10-fold).
						Press the ESC/EXIT key to return to the previous
Calibratio NET input		scale setup		@admin complete 0.0 g 0.02 g		window.
Accept	Reset error	Cancel				

5.12.10 xBPI Linearization

The measurement range for a straight can be optimized by setting the linearization points. The following describes standard linearization.

0.1g

L

🖸 admin

0.0 g 2000.02 g


Difference display

A

Requirements

- The xBPI protocol has been selected (see Chapter 5.12.2).
- The 'xBPI scale' weighing point has been selected.
- The platform has been set up (see Chapter 5.12.4).
- In menu [Weighing point A] 'manual' is set under [Configuration]-[Weighing parameters]-[Confirming adjustment] (see page 187).
- The communication between the device and platform is active.

Procedure



Cancel

xBPI scale setup

12000g

Reset error

Max

Accept Reset error Cancel

Accept

WP-A

→0←

input


inout

Calibration status

Select and confirm [Default linearisation] using the cursor.

- The first linearization point to be calibrated is displayed.
 - Place the corresponding weight (in this case, 2 kg) on the scale.

- ▷ The deviation is displayed in the last line with increased resolution (10-fold).
- Press the [Accept] soft key.



5.12.11 xBPI Display Units

The device is calibrated with a selected weight unit.

WP-A	Max	12000g	d=	0.1g
_			0.8	} g
· 4 산 립		ghing point		@admin
Weighing po	pint A			×8PI scale ≯
Parameters	Calib	Units	Setup	
WP-A	Max	12000g	d=	0.1g
→0← ►			0.0) _g
. 4∲ ¶	×BPI applic	ation parame	ters	@admin
Number of	units	Þ	1	weight unit
Unit 1	Display acc	Gram Suracy	bas	g vic accuracy
		· · ·		Save

Go to the menu [System setup]-[Weighing point]-[Weighing point A] and press the [Units] soft key to select additional units and the associated display accuracy; see Chapter 5.10.16.

[Number of units] see Chapter 5.10.16

[Unit] see Chapter 5.10.16

[Display accuracy] see Chapter 5.10.16

[Save] The settings are saved.

5.13 Setting the SBI Scale

5.13.1 General Information

The PR 5500 can communicate with scales (e.g., Combics1) or weighing modules via the SBI protocol. The scale can be connected via serial interface (PR 5500/04; see Chapter 4.4.1). Communication is serial. There are no variables or digital I/Os for external scales in the SPM of the PR 5500.

5.13.2 Parameter for Serial Interface

▶ Go to [System setup]-[Weighing points] [Weighing point A], select and confirm 'SBI scale'.

	Weighing point A	@admin	
Weighing point	•	SBI scale	
Interface		Option-1 RS-485-A	
Baudrate		9600 baud	
Data bits		8 data bits	
Parity		odd parity	
Stop bits		1 stop bit	
Default	• •	Save	

>	A selection window appears.
	Unavailable interfaces are grayed out.
	Select and confirm the individual settings.
	[Interface]
	serial interfaces
	Selection:
	not assigned, Built-in RS-232, Built-in RS-485,

Option-x RS-485-A, Option-x RS-485-B

[Baudrate]

Modulation rate for data transmission.

Note The selected value must match the value of the connected device (e.g. Combics1).

Selection:

300, 600, 1200, 2400, 4800, <9600>, 19200 baud

[Data bits]

Groups of data bits. Selection: 7 data bits, <8 data bits>

[Parity]

Parity check for detecting errors during data transmission. Selection: no parity, odd parity, even parity

[Stop bits]

Units for transmission protocols. Selection: 1 stop bit, <2 stop bits>

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.13.3 Parametereingabe

WP-A	Max	??	d=	??
r	io va	lues from	scale	•
ৰকুন্ধ	L	Jeighing point		Qadmin
Weighing poi		teigining point		SBI scale
Settings lock				
M&M				none
Max				1000 kg
Scale interva	I			1
🛛 Minimum weig	ght			b 0
Default				Save

Access the menu as follows: [System setup]-[Weighing points]-[Weighing point x]-[Param].

Select and confirm the individual settings.

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[W&M]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

Maximum Capacity [Max]

See Chapter 5.11.5.

[Scale interval]

See Chapter 5.11.6.

[Minimum weight]

Minimum weight at which a print command can be triggered. Setting range: 0...99999999 d. For use in legal metrology a value of at least 20 d must be set.

[Update time]

Timeframe in which a new weight value is displayed. Setting range: 0.1...2.0 s.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.14 Calibrating Digital Weighbridge Load Cell ,Pendeo® Truck'

5.14.1 General Information

The digital load cells have been calibrated at the factory based on the acceleration of gravity at Hamburg, Germany: 9.81379 m/s². The calibration data in the load cells are invariable. The calibration data for the gravity acceleration at the place of installation can be adapted only in the instrument and protected against overwriting (see Chapter 5.1.5). With applications for use in legal metrology, the legal requirements and the conditions given on the test/approval certificate must be taken into account when selecting the settings.

5.14.2 Parameter Input for Serial Interface

WP-A		100t 0.5 hing point Units	d= 17	0.001t t @admin eo Truck >	Go to [System setup]-[Weighing points] [Weighing point A], select and confirm 'Pendeo Truck'.
Heighing poin Interface Baudrate Data bits Parity Stop bits		ing point A		@admin indeo Truck I RS-485-A 19200 baud 8 data bits odd parity 1 stop bit	The following window appears. Select and confirm the line 'Interface'.
eta not assigne Built-in RS- Option-1 RS Option-1 RS	2d -232 5-485-A	ing goint A		Dadari	The following window appears. Select and confirm the RS-485 interface (in this case: Option-1 RS-485-A). The previous window appears. Press the [Save] soft key to save the changes.

5.14.3 Calibration Sequence

During calibration, no data is changed in the digital load cells. The calibration data and parameters are saved in the instrument. The unique serial numbers of the connected load cells are monitored. The number of platforms greatly influences how calibration is carried out.


For the adjustment is the following order specified:

- Search for load cells and set dead load, see Chapter 5.14.4 or
- only search for load cells, see Chapter 5.14.5
- Assign load cells, see Chapter 5.14.6
- Calibrate 'New': Max with weight unit, scale interval, dead load, calibration weight, see Chapter 5.14.7
- Carry out a corner correction if necessary, see Chapter 5.14.10

Note For further information about calibrating weighing points, see Chapter 5.11.

5.14.4 Search for load cells and set dead load


Access the menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].



- ► Unload the scale.
 - Select and confirm the first menu item.



- \triangleright A prompt window appears.
- Press the [Continue] soft key to start the search process.
- Press the [Cancel] soft key to return to the Pendeo setup menu.



An input window appears.

- Change the default value, if necessary and press the [Ok] soft key, um die Eingabe zu bestätigen.
- Press the [Cancel] soft key, if necessary to return to the Pendeo setup menu.
- ▷ Search process is started and dead load is set.


WP-A	Max	99t	d=	0.01t		
+0←	ПГ	INN				
	U.L	JUU		t		
₩ .	Weighi	ing point		@admin		
Setup Per	ndeo					
Quick inst	all with search	load cells a	and set dea	ed load 🔹 🕨		
Search for	connected load	d cells				
	assign load cell:	5				
Calibrate the scale						
Assign load cell name						
Service function for load cells						

▷ After determining the Pendeo setup menu appears.


5.14.5 Search for Load Cells


The following example shows a platform with four load cells.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].



Select and confirm the menu item 'Search for connected load cells'.





- \triangleright A prompt window appears.
 - Press the [Continue] soft key to start the search process.

0r

- Press the [Cancel] soft key to return to the Pendeo setup menu.
- \triangleright Search process is started.
- \triangleright A progress window appears.

+ O.520 t Weighing point Order of the search load cells and set dead load Search for connected load cells and set dead load Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name Service function for load cells		Max	100t	d=	0.01t		
Setup Pendeo Quick install with search load cells and set dead load Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name	+	0.52	20		t		
Quick install with search load cells and set dead load Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name		Weighing p	oint		@admin		
Calibrate the scale Assign load cell name	Quick install with search load cells and set dead load						
	View and assign load cells Calibrate the scale						


After determining the Pendeo setup menu appears.

5.14.6 View and Assign Load Cells

The load cells (serial number) can be assigned to the place of installation in this menu. This is important for correcting the dead load (distribution to the individual load cells), for corner correction and in the event of load cell replacement.

Note The assignment from the installation should be documented in the case of load cells being replaced.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib]-[View].



Select and confirm the menu item 'View and assign load cells'.

The load cells are displayed with their item

[Info] soft key, to display the load cell data.

Select the desired line, if necessary and press the

Press the ESC/EXIT key to return to the previous

If load cell names have been

assigned (see Chapter 5.17.9), the view can be switched with

the soft key [by name].


window.

5.14.6.1 View Load Cells

+	0.51	0	t	The load cells ar number, serial n	umber, and load
▲ ♥● LC 1	View	204	@admin 0.541 t	Select the desire [Info] soft key, t	
LC 2 LC 3 LC 4		201 203 202	-0.163 t -0.349 t 0.484 t	Note	If load cell na assigned (see the view can b the soft key [b
Info	Assign	by name	Accept		
+	0.51	0	t	The following w Press the ESC/EX	

< ∲ ¶	Load cell info	@admin
Model name		PR6224/25tC3
Software version		01.00.04
LC serial number		203
Emax		25.0 t
n		3000 e
Y		14000
Z		3000
Overload		37.5 t
Overload counter		0

5.14.6.2 Assign Load Cells



- Unload the scale.
- Press the [Assign] soft key.


- \triangleright You are prompted to confirm.
- Press the [Continue] soft key.

<u>+</u>	11.12	20	t
- ∢ ∲¶	Viev	4	@admin
LC 1		204	2.142 t O
LC 2		201	3.739 t 1
LC 3		203	1.239 t O
LC 4		202	4.003 t O
Info	Assign	by name	Accept


The load cells are assigned by placing minimum weights on the scale.


- Place the weight on the corner/load cell which will be assigned no. 1.
- ▷ As soon as the device detects the weight change, the corresponding line is selected.
- Press the [Accept] soft key.
- ▷ The future LC no. appears at the far right of the line.
- Remove the calibration weight.
- ▶ Repeat these steps for load cells 2–4.
- Press the [Save] soft key to save the new assignment.

An example of a possible assignment is shown on the left.



3





	Max	100t	d=	0.01t		
+	5.8	10		t		
	Weighing	g point		<u>@</u> admin		
Setup Pendeo Quick install with search load cells and set dead load Search for connected load cells View and assign load cells						
Calibrate the scale Assign load cell name Service function for load cells						

- ▷ The Pendeo setup menu appears.
- Select and confirm the menu item 'View and assign load cells'.

+	5.8	310	t	
₩	1	View	@admin	
LC 1		201	1.158 t	
LC 2		202	2.138 t	
LC 3		203	1.137 t	
LC 4		204	1.373 t	
Info	Assign	by name	Accept	

- \triangleright The new assignment will be displayed.
- Check the corner load (dead load), see Chapter 5.14.10.1.
- Press the ESC/EXIT key to return to the previous window.


5.14.7 Calibrating Load Cells

Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].

Example

Max. load cell capacity: $E_{max} = 50 t$ Number of load cells: 4 Max: 200.000 t Scale interval: 0.020 t Dead load: empty weight Calibration weight: 11.000 t

Procedure




 Select and confirm the menu item 'Calibrate the scale'.

Press the [New] soft key.

Note	The menu item 'Modify' is only used for small changes (e.g., changing the dead load/ preload).
	Otherwise selected 'New'.

New


Modify



t Calibration Local gravity Max Calibration Local gravity Max Scale interval Calibration weight Corner correction Conterval Calibration conterval Calibration conterval Conterval Calibration conterval Calibration c	 The empty scale (deck installed on a vehicle scale, no load) for dead load: Unload the scale, if necessary. Press the [by load] soft key. Confirm. The confirmation is displayed with 'setting dead load'.
Platform 1 by load by value Save	Note If the dead load is known, the value can be overwritten by pressing [by value].
Max 200t d= 0.02t → □ ← 0.0000 t ← Calibration @admin Local gravity 9.81379 m/s ² Max 10000 d 200.000 t Scale interval 1 d 0.020 t Dead load 5.806 t Calibration weight Corner correction	Confirm the selection.
Platform 1 Save	 An input window appears. Center the calibration weight on the scale and enter the weight value. Press the [OK] soft key. Remove the calibration weight.
Max 2001 d= 0.021 +0+ 0.0000 t Calibration @admin Local gravity 9.81379 m/s ² Max 10000 d 200.000 t Scale interval 1 d 0.020 t Dead load 5.806 t Calibration weight 5.000 t Corner correction	 The corner load (dead load set to zero) is displayed. Carry out a corner correction if necessary, see Chapter 5.14.10. Press the [Save] soft key to save the calibration.

5.14.8 Assign Load Cell Name

In this menu the load cells can also be assigned names in addition to the LC no. and serial numbers. Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].



Select and confirm the menu item 'Assign load cell name'.

- \triangleright An input window appears.
- Select the line, enter the name using the keyboard and confirm.
- ▶ Repeat these steps for load cells 2-4.
- ▶ Press the [Save] soft key to save the entries.

5.14.9 Service Function

In this menu faulty load cells can be deactivated and replaced load cells activated. Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].

	O.OOO Weighing point		t @admin			
Setup Pendeo			@admin			
	1					
Setup Pendeo Quick install with search load cells and set dead load Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name Service function for load cells						

+0+ ⊾					
⊲∲ ¶	Si	ervice	<u>@</u> admin		
LC 1 LC 2 LC 3 LC 4	201 202 203 204	1.156 t 2.142 t 1.133 t 1.376 t	1.156 t ∅ 2.141 t ∅ 1.134 t ∅ 1.375 t ∅		
		Accept	•		

Select and confirm the menu item 'Service function for defect load cells'.

 \triangleright The service window appears.

The load cells are displayed with their item number, serial number, dead load and current load.

5.14.9.1 Deactivate Load Cell

+	0.0]20	∆ t		 Select and confirm the defect load cell to deactivate. Press the [Accept] soft key. 	
▲ LC 1 LC 2 LC 3	201 202 203	ervice 1.156 t 2.142 t 1.133 t	0admin 1.159 t ₪ 2.138 t ₪ 1.138 t ₪	 Press the [Accept] soft key. The warning symbol replaces the weight unit. simulation for the deactivated load cell is star 		bol replaces the weight unit. The
LC 4 dea	ctivated	1.376 t Accept	0.004 t 🗆		Note	Trucks should only be allowed to move onto the center of the weighing platform, in order to distribute the weight evenly.

5.14.9.2 Activate Load Cell

Max

→0← ► ⊿	0.0	300	∆ t
4 ∲¶	S	ervice	@admin
LC 1	201	1.156 t	1.161 t ⊠
LC 2	202	2.142 t	2.137 t ⊠
LC 3	203	1.133 t	1.139 t 🗵
LC 4	204	1.376 t	0.006 t 🗹
		Accent	

▶ After inserting and connecting the new load cell,

select the line of the deactivated load cell and confirm.

▶ Press the [Accept] soft key.

- -77 . Ó **4**∲¶ dmin Set Qui Sea Vie searching for load cells... Cal 4 Load cells found As Ser
- ⇒o⇔ t **N** 4 **4**∲¶ @admin Service LC 1 201 1.160 t ⊠ 1.156 t LC 2 LC 3 202 2.142 t 2.138 t ⊠ 1.137 t ₪ 203 1.133 t LC 4 204 1.376 t 1.372 t 🗵 Accept

 \triangleright A search process is started.

 \triangleright Only then the new load cell is detected.

5.14.10 Corner Correction


5.14.10.1 Checking Corner Load (Dead Load)

After assignment and calibration, the load cell positions have been defined clearly.

5.14.10.2 Mechanical Corner Correction

A mechanical corner correction must carry out if the load on the load cells is not evenly distributed, e.g when the platform wobbles. Now the individual dead load on the load cells can be corrected using shims. If two coupled platforms are connected, corner load checking or installation of shims for the platforms must be performed independently.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Calib].



Select and confirm the menu item 'View and assign load cells'.

+0 ←	0.00]0	t
. 4∲]	View	1	@admin
LC 1		201	1.159 t
LC 2		202	2.125 t
LC 3		203	1.141 t
LC 4		204	1.364 t
Info	Assign	by name	Accept

- The load cells are displayed with their item number, serial number, and load.
- In this example, the load on a load cell doesn't need to be increased by a shim.
- A fine correction can be conducted with a software corner correction, see Chapter 5.14.10.3.
- Press the ESC/EXIT key to return to the previous window.

5.14.10.3 Software Corner Correction

If the corners are loaded in succession, the same value should be displayed on the device at all times. An excessive deviation almost always means that the scale is tilted or indicates load cell force shunts.

If the signal deviations cannot be resolved by carefully leveling the scale, the software must be calibrated.

0.02t

Access the menu as follows:

[System setup]-[Weighing point]-[Weighing point A]-[Calib]-[Calibrate the scale]-[Modify].


1	U.UZU	t	Press
√ ↑ ← ↓ ↓ Coal gravity Max Scale interval Dead load Calibration weigh Corner correction		@admin 9.81379 m/s² 200.000 t 0.020 t 5.806 t 5.000 t	
Platform 1	· · ·	Save	
+ ↓ </td <td>5.020 Corner correction</td> <td>t @admin 2.655 t 2 1.936 t = 0.038 t = 0.667 t =</td> <td>Set th The po Confin Remo Repea any do</td>	5.020 Corner correction	t @admin 2.655 t 2 1.936 t = 0.038 t = 0.667 t =	Set th The po Confin Remo Repea any do
· · · · · · · · · · · · · · · · · · ·	Calc		
	5.000 Corner correction	t 0.810 t ⊄ 0.746 t ⊄ 2.059 t ⊄ 1.664 t ⊄	lf all I the [C
	Calc	*	
WP-A Ma Mi Corner correction	D.041	0.021	The to effect When with ' Press correc
Platform 1		Save	

- Select 'Corner correction'.
- Press the [Platform 1] soft key.

- Set the calibration weight on a corner.
- The position (in this case, LC 1) is selected.
- Confirm the position.
- Remove the calibration weight.
- Repeat these steps for the remaining load cells in any desired order.
- If all load cells have been loaded one time, press the [Calc] soft key to carry out corner correction.

- The total weight remains unchanged. Only the effect of the individual load cells is corrected.
- When corner correction is completed, it is marked with 'correction ok'.
- Press the [Save] soft key to save the corner correction.

5.14.11 Parameter input



Access the menu as follows: [System setup]-[Weighing point]-[Weighing point A]-[Param].

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[M&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

[Ambient conditions]

This parameter is used to define the ambient conditions of the scale.

Possible values: very stable condition, Stable condition, Unstable condition, Very unstable condition

[Detect a defect load cell]

Select this parameter and confirm if max. simulation of a faulty load cell should be automatic. A warning symbol is displayed for the duration of the load cell simulation.

[Unbalanced check deviation]

The plausibility check is activated when the average deviation is >0%.

The average deviation of the individual load cells is calculated. The process is displayed using a symbol above the weight unit.

Setting range: 0-100%

[Standstill time]

The parameters [Standstill time] and [Standstill range] can be used to define the stability of the scale (stable balance).

The [Standstill time] parameter is entered in seconds. The permitted range is 0.00-2 s.

The time can be entered from 0.00 to 2.00 seconds, but makes up at least one measurement time.

WP-A	Max	200t	d=	0.02t
		0.0] _t
- 4∲ ¶	Weig	hing point		@admin
Standstill ra	ange	1		1.00 d
Tare timeo	Jt			2.5 s
Zeroset rai	nge			50.00 d
Zerotrack				Yes
Zerotrack (ange			0.25 d
Zerotrack s	step			0.25 d
Default				Save

[Standstill range]

As long as the weight fluctuations remain within this range, the device is determined to be stable.

The [Standstill range] parameter is entered in "d." The permitted range is 0.01-10.00 d.

[Tare timeout]

Timeout for a tare/zeroset command that cannot be executed (e.g., due to mechanical instability of the scale, incorrect filter setting, resolution too high, standstill condition too strict).

This parameter is given in seconds. The permitted range is 0.0-<2.5>-25 s.

At 0.0 s taring is only carried out when the scale is already stable.

[Zeroset range]

Determine a ±range around the zero point determined by the dead load during calibration; within this range

- the displayed gross weight can be set to zero by pressing the zero-setting key (or by a corresponding external command), and
- automatic zero tracking is active.

Setting range: 0.00-10000.00 d

[Zerotrack]

The zero display is automatically maintained within set limits.

Possible values: no/yes

When "No" is selected, the next three parameters are not shown.

When "Yes" is selected values for the next three parameters must be entered.

[Zerotrack range]

Range within which the automatic zerotrack is balanced. Setting range: 0.25-10000.00 d

[Zerotrack step]

If a weight change exceeds the adjusted value, automatic tracking does not function any more. Setting range for automatic tracking increments: 0.25... 10 d

WP-A	Max	200t	d=	0.02t
		0.0] _t
	Weig	hing point		@admin
Zerotrack	time	1		1.0 s
Overload				9 d
Minimum 🖌	veight			20 d
Range mod	le			single range
Default				Save

[Zerotrack time]

Time interval for automatic zero tracking. Setting range: 0.0-25 s At 0.0 s the tracking is switched off.

[Overload]

Weighing range above the maximum capacity (Max) without error message. Setting range: 0-99999999 d.

[Minimum weight]

Minimum weight at which a print command can be triggered. Setting range: 0-9999999 d.

[Range mode]

Possible values: single range, multiple range, multi-interval. For scale range selection, see Chapter 5.11.16.2.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.14.12 Subsequent Dead Load Correction

If the platform weight changes by an amount that is higher than the zero-setting range, e.g., due to dead load reduction, dead load increase, or mechanical changes, the functions for automatic zero tracking and manual zero setting no longer work.

If the entire zero-setting range is already utilized, you can still correct the dead load without affecting other calibration data/parameters.

Access the menu as follows:

[System setup]-[Weighing point]-[Weighing point A]-[Calib]-[Calibrate the scale]-[Modify].

WP-A	Max	200t	d=	0.02t
	0.	000		t
	Ca	alibration		@admin
Local gravity Max Scale interval Dead load Calibration wei Corner correct		100	DD d 1 d	9.81379 m/s ² 200.000 t 0.020 t 5.806 t 5.000 t correction ok
Platform 1		by load	by valu	ie Save

The scale must be empty (deck installed on a vehicle scale, no load).


- Select 'Dead load'.
- Confirm the dead load (\sum corner load).
- Check the corner load, see Chapter 5.14.10.1.
- Carry out a corner correction if necessary, see Chapter 5.14.10.
- Press the [Save] soft key to save the current dead load.

5.15 Calibrating Digital Precision Compression Load Cell 'Pendeo® Process'

5.15.1 General Information

The digital load cells have been calibrated at the factory based on the acceleration of gravity at Hamburg, Germany: 9.81379 m/s². The calibration data in the load cells are invariable. The calibration data for the gravity acceleration at the place of installation can be adapted only in the instrument and protected against overwriting (see Chapter 5.1.5). With applications for use in legal metrology, the legal requirements and the conditions given on the test/approval certificate must be taken into account when selecting the settings.

5.15.2 Parameter Input for Serial Interface



5.15.3 Calibration Sequence

During calibration, no data is changed in the digital load cells. The calibration data and parameters are saved in the instrument. The unique serial numbers of the connected load cells are monitored.


For the adjustment is the following order specified:

- Search for load cells and set dead load, see Chapter 5.15.4 or
- only search for load cells, see Chapter 5.15.5
- Assign load cells, see Chapter 5.15.6
- Calibrate 'New': Max with weight unit, scale interval, dead load, calibration weight, see Chapter 5.15.7

Note For further information about calibrating weighing points, see Chapter 5.11.

5.15.4 Search for load cells and set dead load

Access the menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib].



Unload the scale.

- A prompt window appears.
- Press the [Continue] soft key to start the search process.

Select and confirm the first menu item.

Or

- Press the [Cancel] soft key to return to the Pendeo setup menu.
- + t 1 @admin **4‡**¶ Weighing Setup Pendeo Qui Enter local gravity Sea Vie 9.81379 m/s² Cal As Ser Ok Cancel
- \triangleright An input window appears.
 - Change the default value, if necessary and press the [Ok] soft key, um die Eingabe zu bestätigen.
 - Press the [Cancel] soft key, if necessary to return to the Pendeo setup menu.
 - ▷ Search process is started and dead load is set.


WP-A	Max	17t	d=	0.005t
+0+ ► 4	0.0			t
. ∢ ∲ ¶	Weighi	ng point		@admin
Setup Pe	endeo			
	stall with search l		and set de	ad load 🔹 🕨
	or connected load			
	d assign load cells	;		
Calibrate the scale				
Assign load cell name				
Service function for load cells				

After determining the Pendeo setup menu appears.

5.15.5 Search for Load Cells


The following example shows a vessel with four load cells and four vessel feet.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib].



Select and confirm the menu item 'Search for connected load cells'.

WP-A	Max	17t	d=	0.005t
→□←	0.0			t
∢ ¶ Set		?		dmin
Qui — Sea Vie Cal As	Search for c The actual settin			
Ser _	Cancel		Continue	—



- \triangleright A prompt window appears.
- Press the [Continue] soft key to start the search process.

Or

- Press the [Cancel] soft key to return to the Pendeo setup menu.
- ▷ Search process is started.
- ▷ A progress window appears.

WP-A	Max	20t	d=	0.005t
+	2.8	345		t
. ∢ ∲]	Weighi	ing point		Qadmin
Setup Pendeo Quick install with search load cells and set dead load				
Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name Service function for load cells				


▷ After determining the Pendeo setup menu appears.

5.15.6 View and Assign Load Cells

The load cells (serial number) can be assigned to the place of installation in this menu. This is important for correcting the dead load (distribution to the individual load cells), for corner correction and in the event of load cell replacement.


Note The assignment from the installation should be documented in the case of load cells being replaced.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib]-[View].




Select and confirm the menu item 'View and assign load cells'.

5.15.6.1 View Load Cells



- ▷ The load cells are displayed with their item number, serial number, and load.
- Select the desired line, if necessary and press the [Info] soft key, to display the load cell data.

Note	If load cell names have been assigned (see Chapter 5.18.9), the view can be switched with
	the soft key [by name].



- ▷ The following window appears.
 - Press the ESC/EXIT key to return to the previous window.

5.15.6.2 Assign Load Cells

+	2.	845	t
 4‡₽ 		View	@admin
LC 1		301	0.646 t
LC 2		303	0.798 t
LC 3		304	0.651 t
LC 4		302	0.753 t
Info	Assign	by name	Accept



▷ You are prompted to confirm.

Unload the scale.


Press the [Assign] soft key.

Press the [Continue] soft key.

<u>+</u>	5.01	5	t
	View		@admin
LC 1 LC 2 LC 3 LC 4		301 303 304 302	1.481 t 1 1.033 t 0 1.272 t 0 1.229 t 0
Info	Assign	by name	Accept

The load cells are assigned by placing minimum weights on the scale.

- Place the weight on the corner/load cell which will be assigned no. 1.
- ▷ As soon as the device detects the weight change, the corresponding line is selected.
- Press the [Accept] soft key.
- ▷ The future LC no. appears at the far right of the line.
- Remove the calibration weight.
- ▶ Repeat these steps for load cells 2–4.
- Press the [Save] soft key to save the new assignment.



		20t	d=	0.005t
+	2.8	15		t
₩ .	Weighing	point		@admin
Setup Pendeo Quick install with search load cells and set dead load Search for connected load cells				
Calibrate t Assign loa	Search for connected load cells View and assign load cells Calibrate the scale Assign load cell name Service function for load cells			

<u>+</u>	2.8	45	t
< 4 ∲ 9	Vie	м	@admin
LC 1		301	0.674 t
LC 2		302	0.737 t
LC 3		303	0.788 t
LC 4		304	0.645 t
Info	Assign	by name	Accept

An example of a possible assignment is shown on the left.

- ▷ The Pendeo setup menu appears.
- Select and confirm the menu item 'View and assign load cells'.

- \triangleright The new assignment will be displayed.
- Check the corner load (dead load), see Chapter 5.15.10.2.
- Press the ESC/EXIT key to return to the previous window.


5.15.7 Calibrating Load Cells

Access the Pendeo setup menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib].

Example

Max. load cell capacity: $E_{max} = 5 t$ Number of load cells: 4 Number of vessel feet: 4 Max: 20.000 t Scale interval: 0.020 t Dead load: empty weight Calibration weight: 5.000 t

Procedure



Max	: 20t	d=	0.005t
<u>+</u>	2.845		t
	Calibration		<u>@</u> admin
Number of vesse Local gravity Max Scale interval Dead load Calibration weight Corner correction	4000 1) d d	4 9.81379 m/s² 20.000 t 0.005 t 0.000 t
New Modi	fy		



Select and confirm the menu item 'Calibrate the scale'.

Press the [New] soft key.

Note	The menu item 'Modify' is only used for small changes (e.g., changing the dead load/ preload). Otherwise selected 'New'.

> A prompt window appears.

Press the [Yes] soft key.

↓ Image: Antiper of Vesse Local gravity Max Scale interval Dead load Calibration weig Corner correction Vessel	4000 d 1 d	0.005t t @admin 4 9.81379 m/s² 20.000 t 0.005 t Save	Select the line ,Number of vessel feet', change if necessary and confirm.
H Number of vess Local gravity Max Scale interval Dead load Calibration weig Corner correctio Vessel	4000 d 1 d	0.005t t @admin 4 9.81379 m/s² 20.000 t 0.005 t	Select the line ,Local gravity', change if necessary and confirm.
↓ ↓Vertion Number of vesse Local gravity Max Scale interval Dead load Calibration weig Corner correction Vessel	4000 d 1 d	0.005t t ©admin 4 9.81379 ⊞unit 20.000 t 0.005 t Save	 Enter the maximum capacity with decimal places (in this example: 20.000 t). Double-click on the toggle key
Mumber of vess Local gravity Max Scale interval Dead load Calibration weig Corner correction Vessel	4000 d 1 d M	0.005t t @admin 4 9.81379 m/s² 20.000 t 0.005 t	 The weight unit is taken from [Max]. The number of digits behind the decimal point is also automatically determined when [Max] is entered. Select the scale interval (1 d). The scale interval (d) is then calculated, based on the Max weight value. Confirm the entries. The confirmation is displayed with 'setting scale interval'.

Max 20t d= 0.002t + 2.8944 t Calibration @admin Number of vessel feet 4 Local gravity 9.81379 m/s² Max 10000 d Scale interval 1 d Dead load Calibration weight Corner correction	 An empty vessel for dead load: Unload the scale. Press the [by load] soft key. Confirm. The confirmation is displayed with 'setting dead load'. Note If the dead load is known, the value can be overwritten by pressing [by value].
Max 20t d= 0.002t Calibration Number of vessel feet Local gravity Max Max 10000 d Scale interval Dead load Calibration Local gravity Max Calibration Concer Calibration Calibration Concer	Confirm the selection.
Vessel Save Max 20t d= 0.002t + 2.1666 t + Calibration Oadmin Number of vessel feet 4 Local oravity 9.81379 m/s ² Ma place CAL weight 00 t Sc: 0n the scale and 02 t enter value. Ebunit t Cor Vt Ok Cancel e	 An input window appears. Center the calibration weight on the scale and enter the weight value. Press the [OK] soft key. Remove the calibration weight.
Max 20t d= 0.002t Image: constraint of the system the system the system Number of vessel feet 4 Calibration O admin Number of vessel feet 4 Saturation Saturation Number of vessel feet 4 Calibration Saturation Max 10000 d 20.000 t Scale interval 1 d 0.002 t Dead load 2.845 t 2.000 t Corner correction Save	 The corner load (dead load set to zero) is displayed. Carry out a corner correction if necessary, see Chapter 5.15.10. Press the [Save] soft key to save the calibration.

5.15.8 Assign Load Cell Name

In this menu the load cells can also be assigned names in addition to the LC no. and serial numbers. Access the Pendeo setup menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib].

	Max 20t d=	0.002t
+0+ ► 4	0.000	t
4 0	Weighing point	@admin
Search for (View and as Calibrate th	l with search load cells and set connected load cells ssign load cells e scale	dead load
Assign load Service fun	cell name ction for load cells	
→0+ ► 4	0.000	t
₩	Load cell name	@®ABC
LC 1	301	PR 6204–RU
LC 2	302	
LC 3 LC 4	303 304	
	304	
Default		Save

Select and confirm the menu item 'Assign load cell name'.

- \triangleright An input window appears.
- Select the line, enter the name using the keyboard and confirm.
- ▶ Repeat these steps for load cells 2-4.
- ▶ Press the [Save] soft key to save the entries.

5.15.9 Service Function

In this menu faulty load cells can be deactivated and replaced load cells activated.

Access the Pendeo setup menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Calib].

	Max	20t	d=	0.002t
→0+ ► 4	0.0	00		t
	Weighir	ng point		@admin
Search for View and a Calibrate t Assign loa	all with search l connected load assign load cells he scale d cell name	cells	and set de	2ad load
Service fu	nction for load (cells		

+0+ ► 4	(t	
₩ ‡¶		Service	@admin
LC 1	301	0.672 t	0.737 t ⊠
LC 2	302	0.740 t	0.704 t ⊠
LC 3	303	0.785 t	0.762 t ⊠
LC 4	304	0.648 t	0.642 t ⊠
		Accept	

Select and confirm the menu item 'Service function for defect load cells'.

The service window appears. The load cells are displayed with their item number, serial number, dead load and current load.


5.15.9.1 Deactivate Load Cell

+		3.010	∆ t	
⊲ ‡¶		Service	@admin	
LC	1 301	0.672 t	0.738 t ⊠	[
LC	2 302	0.740 t	0.703 t 🗵	
LC	3 303	0.785 t	0.763 t ⊠	
LC	4 deactivated	0.648 t	0.002 t 🗆	
		Accept		


Select and confirm the defect load cell to deactivate.

- Press the [Accept] soft key.
- The warning symbol replaces the weight unit. The simulation for the deactivated load cell is started.

5.15.9.2 Activate Load Cell



- After inserting and connecting the new load cell, select the line of the deactivated load cell and confirm.
- ▶ Press the [Accept] soft key.



 \triangleright A search process is started.

+0+ ► -	0.0	300	t
₩ .	S	ervice	@admin
LC 1	301	0.672 t	0.730 t 🗵
LC 2	302	0.740 t	0.711 t ⊠
LC 3	303	0.785 t	0.756 t ⊠
LC 4	304	0.648 t	0.648 t ⊠
	· · ·	Accept	

 \triangleright Only then the new load cell is detected.

5.15.10 Corner Correction

5.15.10.1 General Information

An asymmetric scale construction doesn't need a corner correction.

But the corner correction may be necessary at a symmetric scale construction.

5.15.10.2 Checking Corner Load (Dead Load)

After assignment and calibration, the load cell positions have been defined clearly.

5.15.10.3 Software Corner Correction

If the corners are loaded in succession, the same value should be displayed on the device at all times. An excessive deviation almost always means that the scale is tilted or indicates load cell force shunts.

If the signal deviations cannot be resolved by carefully leveling the scale, the software must be calibrated.

0.444 t 🗵


0.698 t 🗹

0.558 t 🗵


0.467 t 🗵

Access the menu as follows:

[System setup]-[Weighing point] [Weighing point A]-[Calib]-[Calibrate the scale]-[Modify].



- Select 'Corner correction'.
- Press the [Vessel] soft key.



Calc

- Set the calibration weight on a corner. ►
- The position (in this case, LC 3) is selected.
- Confirm the position.
- Remove the calibration weight.
- Repeat these steps for load cells 2-4 in any ► desired order
- If all load cells have been loaded one time, press the [Calc] soft key to carry out corner correction.

LC

LC 3


LC 4

1 LC 2

WP-A	Ma× Min	20t 0.04t	d=	0.002t
→0← ► ⊿		0.0		
- 4 ∯¶		Calibration		@admin
Calibration	veight			2.000 t
Corner corr	ection			correction ok
Vessel				Save

- ▷ The total weight remains unchanged. Only the effect of the individual load cells is corrected.
- When corner correction is completed, it is marked with 'correction ok'.
- Press the [Save] soft key to save the corner correction.

5.15.11 Parameter input



Access the menu as follows: [System setup]-[Weighing point] [Weighing point A]-[Param].

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[M&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

[Ambient conditions]

This parameter is used to define the ambient conditions of the scale.

Possible values: very stable condition, Stable condition, Unstable condition, Very unstable condition

[Detect a defect load cell]

Select this parameter and confirm if max. simulation of a faulty load cell should be automatic. A warning symbol is displayed for the duration of the load cell simulation.

[Unbalanced check deviation]

he plausibility check is activated when the average deviation is >0%.

The average deviation of the individual load cells is calculated. The process is displayed using a symbol above the weight unit.

Setting range: 0–100%

[Standstill time]

The parameters [Standstill time] and [Standstill range] can be used to define the stability of the scale (stable balance).

The [Standstill time] parameter is entered in seconds. The permitted range is 0.00-2 s.

The time can be entered from 0.00 to 2.00 seconds, but makes up at least one measurement time.

WP-A	Max	20t	d=	0.002t
	(].0] _t
. ∢ ∲ ¶	Weigh	ing point		@admin
Standstill r	ange	1		1.00 d
Tare timed	out			2.5 s
Zeroset ra	nge			50.00 d
Zerotrack				Yes
Zerotrack	range			0.25 d
Zerotrack	step			0.25 d
Default				Save

[Standstill range]

As long as the weight fluctuations remain within this range, the device is determined to be stable.

The [Standstill range] parameter is entered in "d." The permitted range is 0.01-10.00 d.

[Tare timeout]

Timeout for a tare/zeroset command that cannot be executed (e.g., due to mechanical instability of the scale, incorrect filter setting, resolution too high, standstill condition too strict).

This parameter is given in seconds. The permitted range is 0.0-<2.5>-25 s.

At 0.0 s taring is only carried out when the scale is already stable.

[Zeroset range]

Determine a ±range around the zero point determined by the dead load during calibration; within this range

- the displayed gross weight can be set to zero by pressing the zero-setting key (or by a corresponding external command), and
- automatic zero tracking is active.

Setting range: 0.00-10000.00 d

[Zerotrack]

The zero display is automatically maintained within set limits.

Possible values: no/yes

When "No" is selected, the next three parameters are not shown.

When "Yes" is selected values for the next three parameters must be entered.

[Zerotrack range]

Range within which the automatic zerotrack is balanced. Setting range: 0.25-10000.00 d

[Zerotrack step]

If a weight change exceeds the adjusted value, automatic tracking does not function any more. Setting range for automatic tracking increments: 0.25-10 d

WP-A	Max	20t	d=	0.002t
	(].()] _t
₩	Weighi	ng point		@admin
Zerotrack	time	1		1.0 s
Overload				9 d
🛛 Minimum 🕨	leight			20 d
Range mod	le			single range
Default				Save

[Zerotrack time]

Time interval for automatic zero tracking. Setting range: 0.0-25 s At 0.0 s the tracking is switched off.

[Overload]

Weighing range above the maximum capacity (Max) without error message. Setting range: 0-9999999 d.

[Minimum weight]

Minimum weight at which a print command can be triggered. Setting range: 0-9999999 d.

[Range mode]

Possible values: single range, multiple range, multi-interval. For scale range selection, see Chapter 5.11.16.2.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.15.12 Subsequent Dead Load Correction

If the platform weight changes by an amount that is higher than the zero-setting range, e.g., due to dead load reduction, dead load increase, or mechanical changes, the functions for automatic zero tracking and manual zero setting no longer work.

If the entire zero-setting range is already utilized, you can still correct the dead load without affecting other calibration data/parameters.

Access the menu as follows:

[System setup]-[Weighing points]-[Weighing point x]-[Calib]-[Calibrate the scale]-[Modify].

WP-A	Max	20t	d=	0.002t
	0.0	<u> </u>		t
. ∢ ‡ ¶	Cal	ibration		@admin
Number of v	vessel feet			4
Local gravit	У			9.81379 m/s²
Max		1000	D 0C	20.000 t
Scale interv	al		1 d	0.002 t
Dead load				2.845 t
Calibration 🗸	veight			2.000 t
Corner corre	ection			correction ok
Vessel		by load	by valu	ie Save

The scale must be empty (empty vessel).

- Select 'Dead load'.
- Confirm the dead load.
- Check the corner load, see Chapter 5.15.10.2.
- Carry out a corner correction if necessary, see Chapter 5.15.10.
- Press the [Save] soft key to save the current dead load.

5.16 PR-Net Weiging Point


5.16.1 General Information

PR 5500 can communicate with the following indicators via the network protocol:

- PR 5220
- PR 5230
- PR 5410

The determination and transmission of weight depends strongly on the indicators. Weight values up to seven digits plus preceding +/- sign can be displayed. Before the weighing electronics are assigned to the logical weighing point, the scale (e.g., PR 5230 + load cells) must be calibrated and configured accordingly. The calibration cannot be changed via the network protocol.

5.16.2 Parameter Input



[WP Serial number]

Serial number of the connected device. With serial number 0, checking is omitted. Setting range: 0...99999999

[Network address]

Input:

- IP address of the connected indicator or
- Device name (Host name) of the connected indicator

Note	The entry of a host name assumes that
	 a name server exists on the network, which recognizes the host names of the devices.
	 On the PR 5500, "use DHCP" is activated under [System setup]-[Network parameters] (otherwise the PR 5500 is not given the address of the name server).

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

WP-A	Max	20000kg	d=	1kg
→0←			0	kg
₩	Wei	ghing point		@admin
Weighing p Settings loc			PR-Net we	ighing point
₩&M _				none
WP serial nu	umber			0
Network ad	dress	B		172.24.22.48
Default				Save

▷ After saving the weight value of the scale is displayed.

5.17 Mettler-Scale

5.17.1 General Information

PR 5500 can communicate with the Mettler-Scale via the MT-SICS protocol. The scale can be connected via serial interface. Communication is serial.

The determination and transmission of weight depends strongly on the scale. Weight values up to seven digits plus preceding +/- sign can be displayed. The maximum capacity (Max) is already set in the Mettler scale and cannot be changed via the MT-SICS protocol.

5.17.2 Parameter Input in Mettler-Scale Menu

Example: scale type XS6002SDR

Select the menu item 'Peripherals' in system menu and make the following settings:

Printer	\rightarrow	Off						
Host	\rightarrow	RS232 built-in	\rightarrow	Define	\rightarrow	Baudrate	\rightarrow	9600
					\rightarrow	Bit/Parity	\rightarrow	7/Odd
					\rightarrow	Stop Bits	\rightarrow	1 Stop Bit
					\rightarrow	Handshake	\rightarrow	Xon/Xoff
					\rightarrow	End of line	\rightarrow	<cr> <lf></lf></cr>
					\rightarrow	Char Set	\rightarrow	IBM/DOS
					\rightarrow	Continuous mode	\rightarrow	Off
Secondary Display	\rightarrow	Off						
Bar Code	\rightarrow	Off						
Ext. Keyboard	\rightarrow	Off						

5.17.3 Parameter Input for Serial Interface

	ex??	d=?? Scale @admin Mettler-Scale >	Go to [System setup]-[Weighing point]-[Weighing point A], select and confirm 'Mettler-Scale').
Arameters ↓eighing point Interface Baudrate Data bits Parity Stop bits Default	Weighing point A	Dadmin Mettler-Scale Built-in R5-232 9600 baud 7 data bits no parity 1 stop bit	The following window appears. Select and confirm the line 'Interface'.

eta Lik not assigned Built-in RS-232 Option-1 RS-485-A Option-1 RS-485-B		The following window appears. Select and confirm the desired interface.
Meighing point Interface Baudrate Data bits Parity Stop bits	eighing point A Oadmi Mettler-Scale Built-in RS-23 9600 bau 7 data bits no parity 1 stop bi	The previous window appears. Select and confirm the line ,Baudrate'. Select and confirm ,9600 baud'.
Default Weighing point Interface Baudrate Data bits Parity Stop bits Default	eighing point A @admi Mettler-Scale Built-in RS-23 9600 bau 7 data bit: 0 dd parity 1 stop bi	Select and confirm the line ,Parity'. Select and confirm ,odd parity'. Press the [Save] soft key to save the settings.

5.17.4 Parameters Input for Scale Function

WP-A	Max	??	d=	??		
					-	
no values from scale						
_ ∢ ∲¶	ŀ	leighing point		<u>@</u> admin		
Weighing p	oint A		1	1ettler–Scale 🕨		
Parameters						
1 of officiers						
WP-A	Max	??	d=	??		

no values from scale

	Weighing point	@admin
Weighing point A		Mettler-Scale
Settings locked		
W&M		none
Max		1000 kg
Scale interval		1
Minimum weight		6 O
Default		Save

no values from scale

Max -----

< ∲ ¶	Weighing poi	nt @admin
Weighing point A		Mettler-Scale
Settings locked		
W&M		50 Unit
Max		1.200 kg
Scale interval		1
🛛 Minimum weight		6 O
Default		Save

Press the [Parameters] soft key.

- > The following window appears.
- Enter and confirm the following parameters.

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[M&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

[Max]

Enter the maximum capacity with decimal places and weight unit of the Mettler-Scale.

[Scale interval]

See Chapter 5.11.6.

[Minimum weight]

Minimum weight at which a print command can be triggered.

Setting range: 0-9999999 d.

WP-A

[Update time]


Time frame in which a new weight value is displayed. Setting range: 0.1...2.0 s.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.



 \triangleright The weight value of the scale is displayed.

5.18 Setting the SMA Scale

5.18.1 General Information

The PR 5500 can communicate with a scale via the SMA protocol. The device can be connected via serial interface (PR 5500/04; see Chapter 4.4.1). Communication is serial.

5.18.2 Parameter for Serial Interface

WP-A Max?? NO Values from s (Meighing point Weighing point A	d=?? Cale @admin SMA scale >	Go to [System setup]-[Weighing point]-[Weighing point A], select and confirm 'SMA scale'.
Parameters		
Weighing point A Weighing point Interface Baudrate Data bits Parity Stop bits	Qadmin SMA scale Option-1 RS-485-B 9600 baud 8 data bits no parity 1 stop bit	A selection window appears. Unavailable parameters are grayed out. Select and confirm the individual settings. [Interface] serial interfaces Selection: not assigned, Built-in RS-232, Option-x RS-485-A, Option-x RS-485-B
Default	Save	

[Baudrate]

Modulation rate for data transmission.

Note The selected value must match the value of the connected device.

Selection:

300, 600, 1200, 2400, 4800, <9600>, 19200 baud

[Parity]

Parity check for detecting errors during data transmission. Selection: no parity, odd parity, even parity

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

5.18.3 Parametereingabe

∢†) Weighing poi	NO VALUES FROM	scale) ©admin
• •			Dadmin
Weighing poi	nt A		Con a section of
			SMA scale ▸
Parameters			
WP-A	Max??	d=	??
	no values from	scale	9
	Weighing point		@admin
Weighing po Settings loci		_	SMA scale
			none
M&M			1000 kg
Max			
			1 0 d

Maximum Capacity [Max]

See Chapter 5.11.5.

[Scale interval]

See Chapter 5.11.6.

[Minimum weight]

Minimum weight at which a print command can be triggered. Setting range: 0...99999999 d. For use in legal metrology a value of at least 20 d must be set.

[Update time]

Timeframe in which a new weight value is displayed. Setting range: 0.1...2.0 s.

[Default]

Settings are reset to factory settings.

[Save]

The settings are saved.

Press the [Parameters] soft key.

▶ Select and confirm the individual settings.

[Settings locked]

The weighing point settings and assignment can only be viewed as if the corresponding CAL switch were closed; see Chapter 5.1.5.2.

[M&W]

Setting for operation in legal metrology. Select [none], OIML, NTEP (for USA) or NSC (for Australia); see Chapter 5.11.16.1.

5.19 General Parameter Settings

The parameter settings which are not related to the weighing electronics are divided into several ranges (see Chapter 5.10).

5.19.1 Equipment Settings

The connected devices are configured under this menu item.

. 4 ∯¶	System setup	@admin
Connected devices	;	
Date & Time		
Operating paramet	ers	
Network paramete	rs	
Network share cor	nections	
Fieldbus parameter	s	
Weighing point		
Display settings		
License settings		
User management		
Alibi memory		

Select and confirm [System setup] - [Connected devices] using the cursor.

5.19.1.1 Remote Display

4 0	Connected devices	@admin	\triangleright	A selection window appears.
General devia Remote display ModBus-RTU m PC via EW-Con Printer Add. applicat Ticket printer Printer 2	ces Y naster n	Interface (not assigned) > (not assigned) (not assigned) (not assigned) Interface (not assigned) (not assigned)		Select and confirm the connected device.
Interface	Remote display }	@admin not assigned		Select and confirm the line 'Interface'.
		Save		
not assigned Built-in RS-2 Option-1 RS- Option-1 RS-	32 485-A			A selection window appears. Unavailable interfaces are grayed out. Select and confirm the desired interface.

_ 4 ∯¶	Remote display	<u>@</u> admin
Interface	Þ	Built-in RS-232
Baudrate		9600 baud
Data bits		7 data bits
Parity		even parity
Stop bits		1 stop bit
Defeult		
Default		Save

5.19.1.2 ModBus-RTU Master

Connected devices 448 @admin General devices Interface (Built−in R5-232) (not assigned) ► Remote display ModBus-RTU master PC via EW-Com (not assigned) Printer (not assigned) Add. application devices Interface Ticket printer (not assigned) Printer 2 (not assigned) ModBus-RTU master <u>Oadmin</u> **4∲**₿ Interface not assigned Save ModBue_DTII master **himpe** not assigned Built-in RS-232 Option-1 RS-485-A Option-1 RS-485-B

- \triangleright A selection window appears.
- Select and set the desired parameters.

In this case, only the modulation rate for data transmission (baud rate) can be set.

Note The selected value must match the value of the connected device.

Selection:


300, 600, 1200, 2400, 4800, 9600, 19200 baud

Press the [Save] soft key to save the settings.

Select and confirm the connected device.

Select and confirm the line 'Interface'.

 A selection window appears. Unavailable interfaces are grayed out.
 Select and confirm the desired interface.



▷ A selection window appears.

Unavailable parameters are grayed out.

Select and confirm the individual settings.

[Baudrate]

Modulation rate for data transmission.

Note	The selected value must match the value of the connected device.
	ucvice.

Selection:

300, 600, 1200, 2400, 4800, <9600>, 19200, 38400, 57600, 115200 baud

[Parity]

Parity check for detecting errors during data transmission. Selection: no parity, odd parity, even parity

[Modbus Slave ID]

Input: an address from 1...255 using the keyboard

Press the [Save] soft key to save the settings.

Note The ModBus protocol is described in Chapter 7.

5.19.1.3 PC via EW-Com

General devices Remote display ModBus-RTU maste PC via EU-Com Printer Add. application of Ticket printer Printer 2	_	(Built-in R5-232) (Built-in R5-485-A) (not assigned) ► (not assigned) Interface (not assigned) (not assigned) (not assigned)	•	Select and confirm the connected device.
Interface	PC via EW-Com	Oadmin not assigned		Select and confirm the line 'Interface'.
Atta not assigned Built-in R5-232 Option-1 R5-485- Option-1 R5-485-	A B			A selection window appears. Unavailable interfaces are grayed out. Select and confirm the desired interface.

- 4 ∲¶	PC via EW-Com	@admin	\triangleright	A sele
Interface	۱.	Option-1 RS-485-B	-	
Protocol		EW-Com V1		Unav
Baudrate		9600 baud		Selec
Data bits		8 data bits		Selec
Parity		even parity		Fn .
Stop bits		1 stop bit		[Prot
EW-Com slave ID		А		Trans
				Selec [®] EW-C
				V1 =
Default		Save		V2 =

>	A selection window appears.
	Unavailable parameters are grayed out.
	Select and confirm the individual settings.
	[Protocol]
	Transmission protocol
	Selection: EW-Com V1, EW-Com V2, EW-Com V3
	V1 = for old communication programs
	V2 = for recipe controller
	V3 = for OPC

[Baudrate]

Modulation rate for data transmission.

Note The selected value must match the value of the connected device.

Selection: 300, 600, 1200, 2400, 4800, <9600>, 19200, 38400, 57600, 115200 baud

[Data bits]

Groups of data bits. Selection: 7 data bits, <8 data bits>

[EW-Com Slave ID] Input:

an address from A...Z using the keyboard

▶ Press the [Save] soft key to save the settings.

Note The PR 1612 command sets for the EW-Com protocol are described in Chapter 8.

5.19.1.4 Printer

Connected devices Remote display ModBus-RTU master PC via EW-Com Printer Add. application devices Ticket printer Printer 2	es @admin Interface (not assigned) (not assigned) (not assigned) > Interface (not assigned) (not assigned) (not assigned)	Select and confirm the line.
Printer Interface	@admin not assigned	Select and confirm the line 'Interface'.
not assigned Built-in RS-232 Option-1 RS-485-A Option-1 RS-485-B Network printer Network share connection USB printer USB folder	LEST DIULT 29A6	 A selection window appears. The following interfaces are available: Serial printer Network printer Network share connection USB printer USB folder Unavailable interfaces are grayed out. Select and confirm the desired interface.

Note

The here defined printer is also selected for the application configuration printout.

Serial printer

	Printer		@admin
Interface		Built-	in R5-232
Protocol			XON/XOFF
Baudrate			9600 baud
Data bits		8	data bits
Parity			no parity
Stop bits			1 stop bit
Printer type	۱.	EPSON	I TM-U220
Default		Test print	Save

[Baudrate]

Modulation rate for data transmission.

Note The selected value must match the value of the connected device.

Selection:

300, 600, 1200, 2400, 4800, <9600>, 19200, 38400, 57600, 115200 baud

[Data bits]

Groups of data bits. Selection: 7 data bits, <8 data bits>

[Stop bits]

Units for transmission protocols. Selection: 1 stop bit, <2 stop bits>

[Printer type]

The selection depends on the printer: raw, CR/LF translation, EPSON TM-U220, EPSON LQ 300k, Generic PCL5 (Unicode), Generic PCL5 (Codepage), Generic ESC/P2

- Press the [Test print] soft key.
- ▷ A test page (see Chapter 13.2) is printed.
- Check the printer settings and change if necessary.
- Press the [Save] soft key to save the settings.

A selection window appears.
 Unavailable parameters are grayed out.
 Select and confirm the individual settings.

[Protocol]

Transmission protocol Selection: no protocol, XON/XOFF, RTS/CTS

Network printer

	Printer		<u>O</u> admin
Interface		Netwo	rk printer
Protocol		LPR	(Port 515)
Printer type			гам
Queue name			
IP address	1	172	.24.20.104
Default		Test print	Save

- \triangleright A selection window appears.
- ▶ Select and confirm the individual settings.

[Protocol]

Transmission protocol Selection: Speak with the responsible system administrator: LPR (Port 515) or RAW (Port 9100)

[Printer type]

The selection depends on the printer: raw, CR/LF translation, EPSON TM-U220, EPSON LQ 300k, Generic PCL5 (Unicode), Generic PCL5 (Codepage), Generic ESC/P2

[Queue name]

Queue can be selected only if under [Protocol] ,LPR (port 515)' has been selected.

Selection:

Speak with the responsible system administrator.

[IP address]

Selection: Speak with the responsible system administrator.

- ▶ Press the [Test print] soft key.
- ▷ A test page (see Chapter 13.2) is printed.
- Check the printer settings and change if necessary.
- Press the [Save] soft key to save the settings.

Network share connection

400	Printer		Øadmin
		kl-k	
Interface	Þ	Network share	
Printer type		CR/I	.F translation
Connection name			Reports
Defeult			
Default		Test print	t Save

- \triangleright A selection window appears.
- Select and confirm the individual settings.

[Printer type]

The selection depends on the print file processing: raw, CR/LF translation, EPSON TM-U220, EPSON LQ 300k, Generic PCL5 (Unicode), Generic PCL5 (Codepage), Generic ESC/P2

[Connection name]

Print file storage location. Minimum one network share connection must exist, see Chapter 5.19.5.

- Press the [Test print] soft key.
- \triangleright A test file is created in the selected connection.
- Check the settings and change if necessary.
- Press the [Save] soft key to save the settings.

USB printer

Interface Printer type Selected USB printer USB vendor USB product USB serial number	Printer 2	@admin USB printer гам nter selected
Default	Test print	: Save
- 4 ∯¶	Printer 2	@admin
Interface		USB printer
Printer type		raw
Selected USB printer	Zebra ; LP2844	42A0604004
USB vendor		Zebra ;
USB product		LP2844
USB serial number	42	2A060400476
Default	Test print	Save

- A selection window appears.
 Unavailable parameters are grayed out.
- Select and confirm the individual settings.

[Printer type]

The selection depends on the printer: raw, CR/LF translation, EPSON TM-U220, EPSON LQ 300k, Generic PCL5 (Unicode), Generic PCL5 (Codepage), Generic ESC/P2

Select and confirm line 'Selected USB printer'.

 Printer 2 @admin Interface USB printer Printer type Selected USB printer Zebra; LP2844 42A0604004 USB vendor Zebra; USB product LP2844 USB serial number 42A060400476 Press the [Test print] soft key. A test page (see Chapter 13.2) is printed. Check the printer settings and change if necessary. Press the [Save] soft key to save the settings. 	Zebra ; LP2844 42A060400476 Zebra Technologies ZTC GK420d 2	28J110200678		A selection window appears. The connected printers (here: 2) can be selected. Select and confirm the desired printer.
Printer type raw Selected USB printer Zebra ; LP2844 42A060400 USB vendor Zebra ; USB product LP2844 Press the [Save] soft key to save the settings.	Vinter 2	@admin		Press the [Test print] soft key.
Selected USB printer Zebra ; LP2844 42A0604004 USB vendor Zebra ; USB product LP2844	Interface	USB printer	\triangleright	A test page (see Chapter 13.2) is printed.
USB vendor Zebra; USB product LP2844 Press the [Save] soft key to save the settings.	71			Check the printer settings and change if
USB product LP284				necessary.
				Press the [Save] soft key to save the settings.
USB serial humber 42A060400476				
Default Test print Save				

USB folder

	Printer		Qadmin
Interface	Þ	L	ISB folder
Printer type Folder name			anslation Reports
Default		est print	Save

 Printer
 Oadmin

 Interface
 USB folder

 Printer type
 CR/LF translation

 Folder name
 Reports

 Folder Reports does not exist on USB stick.
 Create folder?

 Folder Reports does not exist on USB stick.
 Create folder?

 Yes
 No

- \triangleright A selection window appears.
- Select and confirm the individual settings.

[Printer type]

The selection depends on the print file processing: raw, CR/LF translation, EPSON TM-U220, EPSON LQ 300k, Generic PCL5 (Unicode), Generic PCL5 (Codepage), Generic ESC/P2

[Folder name]

Print file storage location (here: Reports).

The user-defined directory path is subject to the following restrictions:


- Max. 128 characters .
- 0-9, A-Z (not case-sensitive) are permitted.
- Must not start with space or "/".
- Must not contain space, "//", "./", " /", ".." and "/ ".
- Must not end with space, "." or "/".
- Must not use "<", ">", ":", "", "/", "/", "/", "/", "!", "?" and "*".

Input: via keyboard

- Press the [Test print] soft key.
- \triangleright A prompt window appears.
- ▶ Press the [Yes] soft key.
- ▷ A test file is created in the new created folder.
- Check the settings and change if necessary.
- Press the [Save] soft key to save the settings.

5.19.2 Setting the Date and Time

The parameters for date and time are set under this menu item.



	Date & Time	@admin
Time zone		Berlin, Germany
Local date		02.12.2014
Local time		14:39:07
Clock source	Þ	Remote NTP
Remote NTP server		0.0.0.0
Last update		00.00.0000-00:00:00
online		
Default	Format	Save

Format

Select and confirm [System setup] - [Date & Time] using the cursor.

- \triangleright A selection window appears.
- Select and confirm the individual parameters.

[Time zone]

Selection: all existing time zones

[Local date]

Can be configured if 'local hardware clock' has been selected under [Clock source]. Input: via keyboard

[Local time]

Save

Can be configured if 'local hardware clock' has been selected under [Clock source].

Input: via keyboard

[Clock source]

Selection:

local hardware clock, NTP server (Network Time Protocol)

[NTP server]

The IP address can only be entered if under [Clock source] 'NTP server (Network Time Protocol)' has been selected.

Input: IP address via keyboard

[Last update]

Indicates when the last data was received by the NTP server.

[online]

The checkbox **I** indicates whether the NTP server was successfully contacted during the last attempt.

Default

	Date & Time fo	rmat 🛛 🔍 a	dmin
Date format			
Date of order	۱.	ddmmy	177
Date separator		Perio	od 🗥
Month		2 di	igits
Year		4 d	igits
Date/Time sep	arator	Sp	ace
Time format			
Clock type			24 h
Time separator		Co	lon :
•			

Default

Save

- Press the [Format] soft key to set the format parameters.
- \triangleright A selection window appears.
- Select and confirm the individual settings.

[Date of order]

Selection: mmddyyyy, ddmmyyyy, yyyymmdd, yyyyddmm d = day, m = month, y = year

[Date separator]

Selection: Slash '/', Hyphen '-', Period '.', Space ' ', Japanese 年月日, None

[Month]

Selection: 2 digits, 3 characters

[Year]

Selection: 2 digits, 4 digits

[Date/Time separator]

Selection: Hyphen '-', Space ' ', None

[Clock type]

Selection: 12 h, 24 h

[Time separator]

Selection: Colon ':', Hyphen '-', Japanese 時分秒, None

▶ Press the [Save] soft key to save the settings.

5.19.3 Setting the Operating Parameters

The operating parameters are set under this menu item.

< 4 ¶	System setup	Qadmin
Connected de	vices	
Date & Time		
Operating par	ameters	•
Network para	meters	
Network shar	e connections	
Fieldbus para	neters	
Weighing point	t	
Display settin	gs	
License settir	igs	
User manager	nent	
Alibi memory		

Ma Oper	ating parameters	@admin
Operating		
Display language	(en)	English
External keyboard la	ayout English	QWERTY
Input method		by language
Screensaver		after 10 minutes
Keyclick sound		short key click
Coldstart with STOP+EXIT		for 3 seconds
Programming		
Software download		disabled
Label/Language download		disabled
Operational keys		
¹¹ Keys require logged	in user	
Default	Input test	Save

Select and confirm [System setup] - [Operating parameters] using the cursor.

- \triangleright A selection window appears.
- Select and confirm the individual parameters.

Note	When user management is activated, the settings for the logged-in user remain active.
Display language Selection: (de) Deutsch, <(e	
Note	When user management is activated, the operating language only changes once the currently logged-in user logs out. It is only possible to switch languages immediately using the F1 or F2 key.

[External keyboard layout]

Selection:

<Englisch QWERTY>, German QWERTZ, French AZERTY, Italian QWERTY, Spanish QWERTY, Russian QWERTY/йцукен

[Input method]

This function makes it possible to enter Japanese (Hepburn) or Chinese (Pinyin) characters even if the language in question (Japanese or Chinese) is not selected or another language (such as English) has been selected under [Display language].

Selection:

<by language>,

Hepburn (transliteration of Japanese "Hiragana" characters into Latin script), Pinyin (phonetic transliteration based on the Latin alphabet)

🐗 Operating p	parameters	@admin	Input Test for Keyboard and Keypad
Operating Display language External keyboard layout Input method Screensaver Keyclick sound Coldstart with STOP+EXIT Programming Software download Label/Language download Operational keys Keys require logged in use	sh fi	English QWERTY Hepburn r 10 minutes ort key click or 3 seconds enabled enabled	Press the [Input test] soft key to test the entry.
Default Ing	out test	Save	
Operating Display language	en)	English	An input window appears.Enter the desired characters.
External keyboard layout Inp Scr Ke; Col Pro Enter some to Sol Lat Ope Ke;		QWERTY '' burn ytes blick inds itte ime *#*!/《하 bled bled	 During the input test using the keypad, pressing the key on the instrument switches between in this case: Hepburn Numbers Uppercase letters
De	Ok T	e	- Lowercase letters

Press the [OK] soft key to end the input test.

[Screensaver]

Once the screensaver is switched on, operation is only possible once a password has been entered or a key has been pressed.

Selection:

[no screensaver], after 1 minute, after 5 minutes, after 10 minutes, after 30 minutes

[Keyclick sound]

Duration of acoustic signal when keys are pressed Selection: no key click, <short key click>, medium key click, long key click

[Coldstart with STOP+EXIT]



A cold start leads to a loss of all data on the database.

Selection: <disabled>, immediately, 3 s

[Software download]

Load and start a new application on the device via the network.



Possible production downtime! This parameter must always be set to "locked" for production systems.

Selection: <disabled>, enabled

Software can only be downloaded in running operation when "enabled" has been selected.

[Label/Language download]

Load labels and language files via network temporarily into the device.

Note After a cold sta Loading the lan

After a cold start the files will be lost.

Loading the language files permanently into the device is possible via the update software "FlashIt!" from version 02.73.11.

Selection: <disabled>, enabled

[Keys require logged in user]

If the checkbox \blacksquare is ticked, the keys with weighing point functions (e.g. Set zero; F1 and F2, if configurated for weighing point functions) are locked for users who are not logged in.

	Operating parameters	@admin
Operating		
Tare key	<u>></u>	set tare & reset tare
Set zero key		only when not tared
F1 key		Change language
F2 key		Toggle weight unit
Default	Input test	Save

[Tare key]

The function of the tare key $\rightarrow T \leftarrow$ can be configured.

Selection:

disabled, <set tare & reset tare>, set tare & set tare again

'Disabled' means that the key has no function.

'Set tare & reset tare' means that the device will be tared if it has not been tared previously and the tare will be reset if the device has already been tared.

'Set tare & set tare again' means that each time a key is pressed, the instant value in the tare memory is applied and the net display switches to 0.

[Set zero key]

The function of the set zero key $\rightarrow 0^{\leftarrow}$ can be configured.

Selection:

disabled, <only when not tared>, reset tare on zero set

'Disabled' means that the set zero key on the keypad has no function.

The key's function can be limited to gross mode with 'only when not tared' or switched automatically to gross mode with 'reset tare on zero set'.

If the zero-setting key with these settings has no effect, the configured zero-setting range (around the zero-point set with the dead load) is already utilized due to a previous zero-setting operation and/or automatic zero setting (see Chapter 5.11.16).

[F1 key], [F2 key]

Selection:

no function, Change language, Change user, Lock device, Toggle weight unit, Set tare, Reset tare, set tare & reset tare, set tare & zero set, Analog test, Show 10-fold resolution


Note Weighing point functions are only active when the weight display is switched on.

Selection	Function	
No function	The key has no function.	
Change language	The menus are displayed immediately in the selected language.	
Change user	The login window opens on the display.	
Lock device	This function is only possible, if the user management has been activated.	
Toggle weight unit	Can be switched between display units (see Chapter 5.11.15). This function is only possible if at least two units have been selected.	
Set tare	The current gross weight is stored in the tare memory.	
Reset tare	Switching to gross mode.	
Set tare & reset tare	The device will be tared if it has not been tared previously and the tare will be reset if the device has already been tared.	
Set tare & zero set	The device will be tared if it has not been tared previously and display will be set to 0.	
Analog test	Can be used to test the selected analog weighing point only when the current weight is displayed.	
Show 10-fold resolution	The weight value is displayed for a brief time at an increased resolution (10-fold).	

Press the [Save] soft key to save the settings.

5.19.4 Network Parameters

The network parameters are set under this menu item.



[Device name (hostname)]

Caution!

The device name must be unique in the network!

The user-defined device name is subject to the following restrictions:

- Minimum amount of characters: 2, maximum amount of characters: 24.
- The first character must be a letter. Spaces are not permitted.
- 0-9, A-Z (not case-sensitive) are permitted.
- - or . may be included, but not at the end nor one after the other.

Input: via keyboard

[use DHCP]

If the checkbox \blacksquare is ticked (presetting: DHCP selected), the server automatically allocates the IP address, subnet mask, and default gateway.

If the checkbox is not ticked, the settings for the 'IP address', 'Subnet mask', and 'Default gateway' must be defined in conjunction with the responsible system administrator.

	Network parameters	@admin
HW address		00:90:6C:96:7E:A9
Host name		PR5500-967EA9
use DHCP		
IP address		172.24.20.94
Subnet mask		255.255.240.0
Default gatew	ах	172.24.16.1
Remote acce	255	
Web server ei		
VNC access e	nabled	
VNC client		255.255.255.255
VNC passwore	9	******
Default	•	Save

[Web server enabled]

If the checkbox \checkmark is ticked, the device website can be used.

[VNC access enabled]

If the checkbox \blacksquare is ticked, the device can be operated via VNC.

[VNC client]

This address can be used to allow access to the interface; see following table.

[VNC password]

If a password in entered (max. 8 characters), this password must be entered in the VNC client to access the interface.

▶ Press the [Save] soft key to save the settings.

VNC client	172.24.21.101	
VNC client	172.24.21.255	
VNC client	255.255.255.255	

Access only from client machine with this address. Access from any client with address within range 172.24.21.1 - ..254. Access from client with any address.

[Default]

- resets the host name to PR5500-XXXXXX, where XXXXXX stands for the last 3 bytes of the hardware address (MAC ID).
- sets [use DHCP] to active.
- sets the IP address to 0.0.0.0.
- sets the subnet mask to 0.0.0.0.
- sets the default gateway to 0.0.0.0.
- sets the VNC client to 255.255.255.255.
- resets the VNC password to ,no password'.

5.19.5 Network Share Connections

Under this menu item, network share connections are configured and provided for system maintenance (such as data storage/backups on the network).

The following order must be observed without exception:

- 1. One or more directories on the server/notebook/PC must be shared; see the manual for the operating system in question (e.g., Windows 7: click the directory, right-click on ,Advanced Sharing...' and activate the selection ,Share this folder'. Then click ,OK'.)
- 2. On the instrument under [System setup] [Network share connections], configure the connections to the shared directories on the server/notebook/PC.

4 ∲ <mark>9</mark>	System setup	@admin
Connected	devices	
Date & Tin	12	
Operating (parameters	
Network p	arameters	
Network s	hare connections	•
Fieldbus pa	rameters	
Weighing p	pint	
Display se	ttings	
License se	ttings	
User mana	gement	
Alibi memo	ILÀ	

 Select and confirm [Network share connections] using the cursor.

5.19.5.1 Adding a Network Share Connection

Configure network share connections @admin No connections configured	 A selection window appears. Here: the list is empty because no connection has been configured. Press the [Add] soft key to configure a new connection.
Create network share connection @admin Connection name Image: Connection Image: Connecti	 A selection window appears. Select and confirm the individual parameters. [Connection name] The name must be unique in the network. Input: max. 16 alphanumeric characters [Server] Enter the hostname (see page 260) or IP address.

[Share name on server]

The existing name on the server where the directory was created.

Input: max. 64 characters

[Folder path]

The existing directory path within network sharing (if required).

The user-defined directory path is subject to the following restrictions:

- Max. 128 characters .
- 0-9, A-Z (not case-sensitive) are permitted.
- Must not start with space or "/".
- Must not contain space, "//", "./", " /", ".." and "/ ".
- Must not end with space, "." or "/".
- Must not use "<", ">", ":", "", "/", "/", "/", "]", "?" and "*".

Input: via keyboard

[Domain]

The existing domain for network sharing (if required). Input: max. 64 characters

[User name]

User name on the network (if required). Input: max. 64 alpha numeric characters

[Password]

Password on the network (if required). Input: max. 64 alpha numeric characters

Edit network share connection Definition Connection name Reports Server XXX.company.com Share name on server Office Fol Dor Use I Pas Test passed Ok e	 Press the [Test] soft key to test the connection. An info window appears. Press the [OK] soft key to hide the window. If an error message appears, the configuration must be changed. Press the [Save] soft key to save the connection.
Configure network share connections @admin Reports > Add Change Remove	A selection window appears. The newly configured connection (in this case: Reports) is displayed.
5.19.5.2 Changing a Network Share Connection	 Select the appropriate connection using the cursor. Press the [Change] soft key to change the connection configuration.
Abb Edit network share connection Deadmin Connection name Reports Server XXX.company.com Share name on server Office Folder path Prod_data/Share_PR5500/Re. Domain CONE abc User name forename.surname Password ####################################	 A selection window appears. Use the cursor to select, confirm, and change individual parameters if necessary; see Chapter 5.19.5.1. Press the [Test] soft key to test the connection. Change the configuration again if necessary. Press the [Save] soft key to save the connection.

5.19.5.3 Removing a Network Share Connection

Note	Only the setting is deleted in the instrument.	
	No network share files are deleted.	

Configure network share connections @admin Reports ▶	 Select the appropriate connection using the cursor. Press the [Remove] soft key to delete the connection.
Add Change Remove	
Configure network share connections @admin	A prompt window appears.
Reports >	Press the corresponding soft key.
Remove network share connection Reports?	

5.19.6 Fieldbus Parameters

5.19.6.1 Generell Information

The fieldbus parameters are set under this menu item. This menu item can only be selected if a PR 1721/6x card has been installed in the Option-1/FB slot.

Ve System setup Connected devices Date & Time Operating parameters Network parameters Network share connections Fieldbus parameters Fieldbus parameters Version Weighing point Display settings License settings User management Alibi memory Alibi memory	Select and confirm [System setup] - [Fieldbus parameters] using the cursor.
Ve Fieldbus parameters fieldbus protocol ProfiBus-DP-V1 Vos 8 byte 1/0 Scale interface WP A ProfiBus-DP address 3	The protocol displayed automatically depends on the installed fieldbus card (here: ProfiBus-DP-V1): [Profibus-DP] for PR 1721/61, [DeviceNet] for PR 1721/64, [CC-Link] for PR 1721/65, [ProfiNet I/O] for PR 1721/66 and [EtherNet IP] for PR 1721/67. Confirm the first line.
	Confirm the first line.
Default Save	
B byte I/0 16 Byte I/0 24 Byte I/0 32 Byte I/0 64 Byte I/0	A selection window appears. Select and confirm the desired range using the cursor.
Fieldbus parameters fieldbus protocol ProfiBus-DP-V1 I/Os 8 byte I/O Scale interface MP A ProfiBus-DP address 3 Default Save	Select and confirm "Scale interface" using the cursor.

√ Ω	Fieldhue opromotore
disabled	
WP A	
WP A, B	h
WP A, B, C	2
WP A, B, C, D	
	save
	5000

\triangleright A selection window appears.

Select and confirm the desired line using the cursor.

If 'disabled' is selected, no weight values or statuses can be transmitted.

Only for application programmers who want to use the entire range.

If 'WP A' has been selected, e. g. 32 bytes can be selected under 'I/As' nevertheless. However, the first 8 bytes are used by WP A.

[Fieldbus address]

The input is dependent on the respective fieldbus.

▶ Press the [Save] soft key to save the settings.

5.19.6.2 ProfiBus-DP Settings for S7

Requirements

- The PR 1721/61 ProfiBus-DP fieldbus card is installed; see Chapter 4.4.8.
- The parameters have been selected and saved according to the weighing points (1x WP = 8 byte I/O); see Chapter 5.19.6.1.

Procedure

- ▶ Establish communication with the PLC (in this case: SIEMENS S7-300/400).
- Create/open a project in the SIMATIC MANAGER.
- ▶ Under ,HW config. > Tools > Install GSD files', load the file ,SART_5500.gsd' from the CD.
- ▷ This file appears under profile -> ... as ,PR 5500 Process Controller'.
- Select the appropriate modules (I/O size consistent) here according to the device configuration.
- Find the access addresses in the relevant application manual (Chapter ,Description of the I/O Area').
 Example: The gross weight should be read for weighing point WP A.
 I/O size = 8 bytes, counted from byte 0–7

Card Test

The fieldbus card has 2 LEDs (OP, ST). Communication is functioning correctly when the LEDs are green (see Chapter 4.4.8.

All inputs and outputs are displayed under [System maintenance] - [Test hardware] - [I/O card test] - [Option-FB PR 1721/61].

Note Further details can be found in the supplementary application manual ,How to...' (available upon request from Technical.Support@Sartorius.com).

5.19.6.3 DeviceNet Settings for Rockwell Workstation

Requirements

- The PR 1721/64 DeviceNet fieldbus card is installed; see Chapter 4.4.9.
- The parameters have been selected and saved according to the weighing points (1x WP = 8 byte I/O); see Chapter 5.19.6.1.

Procedure

- Establish communication with the workstation in the ,RSLinx' program (initial ser.DF1, recommended ETH-LAN).
- ▶ Register the file ,sag_5500_DVN.EDS' in the ,RSNetWorx for DeviceNet' program.
- Add a database entry in the hardware window under [Vendor] [Sartorius Mechatronics T&H GmbH] [Communications Adapter]:
 - Drag ,Scanner 1769 SDN' to ,Graph' and enter slot number (e.g., 3).
 - Drag ,MAXXIS Device' to ,Graph' and apply the MAC ID specified on the instrument.
- Start the ,RSLogix5000' program.
- Create a new project (,New') with a hardware structure according to the hardware components and enter Slot1...n.
- ▶ In III [Backplane] III [CompactBus Local] III [1769-SDN/B], select [Properties Slot(n)].
- ▷ The ,Module Properties Report' window appears.
- Enter values for input size [2/4/6/8] and output size [2/4/6/8] (32-bit) according to the active weighing points (1x WP = 2 x 32-bit = 8 byte I/0).
- ▶ Upload from the workstation to the project newly created with the <RSLogix5000> program.
- ▶ In the <RSLogix5000> program, set the access to ,Online' in ¹ [Controller Tags] as [DINT per WP 2 lines with 4 bytes each].
- Additional settings are defined in the application in question, such as phase (see corresponding manual).

Card Test

The fieldbus card has 2 LEDs (MS, NS). Communication is functioning correctly when the LEDs are green (see Chapter 4.4.9).

All inputs and outputs are displayed under [System maintenance] - [Test hardware] - [I/O card test] - [Option-FB PR 1721/64].

Note	Further details can be found in the supplementary application manual ,How to' (available
	upon request from Technical.Support@Sartorius.com).
	,RSLinx', ,RSNetWorx', and ,RSLogix5000' are products of Rockwell Automation®.

5.19.6.4 ProfiNet I/O Settings for S7

Requirements

- The PR 1721/66 ProfiNet I/O fieldbus card is installed; see Chapter 4.4.11.
- The parameters have been selected and saved according to the weighing points (1x WP = 8 byte I/O); see Chapter 5.19.6.1.

Procedure

Establish communication with the PLC (in this case: SIEMENS S7-300/400).

Attention!	A unique device name must be assigned for the hardware configuration and assignment/
	download.

There are two options:

- CPU with ProfiNet port (here: CPU1511-1PN), direct access
 - Under ,Network > Available consumers', assign the device names under the detected devices and select ,Download'.
- Communication Processor (here: CP343-1)

Data is accessed via the function code ,FC11PN I-O send' and ,FC12PN I-O receive'.

- Select ,Available consumers' under ,CP343-1 > PLC > Ethernet > Edit Ethernet Mode > Browse'.
- Select device ,PR 5500', assign the device name, and select ,Download'.
- ► Create/open a project in the ,SIMATIC MANAGER'.
- Under ,HW config. > Tools > Install HTML files', load the file ,GSDML-xxx-Sartorius-PR5500-xxx.html' from the CD.
- ▷ This file appears under profile -> ... as ,PR 5500 Process Controller'.
- Select the appropriate modules (I/O size consistent) here according to the device configuration.
- Find the access addresses in the relevant application manual (Chapter ,Description of the I/O Area').
 Example: The gross weight should be read for weighing point WP A.
 I/O size = 8 bytes, counted from byte 0–7

Card Test

The fieldbus card has 3 LEDs (MS, Link, NS). Communication is functioning correctly when the LEDs are green (see Chapter 4.4.11).

All inputs and outputs are displayed under [System maintenance] - [Test hardware] - [I/O card test] - [Option-FB PR 1721/66].

Note Further details can be found in the supplementary application manual ,How to...' (available upon request from Technical.Support@Sartorius.com).

5.19.6.5 EtherNet IP Settings for Rockwell Workstation

Requirements

- The PR 1721/67 EtherNet-IP fieldbus card is installed; see Chapter 4.4.12.
- The parameters have been selected and saved; see Chapter 5.19.6.1.

Procedure

- Establish communication with the workstation in the ,RSLinx' program (initial ser.DF1, recommended ETH-LAN).
- ▶ Register the file ,sag_5500_ETH.EDS' in the ,RSNetWorx for EtherNetIP' program.
- Add a database entry in the hardware window under [Vendor] [Sartorius Mechatronics T&H GmbH] [Communications Adapter]:
 Drag ,MAXXIS Device' to ,Graph' and apply the ETHIP address specified on the instrument.
- Start the ,RSLogix5000' program.
- ▶ Upload from the workstation to the project newly created with the <RSLogix5000> program.
- ▶ In the <RSLogix5000> program, set the access to ,Online' in [Controller Tags] as [DINT per WP 2 lines with 4 bytes each].
- Additional settings are defined in the application in question, such as phase (see corresponding manual).

Card Test


The fieldbus card has 3 LEDs (MS, Link, NS). Communication is functioning correctly when the LEDs are green (see Chapter 4.4.12).

All inputs and outputs are displayed under [System maintenance] - [Test hardware] - [I/O card test] - [Option-FB PR 1721/67].

Note Further details can be found in the supplementary application manual ,How to...' (available upon request from Technical.Support@Sartorius.com). ,RSLinx', ,RSNetWorx', and ,RSLogix5000' are products of Rockwell Automation[®].


5.19.7 Display Settings

The brightness can be adjusted to suit lighting conditions here.



5.19.8 License Settings

Licenses for functions and application programs are activated under this menu item.



 Select and confirm [System setup] - [License settings] using the cursor.

Activating an Application License

- A selection/input window appears. The nine-digit board number is displayed.
- Enter the license number for the desired function/
- application as a seven-digit number using the keyboard.

Note	License numbers are delivered		
	with the device as a certificate		
	and are valid only for this		
	device/board number.		

▶ Press the [Save] soft key to save the entry.

Activating the Demo Mode

- Press the [Demo mode] soft key to operate the selected application in demo mode.
- \triangleright A prompt window appears.
- ▶ Press the [Continue] soft key to start demo mode.

4∲ ¶	License	settings	Qadmin
Board n	umber		362184361
Tilt corre	ection license	Incl.	in applic. license
Alit		-	2007696
OPC		7	700
Dos			2067
Ар	When demo > device will re > database will import/export an	ARNING!) mode is active, start every 4 ho be reset on rest d backup/restor isabled.	art.
> ac	tivated licenses (vill be reset in de	emo mode.

Board numbe Alibi license	License settings r	@admin 0	⊳	A message appears, indicating an impending cold start.
Allo license OPC server license Dosing license Applicat <u>in 03154ml Demo-Mo</u> Application number 104			To switch on demo mode, enter the corresponding license number (here: example for dosing) and confirm with the [Save] soft key (see following table).	
				The desired dosing is carried out.
				To end demo mode, press the [End demo] soft key.
Default	Finish demo	Save	⊳	The previously entered license number for demo mode is deleted. The previous board number and license number are rewritten again.

Product	License number	Name
PR 5500/91	1550459	Alibi memory license
PR 5500/92	3550167	OPC server license
PR 5500/93	9546082	Dosing license
PR 5500/xx	1786623	Universal license
PR 5500/81	0928277	Phase license
PR 5500/83	7961243	Batching license
PR 5500/86	8965110	IBC license
PR 5500/87	8395383	Basic tilt correction license

⊲ ‡¶	License setting	s @admin
Boar	rd number	362184361
	correction license	Incl. in applic. license
	i license	8026696
OPC Do:	3	700
Ap	f i l	1276
	WARNING	
	'Default' will remove all enter	ed license numbers.
	Cancel	Continue
De	Lancel	

Restoring Factory Settings

- ▶ Press the [Default] soft key.
- \triangleright A prompt window appears.
- ▶ Press the corresponding soft key.

5.20 System Information

🙀 Operating	Select and confirm [System information] using the
Application menu Weighing	cursor.
Check weighing	Unavailable applications/functions are grayed out.
Device employed as terminal Configuration	
System menu	
System setup	
System information > System maintenance	
Logout	

5.20.1 Showing the Version

Show version Show status Show alarm info Show HW options Show ModBus-T Browse alibi mer Show calibration Show calibration Show Pendeo da Show event log Print configurati	check number ta		Select and confirm [System information] - [Show version] using the cursor.
40	Version @admin	\triangleright	The following information is shown:
Maxxis 4 Bios	Rel. 01.00.00.246425 2014-11-28-10:17		[Bios]
Firmware Basic Board number	Rel. 01.00.00.246499 2014-11-28-12:22 Rel. 01.00.05.35 2014-11-21-10:10 362184361		BIOS release and creation date
Boaro numoer	362184361		[Firmware]
			Firmware release and creation date
			[Basic]
			- Application name
*			- Application release and creation date

[Board number]

Nine-digit board number

Press the ESC/EXIT key to return to the previous window.

5.20.2 Showing the Status

. ∢ ‡ ¶	System information			
Show	version			
Show	status 🔸			
Show	alarm information			
Show	HW options			
Show	Show ModBus-TCP 1/0 module			
Вгомя	Browse alibi memory			
Show	Show calibration check number			
Show	Pendeo data			
Show	Show event log			
Print	Print configuration settings			

🟘 Status	@admin
Available system RAM	16328/27188 kB
Available backup memory	3765/3775 MB
Available settings memory	1616/2048 kB
Available database memory	1791/1792 kB
Clock battery status	battery is ok
Board temperature	30.50 °C
Accu status	ok
Accu charge	inactive
Cal switch A	opened
CAL switch 1/2	opened/opened

[Available database memory]

Free database memory

[Clock battery status]

Battery status

[board temperature]

Main board temperature

[Accu status]

Alarm at

- temperatures >60°C: The standby battery is too hot and is not charging. If this does not go away, then the ambient temperature must be checked, see Chapter 12.4.1.
- Overloading
- < min. voltage</p>

If the error can not be corrected automatically, the following error message appears:

"Accu defective or not connected."

Replace a by Sartorius service or equivalent qualified personnel.

[Status battery capacity]

Display of charge strength: Aus, 60 mA, 300 mA

[CAL switch A/B]

Appears only if the required option is installed. Otherwise ,n.a.' (not applicated) is displayed. Status display

[CAL switch 1/2]

Status display

Press the ESC/EXIT key to return to the previous window.

 Select and confirm [System information] - [Show status] using the cursor.

▷ This line shows the following device statuses:

[Available system RAM] Free working system memory space

[Available backup memory] Free memory for backups

[Available settings memory] Free memory for settings

5.20.3 Showing Alarm information

Show HW og Show ModB Browse alit Show calibu Show Pendu Show even	is n information ptions us-TCP IO module of memory ration check number eo data	ion	Select and confirm [System information] - [Show alarm information] using the cursor.
4 ¶ ₩ USB stick	Current system messagi attached.	es @admin	Current system messages are shown.

5.20.4 Showing Hardware Options

System information Show version Show status Show alarm information Show HW options Show ModBus-TCP I/O module Browse alibi memory Show calibration check number Show Pendeo data Show event log Print configuration settings	Select and confirm [System information] - [Show HW options] using the cursor.
Show hardware options @admin Built-in R5232 Option-1 PR5900/04 R5-485/R5-485 Option-2 PR5900/17 Digital I/O Option-FB -empty- WP A PR5900/W1 weighing electronic Info Monitor	 The installed options are displayed. Optional cards not detected by the system are displayed as follows: PR xxxx/xx Option not supported Optional cards detected by the system but not identified are displayed as follows: Information could not be read -assigned- Press the [Info] soft key. Information about the optional card is displayed. Press the ESC/EXIT key to return to the previous window. Press the [Monitor] soft key.
Image: status Option-1 Description RS-485-A is in use Tx character in bytes 265129610 Rx character in bytes 556683235 Breaks 0 Overrun errors 0 Parity errors 0 Framing errors 0 RS-485-A RS-485-B	 The current values are displayed; example: Option-1 RS-485-A interface. Press the [RS-485-B] soft key to display the current values for the Option-1 RS-485-B interface. Press the ESC/EXIT key to return to the previous window.

5.20.5 ModBus-TCP IO Modules

If the ModBus-TCP master is active in an application, the IO modules can be monitored under this menu item.

System information Show version Show status Show alarm information Show HW options Show ModBus-TCP I/O module Browse alibi memory Show Calibration check number Show Pendeo data Show event log Print configuration settings				
	ModBus-TCP master	@admin		
1	Phoenix Module 1	offline		
2	Phoenix Module 2	offline		
3	Phoenix Module 3	offline		
4	Phoenix Module 4	offline		
5	Phoenix Module 5	offline		
6	Phoenix Module 6	offline		
7	Phoenix Module 7	I/O data active ►		
8	Phoenix Module 8	offline		

 Select and confirm [System information] -[ModBus-TCP I/O module] using the cursor.

- > The modules and their status are displayed.
- Select and confirm the corresponding module.

- - •‡ -	Module 7	@admin
Phoenix M	lodule 7	172.24.22.7
I/O data ad	ctive since	13.09.2013-14:19:02
connection	n counter	41
I/O cycles		5383
cycle time	e	0.055 s
Rd	HREGS 8000:	0000
Wr	HREGS 8001:	0000 0000 0000 0000

 \triangleright An info window appears.

[Phoenix Module 7] IP-Adresse

[I/O data active since] Date and time of last established connection.

[Connection counter] Counts each connection in ascending order.

[I/O cycles] Counts each data exchange in ascending order.

[Cycle time]

Indicates how often data is exchanged (in this case, every 0.055 s).

The following lines show the exchanged data with register number.

Press the ESC/EXIT key to return to the previous window.

5.20.6 Browsing the Alibi Memory

Note	A license is required for this function; see Chapter 5.19.8.
	For more information, see 6.2.

5.20.7 Showing Calibration Check Numbers

The overview of corresponding check numbers is displayed under this menu item.


	ition
Show version	
Show status	
Show alarm information	
Show HW options	
Show ModBus-TCP I/O module	
Browse alibi memory	
Show calibration check number	•
Show Pendeo data	
Show event log	
Print configuration settings	
🙀 Calibration check numt	ber @admin
••	
Weighing point A	Pendeo Process
Weighing point A WP serial number	Pendeo Process 2564616265
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number	Pendeo Process 2564616265
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21
Weighing point A WP serial number Last change	Pendeo Process 2564616265 28.11.2014 12:22:21

Select and confirm [System information] - [Show calibration check numbers] using the cursor.

- ▷ The current check number for the weighing points is shown.
- Press the ESC/EXIT key to return to the previous window.

5.20.8 Showing Pendeo data

Information about the Pendeo load cells is displayed under this menu item.




 Select and confirm [System information] - [Show Pendeo data] using the cursor.

🟘 Pendeo data	@admin	Confirm the line.
Show weighing point A	Þ	
· · · ·		

⊲∳]		Show	load c	ell weight	1	@admin
Zer	ro correctio	on				0.00015 t
Cor	nmunicatio	n error	count			1
LC	1	301	0.261	t		
LC	2	303	0.315	t		
LC	3	304	0.027	t		
LC	4	302	0.069	t		
h	nfo by	y name				

[WZ 1...n] Bar graph display



The bar graph shows three areas:

- A = Dead load (can be changed by calibration)
- $B = Nominal load E_{max}$ (max. capacity of load cell) including dead load (load cell, cannot be changed)
- C = Max. usable load including dead load (load cell, cannot be changed)

The colors have the following meanings:

- Red: Weight value is above maximum capacity (overload) or below -1/4 d.
- Green: Weight value is within tolerances.
- Orange: Weight value is above nominal load E_{max} (max. capacity of load cell).

 \triangleright An information windows appears.

[Zero correction]

The zero point correction in use is displayed.

[Communication error count]

The communication errors (time frames exceeded) for the load cells are counted here in ascending order and displayed.

< ∲	Load cell info	@admin
Model name		PR6204/53tC3
Software version		01.00.04
LC serial number		301
Emax		5.0 t
п		3000 e
Y		14000
Z		3000
Overload		50.0 t
Overload counter		0
Temperature		5.8 °C
Max. temperature		5.8 °C
^U Min. temperature		5.7 °C

[Info]

- Select the desired load cell and press [Info] soft key.
- ▷ The load cell data are displayed:

Emax =	Max. capacity
n =	Max. resolution
Y =	Min. load cell verification interval
Ζ =	Factor for dead load output return after load
Overload =	Weight value above usable load
Overload counter =	Number of weight values above max. load
	The higher the number, the higher the probability of a faulty load cell.
Temperature	Current measured temperature
Max. temperature	Max. measured temperature
Min. temperature	Min. measured temperature
Max. weight value	Date and time display
at	Time of largest load on load cells
Max. weight value	Display

[by name]

If names have been assigned under [Calib]-[Assign load cell name], these names are displayed.

[by ID]

Show load cell item number.

Press the ESC/EXIT key to return to the previous window.

	Show load cell weight	@admin
Zero correctio	חכ	0.00015 t
Communicatio	n error count	1
PR 6204-1	0.261 t	
PR 6204-2	0.315 t	
PR 6204-3	0.027 t	
PR 6204-4	0.069 t	
Info	6y 10	

5.20.9 Displaying Event Log

Event logs for the following areas are displayed under this menu item:

- System setup (e.g., user login/logout, calibration, etc.)
- Device (e.g., search for Pendeo load cells)
- Switch on and off (e.g., switch on and off device)
- Errors



5.20.10 Printing Out Configuration Settings

< 4 ∯∰	System information
Show version	
Show status	
Show alarm informa	tion
Show HW options	
Show ModBus-TCP	/O module
Browse alibi memor	У
Show calibration ch	eck number
Show Pendeo data	
Show event log	
Print configuration	settings 🔹 🕨

⊲ ‡¶	System information	@admin
	2	
	and the second	
	Print configuration settings	_
	Press 'Continue' to print all configuration	
	settings. Press 'Cancel' to abort	
	Cancel Continue	-

Requirements

- Print parameters have been entered; see Chapter 5.19.1.4.



- Printer is connected; see Chapter 5.19.1.4.


Procedure

- Select and confirm [System information] [Print configuration settings].
- \triangleright A prompt window appears.
- Press the corresponding soft key.
- ▷ The configuration is printed out; for an example, see Chapter 13.1.

6 Extended Functions

6.1 System Maintenance

6.1.1 General Information



The following functions can be accessed via the [System maintenance] menu.

When user management is activated, the logged in user must have rights for the following:

- Complete system maintenance
- Importing (importing and restoring)
- Exporting (exporting and saving)

6.1.2 Saving to selected Media (Backup)

This function is required to back up the current configuration and/or device database to connected storage devices and/or network share connections.

This may be necessary for one of the following reasons:

- The current data is needed on another device.
- The configuration data is to be archived centrally.
- The configuration and/or database might be deleted accidentally.
- The configuration might be changed inadvertently.

The saved data can be restored later.

The backup stores the data sets in a format that can only be restored via the "Restore" function.

The backup can be saved:

- to the internal SD card,
- to a USB stick, or
- to the shared directories on the network.

Note If ,EXIT' key is pressed during backup stored data is deleted.

System maintenance @admin Backup > Restore Export Import Alibi memory maintenance SD card maintenance SD card maintenance Create service report Shutdown & Power off Update software Factory reset Test hardware	Select and confi [Backup].	rm [System maintenance]-
Select media for backup @admin Attached storage devices SD card SD card > USB stick Network share connections Allibi Backups Exports Reports	A selection wind media. Note	low shows the available storage Connections to the shared fol- ders are only shown when these have been configured under [System setup] - [Network share connections].

Saving to the SD Card (Backup) 6.1.2.1


The back-up is saved to the internal SD card in the event that it will be needed:

- _ on the same device, or
- on a replacement device. _

Select media for backup Attached storage devices SD card USB stick Network share connections Alibi Backups Exports Reports	<u>@admin</u> ▶	 Select and confirm [SD card].
Backup to SD card Select items for backup Setup data Calibration data User management Application data Database tables Start All	Qadmin V V V	 Check the appropriate box or press the [All] soft key to select all possible items. Press the [None] soft key to de-select all selected items.

. ∢ ‡ ¶	Backup to SD card	<u>@</u> admin	\triangleright	An input window appears.
Selec Setu	ct items for backup Ip data oration data			Enter a comment using the keyboard. Press the [Continue] soft key.
Ap Dat	? Enter a comment for this backup. BA	ABC	\triangleright	The progress windows for the individual items appear and then disappear in sequence.
S	Conținue Cancel	e		

Note	The data is stored to the SD card in the folder ,backup':
	/YYYYMMDDHHMMSS/
	Where:
	YYYYMMDDHHMMSS = time of the backup



- As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [System maintenance] menu.

6.1.2.2 Saving to the USB Stick (Backup)

The backup is saved to a USB stick when archiving on a central data carrier is required.

. 4∲ ¶	Sel	ect media for backup	@admin		Select and confirm [USB stick].
Attached SD card	storag	ge devices			
USB stick			•		
Network : Alibi Backups Exports Reports	share (connections			
Note	e	If no USB stick is pluge	ged in, a warnii	ng a	ppears.

Plug in a USB stick and wait until the symbol 🙀 appears in the info line.
Press the [Retry] soft key.

Setup da Calibrati User ma	ion data anagement tion data	Oadmin 2 2 2		A selection window appears. Check the appropriate box 🗹 or press the [All] soft key to select all possible items. Press the [None] soft key to de-select all selected items. Press the [Start] soft key to start the process.
Start		☑ ☑ ☑ ☑ ☑ ☑ ☑	$\land \land \land \land$	An input window appears. Enter a comment using the keyboard. Press the [Continue] soft key. The progress windows for the individual items appear and then disappear in sequence.
Nc	The data is stored to the USI /pr5500/hostname/YYYYMM Where:			

	YYYYMMDDHHMMSS = time of	YYYYMMDDHHMMSS = time of the backup		
4 () Sele	Backup to USB stick @a ect items for backup	dmin	\triangleright	As
	up data bration data 1			Pr m
	Backup completed			

<u>O</u>k

Hostname = device name from the network settings

- > As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [System maintenance] menu.

6.1.2.3 Saving to the shared Folder (Backup)

The backup is saved to a shared directory when archiving on a central data carrier is required.

Note Connections to the shared folders are only shown when these have been configured under [System setup] - [Network share connections]. Badmin Here: Select and confirm [Backups]. Select media for backup Attached storage devices SD card USB stick Network share connections Alibi Backups Exports Reports \triangleright A selection window appears. Qadmin Backup to Backups 440 Select items for backup Check the appropriate box \mathbf{V} or press the Setup data [All] soft key to select all possible items. Press the **Calibration data** ₽ User management [None] soft key to de-select all selected items. Application data 2 Database tables Press the [Start] soft key to start the process. Start All None An input window appears. Backup to Backups Qadmin \triangleright **-**∳¶ Select items for backup Enter a comment using the keyboard. Setup data ø **Calibration** data Z Press the [Continue] soft key. Use Ap Dat ☑ The progress windows for the individual items \triangleright appear and then disappear in sequence. Enter a comment for this backup. 🖷 ABC.. BASIC Continue Cancel Note The data is stored to the network share connection in the folder ,backups': /pr5500/hostname/YYYYMMDDHHMMSS/ Where:

Hostname = device name from the network settings

YYYYMMDDHHMMSS = time of the backup

⊲ ‡¶	Backup to Backups 🔲	admin	C
Sele	ct items for backup		
	up data		
	bration data		
Use	•		
Ар	1		
Dat	.		
	Backup completed		
	Ok		
5,	▼	e	

- As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [System maintenance] menu.

6.1.3 Restoring Backup Data from External Media

This function is required to restore backup data (see Chapter 6.1.2) from external media to device.

Important	During the restoring process, all data selected on the device is overwritten with the data from the backup.
	The following applies:
	 Restoring the setup data will replace all settings and therefore delete all settings made after the backup.
	 Restoring the calibration data will replace the current calibration and therefore delete all calibrations made after the backup.
	 Restoring the user management data will overwrite all users and therefore delete all users created after the backup.
	- Restoring the application data will overwrite all settings and therefore delete all settings made after the backup.
	- Restoring the database will overwrite all tables and entries in the database.


Hestore Restore Export Import Alibi memor SD card mai Create serv Shutdown & Update soft Factory rest Test hardwite	vice report Ромег off ware set	Oadmin.		Select and confin [Restore] .	rm [System maintenance]-
Attached s	Select media for restore storage devices	@admin	\triangleright	A selection wind appears.	ow with available storage media
USB stick	nare connections			Note	The connections to the share folders are only displayed if previously configured under [System setup]- [Network share connections].

6.1.3.1 Restoring Backup Data from SD Card

Select media for restore Attached storage devices SD card USB stick Network share connections Alibi Backups Exports Reports	@admin ►		Select and confirm [SD card].
Restore from SD card	@admin	⊳	A selection window appears.
Select a backup directory to restore lastsetup 4 data file(s) 20141215174311 BASIC 20141215174105 20141119064530 20141119064517 20141119064517	2 from		Select and confirm the corresponding folder.
🐗 Restore from SD card	@admin	⊳	A selection window appears.
Select items to restore. Setup data Calibration data User management Application data Database tables			Check the appropriate box 🗹 or press the [All] soft key to select all possible items. Press the [None] soft key to de-select all selected items. Press the [Start] soft key to start the process.
Start All	None		
Restore from SD card Select items Setup data Calibration dat PR5900 Basic 01.00.05.34 User managem Current loaded application is Application dat PR5500 Basic 01.00.05.35 Database tables	Oadmin C S C C		Should database tables stored on external media not be suitable for current application a warning message appears. If necessary, select a different backup directory or deselect "Database tables".
Start All	None		

Setup	ation data		A prompt window appears. Press [Continue] soft key. The progress windows for the individual items appear and then disappear in sequence.
Setup	ation data		As soon as the process is complete, an info window appears. Press the [OK] soft key to return to the [System maintenance] menu.
SD car USB st	tick ork share connections ps ts	in >	Select and confirm [USB stick].

Note	If no USB stick is plugged in, a warning appears.
	Plug in a USB stick and wait until the symbol 🖬 appears in the info line.
	Press the [Retry] soft key.





Setu	Restore from USB stick Ct items to restore. Up data Doration data Press 'Continue' to restore selected items. Cancel Continue	$\Delta \land \Delta$	A prompt window appears. Press [Continue] soft key. The progress windows for the individual items appear and then disappear in sequence.
4) Selec Setu	Restore from USB stick ct items to restore. up data bration data Restore completed		As soon as the process is complete, an info window appears. Press the [OK] soft key to return to the [System maintenance] menu.

6.1.3.3 Restoring Backup Data from the shared Folder

Ok

Note Connections to the shared folders are only shown when these have been configured under [System setup] - [Network share connections].





secup	Data				P	
Calibra Usc Ap Dat	ation data	?		2 2 2 2 2	⊳	The p appe
	Press 'Continue	' to restore	selected items.	_		
	Cancel		Continue	-		

P

- progress windows for the individual items
- ar and then disappear in sequence.

. ∎ ∳ ¶	Restore from Backups 🛛 🔲 🗠	Idmin
Sel	ect items to restore.	
	up data	
Cal	ibration data	
Use		
Ар		
Dat	1	
	Restore completed	
	Ok	
	JK ▼	

- As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [System maintenance] menu.

6.1.4 Exporting to selected Media

This function is required to export device data to external storage media (e.g. processing of data base tables).

Note Only data saved on the device using the [Save] soft key is exported.

Exported data is saved in XML format. These files can then be opened in an editor (e.g. Windows Notepad) for closer inspection, or to apply an import filter for XML processing software.


Examples

- Exporting all settings and compiling the host names assigned for the network settings to generate a list of device names.
- Exporting all calibration data to generate a report for all weighing points in the system.
- Exporting the database to generate statistics from the REPORT table for the batching software.
- Exporting the alibi memory to archive alibi entries for long-term storage.

Note	The export data is stored to external storage media in the following folder:			
	/pr5500/hostname/YYYYMMDDHHMMSS/			
Where:				
Hostname = device name from the network settings				
	YYYYMMDDHHMMSS = time of the export			

	System maintenance	@admin
Backup		
Restore		
Export		•
Import		
Alibi memory	maintenance	
SD card maint	enance	
Create servic	e report	
Shutdown & P	ower off	
Update softwa	are	
Factory reset	t	
Test hardwar	e	

 Select and confirm [System maintenance]-[Export].



Note	The connections to the share folders are only displayed if previously configured under
	[System setup]- [Network share connections].

6.1.4.1 Exporting Data to USB Stick

USB stick	Select media for d storage devices share connections	export Dadr	Select and confirm [USB stick].	
No		tick is plugged in, a wa a USB stick and wait	appears. e symbol 📌 appears in the info line.	

Press the [Retry] soft key.


Select items of Setup data Calibration data User managem Application data Database table	a ent ta	Qadmin 2 2 2 2	 A selection window appears. Check the appropriate box or press the [All] soft key to select all possible items. Press the [None] soft key to de-select all selected items. Press the [Start] soft key to start the process.
Start	All	None	1

4 @	Export to USB stick		\triangleright	An input window appears.
Select Setup	t items for export data			Enter a comment using the keyboard.
	ation data	V		Press the [Continue] soft key.
Ap Dat	?	2	\triangleright	The progress windows for the individual items appear and then disappear in sequence.
	Enter a comment for this export. 🖷 A BASIC	BC		appear and creat asappear in sequences
	Conținue Cancel e			
	Export to USB stick @adr t items for export	<u>min</u>	\triangleright	As soon as the process is complete, an info window appears.
Use	data ation data 			Press the [OK] soft key to return to the [System maintenance] menu.
Ap Dat _	export completed	N		

6.1.4.2 **Exporting Data to shared Folder**

Ok

Connections to the shared folders are only shown when these have been configured under Note [System setup] - [Network share connections].



4 00	Export to Exports	🛛 admin	 An input window appears.
Select if Setup da Calibrati Usc Dat	en data Enter a comment for this export.	EASIC	 Enter a comment using the keyboard. Press the [Continue] soft key.
Select if Setup da Calibrati Usc Ap Dat			window appears.

6.1.5 Importing Data from External Media


This function is required to import the exported data (or e.g. database tables generated by the PC) on device. Data to be imported must be in XML format. The format must be the same as that of exporting. The data can be created manually (using e.g. Windows Notepad) or via software export with known format.

Examples


- Creating operating parameters to make the parameters for all devices available in the system.
- Providing data for user management to ensure the same access rights for all devices.
- Providing a new tare table every day for the BASIC application.

Important	During the importing process, only data present in the data set being imported will be overwritten.						
	 The following applies: Importing the setup data will only replace the settings present in the data set. For example, if the data set only contains operating parameters, the other settings will remain unchanged. 						
	 Importing the calibration data will only replace the calibration values present in the data set. 						
	- Importing the user management data will only replace the settings present in the data set. For example, if the data set only contains new users, the existing users will remain unchanged.						
	- Importing the application data will only replace the settings present in the data set. For example, if the data set only contains print parameters, the other settings will remain unchanged.						
	- Importing the database tables will only replace the tables present in the data set. If the data set contains the tare table only, the text table will remain unchanged in the device; the tare table will be overwritten completely however.						

SD card n Create se	eset	<u>@</u> admin ►	Select and confir [System mainten	
USB stick	Select media for import d storage devices share connections	<u>@</u> admin ►	A selection windo appears. Note	ow with available storage media The connections to the share folders are only displayed if previously configured under [System setup]- [Network share connections].
- 4 00	Importing Data from USB Stick Select media for import d storage devices	@admin	Select and confir	m [USB stick].




Note
If no USB stick is plugged in, a warning appears.
Plug in a USB stick and wait until the symbol n appears in the info line.
Press the [Retry] soft key.




Setup dat Calibratio Usc Ap Dat	Oadmin 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	$\Delta \land \Delta$	A prompt window appears. Press [Continue] soft key. The progress windows for the individual items appear and then disappear in sequence.
Select it: Setup dai Calibratio Usc Ap Dai	admin 2 2 2 2 2		As soon as the process is complete, an info window appears. Press the [OK] soft key to return to the [System maintenance] menu.

6.1.5.2 Importing Data from the shared Folder

Note Connections to the shared folders are only shown when these have been configured under [System setup] - [Network share connections].





. ∢ ‡ ¶	Import from Exports 🛛 😡 a	dmin
Sele	ct items to import	
Set	up data	
Cali	bration data	\checkmark
Use		
Ap	i i i i i i i i i i i i i i i i i i i	
Dat	1	
	Import completed	
	Ok	
	UK T	

6.1.6 Alibi Memory Maintenance

This function is required to:

- export a selection of data records from the Alibi memory to a storage media in XML format.
- export a selection of data records from the Alibi memory to a storage media in XML format and then delete the data on the device.
- print a selection of data records.
- print a selection of data records and then delete the data on the device.

4∲ ¶	System maintenance	@admin
Backup		
Restore		
Export		
Import		
Alibi mem	ory maintenance	•
SD card m	aintenance	
Create se	rvice report	
Shutdown	& Power off	
Update so	ftware	
Factory r	eset	
Test hard	Male	

 Select and confirm [System maintenance]-[Alibi memory maintenance].

 \triangleright As soon as the process is complete, an info


Press the [OK] soft key to return to the [System

window appears.


maintenance] menu.

6.1.6.1 Exporting a Selection of Data Records

This function is required to export a selection of data records to a storage media.



- \triangleright A selection window appears.
- Select and confirm [Export selection of records].



	10 12 on	The window reappears, now displaying the sequence number for the selected data record (in this case, 10) under [First sequence number]. Repeat the process to choose the last sequence number. Select the output parameters.
Export Browse		[Compression] Selection: <no compression="">, Best speed (reduced size by a factor of ~10, requires ~10 % longer), Best compression (reduced size by a factor of ~20, requires ~70 % longer)</no>
		[Destination] Selection: USB stick, network share connections (configured under [System setup] - [Network share connections])
		Press the [Export] soft key to start the export.
	10 12 on	A prompt window appears. Press the [Continue] soft key.
Ex Cancel Continue se		
NoteIf no USB stick is plugged in, a wa▶Plug in a USB stick and wait u▶Press the [Retry] soft key.	5	ppears. e symbol 🔁 appears in the info line.
Export alibi records Dadm Select alibi records to export First sequence number	<u>nin</u> ⊳ 10 ⊳	The XML file is saved to the USB stick. As soon as the process is complete, an info window appears.

se

Press the [OK] soft key to return to the [Alibi memory maintenance] menu.

Ex

Alibi export completed.

Ok

Note	Storing on the USB stick
	The exported data is stored on the USB stick in the corresponding folder:
	/export/hostname/alibi
	Where hostname = device name from the network settings
	The file name is created from the date, time, sequence number range in brackets and the file extension, e.g., 2014032014332317 [27-139].xml.
	Storing in network share connection
	The exported data is stored in a network share connection.
	The file name is created from the date, time, sequence number range in brackets and the file extension, e.g., 2014032014332317 [27-139].xml.

6.1.6.2 Exporting and Clearing a Selection of Data Records

This function is required to export a selection of data records to a storage media and then delete the data on the device.

Alibi memory maintenance @admin Export selection of records Export + tidy up selection of records Print selection of records Print + tidy up selection of records	 A selection window appears. Select and confirm [Export + tidy up selection of records].
Export + clear alibi records Select alibi recor 20.11.2014 17:47:24 First sequence number 1 Last sequence number 12 Select output Compression Compression No compression Destination USB stick Export Browse	A window appears, displaying the available export range. The first data record in the range is automatically selected and cannot be changed.
Export + clear alibi records Select alibi records to exnort First sequence num 16.12.2014 11:24:37 1 Last sequence number 12 Select output Compression No compression Destination USB stick Export Browse	Select [Last sequence number] and press the [Browse] soft key to search for the last data record in the range.

∢†e Year Month Day	Select record to export 2014 Dec 16	by date. 12 records 7 records 7 records		A selection window appears. Confirm the selection.
Show 11.2014 12.2014	Colort conord to evonrt	by date 5 records 7 records		A selection window appears. Confirm the selection. Press the [Show] soft key.
STIUM SEQUENCE N WP serial nu ID G NET T Previous		date. Qadmin C3/71 16.12.2014–11:22:20 8 2564616265 <0.220 t> <0.220 t> 0.000 t +10 Select	• •	Press the [Previous]/[Next] soft key to view the desired data record. Press the [Select] soft key to choose the last data record in the range.

Export + clear alibi records Dadmin Select alibi records to excort First sequence num First sequence number 1 Last sequence number 8 Select output 8 Compression No compression Destination USB stick	The window reappears, now displaying the sequence number for the selected data record (in this case, 8) under [Last sequence number]. Repeat the process to choose the last sequence number. Select the output parameters.
Export Browse	[Compression] Selection: <no compression="">, Best speed (reduced size by a factor of ~10, requires ~10 % longer), Best compression (reduced size by a factor of ~20, requires ~70 % longer)</no>
	[Destination] Selection: USB stick, network share connections (configured under [System setup] - [Network share connections])
	Press the [Export] soft key to start the export.
Export + clear alibi records @admin Select alibi records to export 1 First sequence number 1 Last sequence number 8 Select 8 Cor 7 Des 1 Insert an USB stick and press 'Continue' to export alibi records. Press 'Cancel' to abort. sion Ex Cancel Continue Ex x x	A prompt window appears. Press the [Continue] soft key.

Note	If no USB stick is plugged in, a warning appears.
	Plug in a USB stick and wait until the symbol ¹ appears in the info line.
	Press the [Retry] soft key.
	Press the [Retry] soft key.

0k

First	Export + clear alibi records Oadmin ct alibi records to export sequence number 1 sequence number 8	\triangleright	The XML file is saved to the USB stick. A progress window appears during the save process.
Cor Des	? sion tick	\triangleright	A prompt window appears.
	Export of alibi records is completed. Press 'Clear' to remove exported records in alibi memory.		Press the [Clear] soft key to remove the exported data records from the Alibi memory.
E×	Clear Cancel se		
4∲ ¶	Export + clear alibi records @admin	\triangleright	As soon as the process is complete, an info
	st alibi records to export		window appears.
Last	sequence number		Press the [OK] soft key to return to the [Alibi
Selc - Cor	sion		memory maintenance] menu.
Des	L itick		
	Remove alibi records completed.		

Note	Storing on the USB stick
	The exported data is stored on the USB stick in the corresponding folder:
	/export/hostname/alibi
	Where hostname = device name from the network settings
	The file name is created from the date, time, sequence number range in brackets and the file extension, e.g., 2014032014332317 [27-139].xml.
	Storing in network share connection
	The exported data is stored in a network share connection.
	The file name is created from the date, time, sequence number range in brackets and the file extension, e.g., 2014032014332317 [27-139].xml.

Ex

6.1.6.3 Printing a Selection of Data Records


This function is required to print a selection of data records.

Requirements

Printer is connected; see 5.19.1.4

Note If no printer has been connected, the message "No printer configured" appears.

Procedure



Celect first record to print 01.2015 4 records 02.2015 5 records	 A selection window appears. Confirm the selection. Press the [Show] soft key.
Select first record to print 02.02.2015 11/51 Date/Time 02.02.2015-10:55:29 Sequence number 31 WP serial number 464605997 D 6 A <2516.40 g> NET A T A 0.00 g T	 Press the [Previous]/[Next] soft key to view the desired data record. Press the [Select] soft key to choose the first data record in the range.
Print alibi records Select alibi records to orint First sequence num D2.02.2015 11:11:28 31 Last sequence number # 35	 The window reappears, now displaying the sequence number for the selected data record (in this case, 31) under [First sequence number]. Repeat the process to choose the last sequence number. Press the [Print] soft key to start the printout. A progress window appears during the print process.
Print alibi records Select alibi records to print First sequence number 31 Last sequence number 35 I Alibi print completed. Ok	 As soon as the process is complete, an info window appears. Press the [OK] soft key to return to the [Alibi memory maintenance] menu. For an example of an Alibi printout; see Chapter 13.3.

6.1.6.4 Printing and Clearing a Selection of Data Records


This function is required to print and clear a selection of data records.


Requirements

Printer is connected; see Chapter 5.19.1.4.

Note If no printer has been connected, the message "No printer configured" appears.

Procedure





. 4∲ ¶	Print + clear alibi records	
Select a	alibi records to print	
First se	quence number	23
Last se	quence number 🕴 🚺	25
	1	
_		
	Remove alibi records completed.	
	Ok	
P	•	se

- As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [Alibi memory maintenance] menu.


6.1.7 SD Card Maintenance


₩ .	System maintenance	@admin	
Backup			
Restore			
Export			
Import			
Alibi men	nory maintenance		
SD card r	naintenance	•	
Create se	ervice report		
Shutdowr	n & Power off		
Update s	oftware		
Factory	reset		
Test har	Jware		

Select and confirm [System maintenance]-[SD card maintenance].

6.1.7.1 Formatting the SD Card

This function is required to format the SD card or delete backups that are no longer needed.





6.1.7.2 Cleaning Up Backups

This function is required to view backups on the SD card and delete them if necessary.

NoteAccess to the SD card slows down considerably if too many backups are saved to the card.If more than 100 backups are saved to the card, not all backups will be accessible.

4 ∲¶	SD card maintenance @admin			Select and confirm [Cleanup backups].	
Maintenance level for the SD card Format SD card Cleanup backups		•		Note	The newest three backups cannot be deleted.
	· · ·				
₩	Cleanup backups	@admin	\triangleright	A selection wir	ndow appears.
Select backups to remove. 20141215174311 20141215174105 20141119064530 20141119064517				Check the appr soft key to sele	ropriate box \blacksquare or press the [AII] ect all possible items. Press the y to de-select all selected items.
201111000				Press the [Rem selection.	ove] soft key to delete the
				Press the ESC/E maintenance]	EXIT key to return to the [System menu.
Remove	All	None			

6.1.8 Creating a Service Report

This function is required to generate a service report file with the following data:

- All system setup data
- All user management data
- All I/O card data
- Statistics on database and Alibi memory usage
- Error logs
- Logs (audit trails)
- Log files

This file can be sent to customer service for analysis in the event of technical queries.

Note	For contact info; see Chapte	er 1.		
			Select and confi	
Backup Restore Export Import Alibi memory SD card main Create servic Shutdown & F Update softw Factory rese Test hardwar	е report Ромеr off аге t	<u>@admin</u> ▶	Select and confi [System mainter	rm nance]-[Create service report].
Attached st USB stick	lect media for service report orage devices are connections	©admin ▷	A selection wind appears. Note	low with available storage media The connections to the share folders are only displayed if previously configured under [System setup]- [Network share connections].
		•	Here: Select and	confirm [USB stick].
Note	If no USB stick is plugged in ▶ Plug in a USB stick and ▶ Press the [Retry] soft keep	wait until th		ars in the info line.


4 👸	Create service report on USB stick	<u>O</u> admin
Attached storage devices		
USB	stick	Þ
	work share connections	
Ali⊦		1
Bac	i i i i i i i i i i i i i i i i i i i	
E×	1	
Ref	Service report completed.	_
		-
	Ok	


- The service report file (PR5500-servicereportdevicename-date + generated number.xml) is saved to the "Service reports" folder on the storage media (here: USB stick).
- As soon as the process is complete, an info window appears.
- Press the [OK] soft key to return to the [System maintenance] menu.
- Remove the USB stick from the device and insert in a PC to send the file to customer service via e-mail.


6.1.9 Switching Off the Device

This function is required to disconnect the device from the power immediately, e.g., to install an option card. Before switching off, all data are stored on the SD card and automatically restored again after switching on.

- The battery will be deactivated immediately.
- The application will be closed.







6.1.10 Updating the Software

6.1.10.1 General Information

This function is required to install up-to-date software on the device.

The following options are available:

There are two ways to update the software:

- via soft key (one click software update)
- via menu

6.1.10.2 One Click Software Update

This function can be used if new software versions from a department are provided on the company's central network and these should be easily installed by an authorized operator.

To execute the software update via soft key, the following requirements must be met:

- Network share connection ,ONECLICKUPDATE' is created under [System setup] – [Network share connections].
- The files, if they exist, must have the following names:
 - pr5500-r01-bios.bin
 - pr5500-r01-firm.bin
 - pr5500-appl.bin
 - pr5500-labl.bin (optional)
- The parameter [W&M] must be set to ,none'.
- The parameter ,Settings locked' is deactivated.
- The CAL switches are open.

- If no SD card is inserted or the SD card is not detected, a prompt window will appear.
- Press the [Cancel] soft key to avoid data loss.
- Insert the SD card and confirm the line [Shutdown & Power off].
- ▷ A prompt window appears.
- Press the [Continue] soft key.
- Disconnect the power plug.

† 9	Operating	@admi	n 🕨	Press [Up	odate] soft key in the operating menu.
Weig Chec	k weighing				
	ce employed as terminal iguration				
	em menu				
Syst	tem setup	•			
	tem information tem maintenance				
3751					
Loge	out	. Update			
4 ∲¶	One click software u	odate @admi		A promp	t window appears.
				The insta	lled and available software is listed.
	2			green:	Installed and availabled versions are t
	?			green:	Installed and availabled versions are t same.
	Installed software:				same.
	Passee-Bios 00.11.01-trunk.246425 PRSS00-Bios 00.11.01-trunk.246425 PRSS00-Bios 00.11.01-trunk.246425	2014-11-28-10-17-10 2014-12-19-07-42-31 2014-12-19-07-42-31		red:	same. Installed and availabled versions are
	Presson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Resson Reso	2014-11-28-10-17-10 2014-12-10-0742-31 2014-11-21-10-10-4 2014-11-21-10-10-4			same.
	PR5500-Fino 90.11.01-trunk.246425 PR5500-Fino 90.11.01-trunk.247256 PR5500-Appl-Basic 01.00.05.35 Available software: PR5500-Fino 90.11.01-trunk.247433 PR5500-Fino 90.11.01-trunk.247433	2014-11-28-10-17-10 2014-12-10-0742-31 2014-12-10-0742-31 2014-12-15-10-1041 2014-12-5-10-104-0 2014-12-5-14-12-90 2014-12-5-14-12-90	•	red:	same. Installed and availabled versions are
	PR5500eFios 001101+trunk.246425 PR5500eFine 001101+trunk.247256 PR5500eFine 001101+trunk.247256 PR5500-Bois 001101+trunk.247433 PR5500-Bois 001101+trunk.247433 PR5500-Hpp1-Basic 0100.04.28	2014-11-21-18:18:41 2014-12-15-07:45:31 2014-12-15-19:15:49 2014-03-28-11:44-03		red: Press [Up	same. Installed and availabled versions are different. odate] soft key.
	PR5500-Fino 90.11.01-trunk.246425 PR5500-Fino 90.11.01-trunk.247256 PR5500-Appl-Basic 01.00.05.35 Available software: PR5500-Fino 90.11.01-trunk.247433 PR5500-Fino 90.11.01-trunk.247433	2014-11-21-10-10-41 2014-12-15-07-45-31 2014-12-15-14-15-49	▶ △	red: Press [Up A databa	same. Installed and availabled versions are different. odate] soft key. ise backup is stored to a temporary fold
	PR5500eFios 001101+trunk.246425 PR5500eFine 001101+trunk.247256 PR5500eFine 001101+trunk.247256 PR5500-Bois 001101+trunk.247433 PR5500-Bois 001101+trunk.247433 PR5500-Hpp1-Basic 0100.04.28	2014-11-21-18:18:41 2014-12-15-07:45:31 2014-12-15-19:15:49 2014-03-28-11:44-03		red: Press [Up A databa on the SI	same. Installed and availabled versions are different. odate] soft key. use backup is stored to a temporary fold

6.1.10.3 Software Update via Menu

The following options are:

- Update from SD card _
- Update from USB stick _
- Update via network share connection _
- Update via FlashIt! _
- Restore software from SD card _

4∲ ¶	System maintenance	<u>@</u> admin
Backup		
Restore		
Export		
Import		
Alibi men	nory maintenance	
SD card r	naintenance	
Create se	rvice report	
Shutdowr	& Power off	
Update s	oftware	•
Factory	reset	
Test har	Jware	

- are the
- are
- folder
- \triangleright The software is loaded onto the device.
- \triangleright The device runs a cold start.
- ▷ The database is restored from the temporary backup.


Select and confirm [System maintenance]-[Update software].



- **\squareadmin** \triangleright A selection window appears.
 - ▶ Select and confirm [Update software].

Update from SD card


This function is required to restore a software version stored on the SD card.




♦ Update software from SD card @admin	A selection window appears.
Installed software PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-12-10-07:42:31 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. Sol card Select software to update from SD card 2014-11-28-10:17:10 PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-11-21-10:10:41 RS500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 keep no Labels keep no Labels	 Here is the software installed on the device and the delivery status of the software listed. Select software see page 323. Press [Start] soft key to start the updating.
🟘 Update software from SD card 🛛 🔍 admin	A prompt window appears.
	Press [Continue] soft key.
	▷ The software are updated on the device.
?	▷ The device runs a cold start.
Press 'Continue' to update selected software from SD card.	
Cancel Continue	

Update from SD card (factory data)

This menu item is selected to restore the delivery status of the software.





Note The software file names may not be changed! 🟘 Speichermedium für Software-Aktual. ausw. 🛛 🔯 🖓 🎰 Requirement Verbundene Speichergeräte The USB stick has been plugged into the device. SD-Karte SD-Karte (Fabrikeinstellungen) USB-Stick Procedure Þ Netzwerkfreigabeverbindungen Select and confirm [USB stick]. Alibi Backups Exports ONECLICKUPDATE Reports Note If no USB stick is plugged in, a warning appears. Plug in a USB stick and wait until the symbol 妃 appears in the info line. Press the [Retry] soft key. ▷ A selection window appears. The displayed 4 🎒 🛛 Update software from USB stick Oadmin Select binary files to use for update content is an example. USB stick : / Here: Select and confirm [Software]. 🗇 Reports 🗇 Servicereports 🗇 backup 🗇 export 4 binary file(s) 🗇 pr5500 📋 software \triangleright A selection window appears. Update software from USB stick Oadmin **4 🕘** . Select binary files to use for update ▶ Here: Select and confirm [4 binary files]. USB stick : //software 🗒 4 binary file(s)

Update from USB stick

Update software from USB stick Dadmin Compressed files (.biz) found. It will take some more time to read them. Continue to read biz files? Yes	 There are BIZ files on the storage media: ▶ A prompt window appears. ▶ Press [Yes] soft key.
Update software from USB stick Dadmin	\triangleright A selection window appears.
Installed software PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-12-10-07:42:31 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. Select software to update from USB stick PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. keep current Bios PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. keep current Bios Start Start	 A selection window appeals. Here is the software installed on the device and the software stored on the USB stick listed. Are different versions available, the version to be installed can be selected. Note Check versions: If e.g. Firmware 02.10 is combined with Bios 02.00 the update can't be started.
Update software from USB stick Oadmin Installed software PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-12-10-07:42:31 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. Select software to update from USB stick PR5500-Bios 00.11.01-trunk.247483 2014-12-15-14:15:49 PR5500-Firm 00.11.01-trunk.247483 2014-12-15-14:15:49	 Here: Bios and Firmware are to be updated and the application is to be kept. ▶ Select and confirm the third line.
Start Hodate software from USB stick Madmin Resp current Application PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41	 A selection window appears. Select and confirm the corresponding line.

😋 Update software from USB stick @admin	Press [Start] soft key to start updating.
Installed software PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-12-10-07:42:31 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. 2014-12-15-14:15:49 Select software to update from USB stick PR5500-Bios 00.11.01-trunk.247483 PR5500-Firm 00.11.01-trunk.247483 2014-12-15-14:15:49 Start Start	
내 Update software from USB stick @admin	▷ A prompt window appears.
	Press [Continue] soft key.
2	Bios and Firmware are updated on device. The application is kept.
Press 'Continue' to update selected software from USB stick.	\triangleright The device runs a cold start.
Cancel Continue	

Update via network share connection

To update the software via a network share connection, the following requirements must be met:

- Network share connection has been created under [System setup] [Network share connections]; see Chapter 5.19.5.
- The software files must be located in the directory (here: ,Software') on the Notebook/PC.

Attached sto SD card		odate software s	<u>@</u> admin
SD card	rage device	:5	
SD card (factor USB stick	ry uata)		
Network shar	e connectio	ns	
Alibi	e connectio		
Backups			
Exports			
ONECLICKUPDAT	ΓE		
Reports			
Software			▶
📢 Upda	ate software f	rom Software	@admin
Select binary	files to use	e for update	
Software : /			
🗑 4 binary file	(s)	_	•
			•

 Select and confirm network share connection [Software].

- \triangleright A selection window appears.
- ▶ Here: Select and confirm [4 binary files].

🙀 Update software from Software 🛛 @admin	A selection window appears
Installed software PR5500-Bios 00.11.01-trunk.246425 2014-11-28-10:17:10 PR5500-Firm 00.11.01-trunk.247256 2014-12-10-07:42:31 PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 No Labels installed. Select software to update from Software keep current Firmware keep current Firmware • PR5500-Appl-Basic 01.00.05.35 2014-11-21-10:10:41 start Start	 Here is the software installed on the device and the software stored in network share connection (folder ,Software') listed. Select software see page 323. Press [Start] soft key to start the updating.
🐗 Update software from Software @admin	A prompt window appears.
	Press [Continue] soft key.
	The software are updated on the device.
?	\triangleright The device runs a cold start.
Press 'Continue' to update selected software from Software.	
S Cancel Continue	

Update via FlashIt!

2

Press 'Continue' to update software via FlashIt!.

Cancel

Wait for FlashIt!

lpAddr=172.24.20.111

Continue

Update so Update via Remove a Restore so	a Flashit!	@admin ►	 Requirements The program "FlashIt!" (on the accompanying CD) is installed on the notebook/PC. The device is connected to the notebook/PC directly or via network. The software files are stored on the notebook/PC.
	Update software via Flashlt!	Qadmin	Procedure

 \triangleright A prompt window appears.

▶ Press the [Continue] soft key.

EN-326

- \triangleright A window appears on the display.
- ▷ The device waits for the update to start on the notebook/PC.

A Flashiti32	The files are installed in the following order:
Project Options Help	- PR5x00-Firm xx
Firmware Elash Select PR5x00 Bios 00.02.00.biz => \\hhubbld01\builds\pr5x00\ Image Info PR5x00-Bios 00.02.00.138588 2012-08-14-11:56:14 Merge Exit Exit Exit	 PR5x00-Bios xx (only when required for firmware) Applikation (PR5x00-Basic xx in this case)
Application Select I* no application* Info Flashtl32 02.73.01	Double-click the corresponding file in the "Explorer."
Print Label Build 119566 Select * no labels * Label	 "FlashIt!" opens and the file is displayed next to [Select].
Translation COM-Port	Select [Network].
Select * no translation *	Enter the device IP address (shown in the window on the device display).
	Click [Flash] to start the procedure.
FlashIt!32	A confirmation prompt appears when the Bios is updated.
Con Last Warning!	Click [OK].
You are about to erase and reprogram your bios	▷ The process starts now.
Do not abort or disconnect until procedure is complete	The window appears on the device display after the file has been loaded onto the device.
	The next files can then be loaded.
OK Abbrechen	After the last file has been loaded, the window appears again on the device display.

- \triangleright Press the Exit key to stop the flash process.
- \triangleright The device runs a cold start.

Remove application

This function is required to remove the available application with all specific settings and database tables. This is essential during the development of own applications to be loaded into device via PR 1750.

Upda Remo	Update software te software te via Flashit! ove application ore software from SD card	@admin ►	A selection window appears. Select and confirm [Remove application].
.	Remove application P Menu item 'Remove application' will - delete application software, - remove all application settings, - remove all tables from database, - restart the system.	<u>@admin</u>	A confirm window appears. Press [Continue] soft key. Application, settings and database tables are removed. The device runs a cold start.
	Cancel Continue		

Restore software from SD card

This function is required after the SD card has been inserted into a replacement device. The application software with corresponding settings and database tables are loaded into device without any confirmation, see also Chapter 13.7.

Updat Remo	Update software Oad re software re via FlashIt! ve application re software from SD card	A selection window appears. Select and confirm [Restore software from SD card].
- -	Restore software from SD card	A confirm window appears. Press [Continue] soft key. Application software, settings and database tables are loaded into device. The device runs a cold start.

6.1.11 Resetting the Device to the Factory Settings

Note	The device can only be reset to the factory settings when overwrite protection is deactivated;
	see Chapter 5.1.5.


. 4∲ ¶	System maintenance 🛛 🔲 ad	min
Bac		
	tore	
E×p		
Imp		
	i memory maintenance card maintenance	
	ate service report	
	tdown & Power off	
	ate software	
Fact	tory reset	
Tes	t hardware	
	· · · · · · · · · · · · · · · · · · ·	
4 0-1	Factory reset Oad	min
110		
	7	
	Shall all parameters be set to default values?	
	Yes No	

This function is required to reset the device to the factory settings:

- All calibration data
- All system settings (including licenses and user management)
- All Alibi memory records
- All database tables
- Select and confirm [System maintenance]-[Factory reset].
- \triangleright A prompt window appears.
- Press the [Yes] soft key.
- \triangleright The device restarts with the factory settings.

6.1.12 Hardware Test


This function is required to test the display, keys, and I/O cards.




6.1.12.1 Display Test

. 4∲ ¶	Test hardware	<u>O</u> admin	\triangleright	A selection window appears.
Display test Keyboard test I/O cards test		>		Select and confirm [Display test].
	==== Display test ==== [13] Basic colors [46] Secondary colors [78] black & white [9] Border [0] Palette [0] Palette [0k] Return to test menu			An info window appears. Press the corresponding keys to test the display. Press the ESC/EXIT key to return to the test menu.

6.1.12.2 Keyboard Test






÷Τ۰

e 👌 🛃

- When all keys have been checked off, an info window appears.
- Press the ESC/EXIT key three times to return to the test menu.



▷ Errors are displayed by crosses and question marks in red/yellow.

Display	Cause
red/yellow cross	Keys are bridged (e.g. short circuit in keypad foil).
red/yellow question mark	Unknown key position (e.g. keypad connection plugged wrong)

- Press the ESC/EXIT key three times to return to the test menu.
- \triangleright A selection window appears.
- ▶ Select and confirm [I/O cards test].

- Eingangs-/Ausgangskarten-Test **₩** Oadmin Intern Option–1 R5232 ▶ R5-485/R5-485 PR5500/04 PR5500/17 Digital E/A Option-2 Option-FB -leer-WP A PR5500/W1 Wägeelektronik
 - \triangleright A selection window appears. The test process differs depending on the function of the card.

There are several modes for the analog and digital I/O cards test:

- Test mode 1 "Monitor" _
- Test mode 2 "Intern"
- Test mode 3 "Extern"


Note	If a card is not being used by the application currently loaded, test mode 3 "Extern" is
	selected automatically. The "Monitor" and "Intern" test modes are not available in this case.

Oadmin

6.1.12.3	I/O Card Test
.	Hardware testen

Anzeigetest

Tastaturtest E/A-Kartentest



Active PLC:


- The physical inputs of the system (plant) are directed to the PLC (application).
- The physical outputs of the system (plant) are set by the PLC (application).
- The physical inputs and outputs are displayed (display).

Active PLC:

- The entered input values are sent to the PLC (application).
- The PLC output is displayed (display).
- The physical inputs and outputs of the system (plant) are deactivated and passive (in secured condition).

Test mode 3

Application



Plant

Outputs

Deactivated PLC:

- The physical inputs are displayed (display).
- Output values can be entered.
- The given output values are set on the physical outputs.

Example: PR 5500/W1

4 44	Test I/O–Cards	@admin
Built–in		R5232
Option-1	PR5500/04	RS-485/RS-485
Option-2	PR5500/17	Digital I/O
Option-FB		_empty_
MP A	PR5500/W1	weighing electronic 🕨
	· · · · ·	· · · · · · · · · · · · · · · · · · ·

_ +	0.0]3 🔋
< ₩	Test I/O–Cards	@admin
HP A Gross Net Tare Zero correction InputVoltage Dead load voltage	PR5500/W1weigt	ning electronic 0.03 g 0.00 g 0.0000 g 0.040694 % 0.040682 %
10x Res. Analog	test	

	3000.0)5
	Test I/O-Cards	@admin
WP A Gross	PR5500/W1weigh	ing electronic 3000.05 g
10× Res.	Analog test	

- \triangleright A selection window appears.
- Select the desired card and confirm.

 \triangleright An info window appears.

[Gross], [Net], [Tare] Display the current values.

[Zero correction]

Displays the zero set range already used.

[InputVoltage]

The displayed value x input voltage (e.g., 12 V) gives the value to be measured; see Chapter 4.4.4.6.

[Dead load voltage]

Displays the value calibrated for the dead load.

- ▶ Press the [Analog test] soft key.
- \triangleright An info window appears.
- Press the [10x Res.] soft key if necessary to display the weight value in an increased resolution (10-fold).

Press the soft key again to switch off the increased resolution (10-fold).


Press the ESC/EXIT key to return to the card test menu.

Adapting the Analog Output: PR 5500/07

The output current can be adjusted in small ranges. This is required, if small deviations from the nominal value occur in a connected PLC.

	Test I/O-Cards		 A selection window appears.
Built-in Option-1 PR5500/0 Option-2 PR5500/0 Option-FB WP A PR5500/4	7 4	R5-232 5/R5-485 Analog I/O > -empty- electronic	 Select the desired card and confirm.
Antion 2 DDEE00/0	Test I/O-Cards		
Option-2 PR5500/0 in use by PLC task		Analog I/O 3	is active.
Test mode Analog output, curre Analog input 1, curre Analog input 2, volta	int	Monitoring 0.000 mA 0.001 mA 0.000 V	Press the [Extern] soft key.
Monitor Intern	Extern		
4 01	Test I/O-Cards	Analog I/O	
	Test I/O-Cards 7	Analog I/O 3 xternal test 0.000 mA 0.001 mA 0.000 V	is active.
Option-2 PR5500/0 in use by PLC task Test mode Analog output, curre Analog input 1, curre	Test I/O-Cards 7	Analog I/0 3 xternal test 0.000 mA 0.001 mA	is active.
Option-2 PR5500/0 in use by PLC task Test mode Analog output, curre Analog input 1, curre Analog input 2, volta Monitor Intern	Test I/O-Cards 7 nt B nt ge	Analog I/0 3 *ternal test 0.000 mA 0.001 mA 0.000 V	is active. • Press the [Adjust] soft key.

	Adjust Analog	Output Option-2	
Output			20.0 🖲 123
Measured			19.856 mA



- 1	Test I/0-	-Cards	
Option-2 PR550			Analog I/0
in use by PLC t	ask	_	3
Test mode		E×	ternal test
Angles subsub-			- 0.000 mA
An	- 7		mA
An			po v
	Reset to de	fault?	
Ma Ye	25	No	et

- An info window appears for the second value (20 mA).
- ► Enter the value for 20 mA (measured, for example, by the connected PLC) under [Measured].

- \triangleright A prompt window appears.
- ▶ Press the [Yes] soft key to save the settings.

- Press the [Reset] soft key to reset to the factory settings (4 mA and 20 mA).
- \triangleright A prompt window appears.
- Press the [Yes] soft key to reset to the factory settings.
- Press the ESC/EXIT key to return to the card test menu.

Example: PR 5500/17

Image: Market Marke	 A selection window appears. Select the desired card and confirm.
Test I/O-Cards Oadmin Option-2 PR5500/17 Digital I/O in use by PLC task 3 Test mode Monitoring Digital Outputs 00000011 Digital Inputs 000000	 An info window appears. The test mode 1 is active. The current input and output values from the PLC (application) are displayed; see "Test mode 1". Note If the option is not used by the application, the test mode 3 is active and the values cannot be changed.
Monitor Intern Extern Test I/O-Cards @admin Option-2 PR5500/17 Digital I/O in use by PLC task 3 Test mode Internal test Digital Outputs 00000011 Digital Inputs 0000000	 Set the input values via keyboard and confirm. Input: 0 and 1 (e.g.: 1111; 0010)
Monitor Intern Extern Intern Extern Intern Extern Intern Digital I/O In use by PLC task 3 Test mode External test Digital Outputs 00000011 Digital Inputs 0000000 Monitor Intern Extern Extern	 Press the [Extern] soft key. Set the output values via keyboard and confirm. Input: 0 and 1 (e.g.: 1111; 0010) An info window appears. The "External test" mode is active. The physical inputs and outputs (hardware) are tested without the involvement of the PLC (application); see "Test mode 3". Press the ESC/EXIT key to return to the card test menu.

6.1.13 Functions via the WEB Site

If the device is connected to the network, this can be displayed through the UPnP view (see Chapter 5.6.1).

	sartorius
PR5500 Maxxds 4 (PR5500-967EA9)	
Configuration • Remote configuration (VNC) • Remote configuration (VNC) pop-up window • Configuration printout View • Indicator • Indicator Pop-up Window • Browse database • Browse alibi memory • Manuals Service level • Browse eventlog • Browse logfiles • Show last fatal system error • Screenshot • Export Alibi memory • Export Sorie Pool • Backup and restore setup data • Upload language files	Hanne 197 State

- Double-click the device icon.
- The menu appears on the screen. The device name entered under [host name] appears under the header in brackets.

Configuration

- [Remote Configuration (VNC)]
- [Remote Configuration (VNC) Pop-up Window]
- [Configuration Printout]

View

- [Indicator]
- [Indicator Pop-up Window]
- [Browse Database]
- [Browse alibi memory]
- [Manuals]

For device operation using the VNC program without additional installation of VNC; see Chapter 5.6.5.

Can be used for displaying the configuration printout; see Chapter 13.1.

Displays the weighing point in a status window; see Chapter 6.1.13.1.

Browse the application-specific database; see Chapter 6.1.13.2.


Browse the Alibi memory; see Chapter 6.1.13.3.

PDF files are saved to the SD card; see Chapter 6.1.13.4.

	Note	Some functions require additional rig	hts.
		When user management is activated, on the website" and the appropriate s	the logged in user must have rights for "Use functions system rights.
•	[Browse eve	ntlog]	Browse event log; see Chapter 6.1.13.5.
•	[Browse log	files]	Browse, display, copy, print log files; see Chapter 6.1.13.6.
•	[Show last f	atal system error]	Browse, display, copy, print the error log; see Chapter 6.1.13.7.
•	[Screenshot]]	Saves a screenshot; see Chapter 6.1.13.8.
٠	[Export data	ibase]	Export the database as an XML file to a selected folder; see Chapter 6.1.13.9.
٠	[Export Alib	i memory]	Export the Alibi memory as an XML file to a selected folder; see Chapter 6.1.13.10.
٠	[Export serv	ice report]	Export the service report as an XML file to a selected folder; see Chapter 6.1.13.11.
•	[Backup and	l restore setup data]	Create a backup and restore setup data; see Chapter 6.1.13.12.
٠	[Upload lang	guage files]	Upload language files to the device; see Chapter 6.1.13.13.

Service level

6.1.13.1 Displaying Weighing Points in a Table




- Click on [Weighing Points] under "View."
- \triangleright A status window with weighing point appears.
- ► Click on the symbol ← to return to the menu window.
- Click on [Weighing Points Pop-up Window] under "View."
- A status window with weighing point appears in a separate window.
- ► Click on the symbol ⊠ to return to the menu window.

6.1.13.2 Displaying the Application-specific Database

- Click on [Browse Database] under "View."
- ▷ A table appears. Click on the entries in the table to display the corresponding content.
- \blacktriangleright Click on the symbol $\overleftarrow{\leftarrow}$ to return to the menu window.

6.1.13.3 Browsing the Alibi Memory



6.1.13.4 Displaying Manuals

- Click on [Manuals] under "View."
- ▷ Several files are listed. Click on a file to view its contents.
- Click on the symbol \leftarrow to return to the menu window.

6.1.13.5 Browsing the Event Log

The log is a table showing the individual events on the device. This log can be used to analyze any possible problems.

The three event types are:

- Error _
- Info
- Warning _

The four source types are:

- [Fatal error] _
- [Setup] _
- [Power system] _
- [Indicator]
- Click on [Browse Eventlog] under "Service level."
- ▷ The "Eventlogger" window opens.

Eventlogger

To refresh the event view press Refresh reading the events. If you do not want to show all events press Stop reading the events. There are 3 different types of events (Error, Info, Warning) and 4 different sources (Fatalerror, Setup, Powersystem, Indicator).

Refresh reading the events

Stop reading the events

Show 10 💌 entries				Search:
Title	≎ Type	≎ From ≎	Date 🔹	Description \$
Event	Warning	Indicator	2014-12-17 18:09:59	Negative input
Event	Warning	Indicator	2014-12-17 18:09:11	Overload off
Event	Warning	Indicator	2014-12-17 18:09:09	Overload on
Event	Info	Setup	2014-12-17 18:07:11	new vnc connection from 172.24.20.91
Event	Info	Setup	2014-12-17 17:39:21	network settings changed
Event	Info	Setup	2014-12-17 17:38:43	parameter for wp=A save , user=Admin
Event	Info	Setup	2014-12-17 17:38:32	span set with load wp=A, user=Admin
Event	Info	Setup	2014-12-17 17:37:56	deadload with load wp=A, user=Admin
Event	Info	Setup	2014-12-17 17:37:51	step set wp=A, user=Admin
Event	Info	Setup	2014-12-17 17:37:45	max set wp=A, user=Admin
Showing 1 to 10 of 271 entries				First Previous 1 2 3 4 5 Next Last

 \blacktriangleright Click on the symbol $\overleftarrow{\leftarrow}$ to return to the menu window.

6.1.13.6 Browsing Log Files

Log files can be used to analyze any possible problems.

- Click on [Browse logfiles] under "Service level."
- ▷ Several files are listed. Click on a file to view its contents.
- Click on the symbol (\leftarrow) to return to the menu window.

6.1.13.7 Displaying a Log of the Last System Error

Logs can be used to analyze any possible problems.

Note	This data can also be found in the servi	ice r	report.
PC=C0004102 D0=02CFA0C0 D1=000000CC D2=00000002 D3=00000000 D4=00000000 D5=41296500 D6=00000000 D7=00000000 C00040F2:202 C00040F6:254 C00040FE:206 C0004102>4C6A C0004108:240	\$014): Reserved FRM=4014 SR=2000 A0=0000003A SP+00=8000766C A1=41FCAF3A SP+04=8000762B A2=80000B7C SP+08=000491F0 A3=00000006 SP+12=0000005 A4=0000066 SP+16=00004552 A5=412C16F4 SP+20=41296500 A6=800076F0 SP+24=80000EF6 A7=800075AC SP+28=8000766C 2F0010 MOVE.L \$0010(A7),D0 400020 MOVE.L D0,\$0020(A2) 10800 MULS.L D1,D0 5A0028 MOVEA.L \$0028(A2),A0 0000001C DIVU.L \$001C(A2),D0		Click on [Show last fatal system error] under "Service level." The last saved system error appears. Click on the symbol ← to return to the menu window.

6.1.13.8 Saving a Device Screenshot



- Switch to the desired display (in this case, weighing).
- Click on [Screenshot] in the WEB menu under "Service level."
- The device display is shown on the notebook/ screen.
- Right-click on the display and save to the desired folder via the "Save image as..." option.
- Click on the symbol $\overleftarrow{\leftarrow}$ to return to the menu window.

6.1.13.9 Exporting a Database

This function allows a database to be exported as an XML file to a selected folder.

- ▶ Click on [Export database] under "Service level."
- \triangleright An input window may appear.
- ▶ Enter and confirm the user name and password if necessary.
- \triangleright The file download window of the internet browser appears.
- ► Click [Save].
- Select a folder to store the XML file.
- ► Click [Save].

6.1.13.10 Exporting the Alibi Memory

This function allows the Alibi memory to be exported as an XML file to a selected folder.

Example: "Internet Explorer"

- Click on [Export Alibi memory] under "Service level."
- \triangleright An input window may appear.
- Enter and confirm the user name and password if necessary.

Select alibi records to export. First record is #16. Last record is #20.

First sequencenumber (1620)	16	•
Last sequencenumber (1620)	20	•
Start export		

- \triangleright A page for selecting export alibi entries appears.
- ► Enter the desired range of data records (in this case, 1–51) and click [Start export].
- ▷ The file download window of the internet browser appears.
- Click [Save].
- ▶ Select a folder to store the XML file.
- ► Click [Save].
- ► Click on the symbol ← to return to the menu window.

6.1.13.11 Exporting the Service Report

This function allows the service report to be exported as an XML file to a selected folder. If an error occurs, this file can be sent to customer service.

Example: "Internet Explorer"

- Click on [Export service report] under "Service level."
- ▷ An input window may appear.
- Enter and confirm the user name and password if necessary.
- ▷ The file download window of the internet browser appears.
- Click [Save].
- Select a folder to store the XML file.
- Click [Save].

6.1.13.12 Backing Up and Restoring Setup Data

This function makes it possible to:

- create a backup with setup, user, calibration, and application data on the PC.
- restore the setup, user, calibration, and application data on the device.

Note This function cannot be used to back up the databases on the PC and restore them in the instrument. This is possible only under [System Maintenance] in the system menu.

- Click on [Backup and restore setup data] under "Service level."
- \triangleright An input window may appear.
- Enter and confirm the user name and password if necessary.



[Restore]



PR5500 Maxxis 4 (PR5500-967EA9)

Backup

Press Dackup to copy all configuration data from "PR5500-967EA9" to your local pc Restore

Select a .xml-File Datei auswählen setup-PRS5...93913.xml

Press Restore to save all configuration data to "PR5500-967EA9"

[Backup]

- ▷ The backup and restore menu appears.
- Click on [Backup] to create a backup.

Example: "Internet Explorer"

- Click the tab of the created file.
- \triangleright The XML file is opened.
- ► Save the XML file under [File] [Save as...] in a selected folder.
- Select [Save].
- \triangleright The backup is saved to the selected folder.
- Close the XML file under [File] [Close].
- Click on [Browse] to select an XML file to be restored.

Example: "Internet Explorer"

- The file upload window of the internet browser appears.
- Select the XML file (e.g., setup-PR5500-967EA9-20141218-093913.xml).
- Select [Open].
- ▷ The file name is displayed in the selection window.
- ► Click on [Restore].
- ▷ The setup data is saved to the device.

Possible Error Messages

	×	The displayed message appears when the user is not logged off.
Device is in use! Please log out and try again.		
	ОК	
	×	The displayed message appears when the CAL switch is closed and/or "Settings locked" is active.
Cal-Jumper closed or settings locked.		
	ОК	

6.1.13.13 Loading Language Files

This function allows language files to be loaded.

Note	This function allows translations to be tested during development. The files are not
	permanently saved and are lost when the next cold start occurs. To permanently save the
	files, the language files must be loaded onto the instrument together with the application via
	"Update software".

PR5500-967EA9

Upload language file

- 1. Select .mo-file with translated strings
- 2. Do submit file to device
- 3. Select language in Setup/Software parameter

.mo-File	Datei auswählen	Keine ausgewählt
Upload		

- Click on [Upload Language Files] under "Service level".
- \triangleright A selection window appears.
- Click on [Browse], select the desired mo files, and click [Upload] to load the files onto the device.
- ► Click on the symbol ← to return to the menu window.


6.2 Alibi Memory

6.2.1 General Information

Note	A license is required for this function; see Chapter 5.19.8.
	If CAL switch 1 is closed or if the parameters ,W&M' and ,Settings locked' are set for a weighing point, the alibi memory cannot be deleted and the settings are not changed.
	The alibi memory must be set before verifying the weighing points!

6.2.2 Erasing the Alibi Memory

This function is required to automatically overwrite individual data sets or manually delete the entire Alibi memory.



6.2.2.1 Overwriting Data Records Automatically

	5	,		
- (Alibi memory	Qadmin	\triangleright	A selection window appears.
Tidy up records	•	enabled		Confirm the selection.
Default	Erase	Save		
enabled disabled by age	Alihi memory			A selection window appears. If "enabled" is selected, the oldest data set in the entire Alibi memory will automatically be overwritten. If "disabled" is selected, data sets must be deleted manually when the Alibi memory is full. Select and confirm the options, e.g., "by age."

Alibi memory Oadmin Tidy up records (10 123 Alibi memory keeps 90 days		i 🖽 123	indicate how old automatically ov Confirm the ent	er of days using the keybo l a data set must be in or verwritten.
Default	Erase	Save	Note	If the [Default] soft key pressed, this number is the default value.

6.2.2.2 Deleting the Alibi Memory Manually

₩ ‡¶		Alibi memory	@admin
Tidy	y up records	Þ	enabled
Def	fault	Erase	Save
↓		Alibi memory	<u>O</u> admin
	y up records	Alibi memory	@admin enabled
	y up records	· · · · · · · · · · · · · · · · · · ·	
	y up records	· · · · · · · · · · · · · · · · · · ·	
	y up records	· · · · · · · · · · · · · · · · · · ·	
	y up records	?	
		P P WARNING!	enabled
		?	enabled
		P WARNING! will erase all records in th	enabled
		P WARNING! will erase all records in th	enabled
		ARNING! WARNING! will erase all records in the memory.	enabled e alibi

- board to order to be
- tings.

Note	If the [Default] soft key is pressed, this number is reset to the default value.
------	--


Press the [Delete] soft key to delete the entire Alibi memory manually.


- \triangleright A prompt window appears.
- ▶ Press the [Continue] soft key to confirm the manual deletion.


6.2.3 Browsing the Alibi Memory

The following options are available:

- Search by a specific date
- Search by a specific sequence no.
- Display the status of the Alibi memory







	Alibi memory c date in alibi memor n sequence number ry	©admin Ƴ ∙	Select and confirm [Status alibi memory] using the cursor.
Image: style="text-align: center;">Sta Records stored First record Last record Used memory Estimated free record	atus alibi memory	@admin 8 16.12.2014–12:20:56 18.12.2014–11:00:06 0.01 % 156991	The info window for the Alibi memory appears. Press the ESC/EXIT key to return to the previous window.

6.2.4 Exporting and Printing Alibi Data Records See Chapter 6.1.6.

6.3 BIOS Menu

6.3.1 General Information

If the device cannot carry out a normal system start, the BIOS menu must be used.

Note The BIOS menu is in English, regardless of the selected language settings.

Requirements

- The supply voltage is disconnected.
- All LEDs have gone out.

If this is not the case, the connection to the standby battery must be interrupted with the power supply disconnected (pull the plug out carefully). Restore the connection afterwards.

Note The battery is located below the weighing electronics board WP-A.

6.3.2 Accessing the BIOS Menu

B Select device boot Warmstart Coldstart Recover	IOS BOOT MENU mode (continue from powerfail) ► (reset application) (fix unbootable system)		 Release the STOP key. 				
			OK to confirm the selection. up in the same way it does after				
			Note	This menu item is locked if a warm start is not possible. A warm start may not be possible for the following reasons: - Fatal system error - Faulty battery			
B	IOS BOOT MENU	[Co	oldstart]				
Select device boot Warmstart	(continue from powerfail)		Press the \checkmark key t	to select the line.			
Coldstart Recover	(reset application) ► (fix unbootable system)			OK to confirm the selection.			
		\triangleright	The device starts, application resta	, the database is cleared, and the rts.			
			Note	If the device starts successfully, an existing database backup, if there is one, can be re-imported (see Chapter 6.1.3).			

BIOS BOOT MENU	[Recover]
Select device boot mode Warmstart (continue from powerfail)	\blacktriangleright Press the \checkmark key to select the line.
Coldstart (reset application) Recover (fix unbootable system) >	▶ Press the \blacktriangleright key/ OK to confirm the selection.
	The overwrite protection statuses are checked (CAL switches and parameter ,Settings locked').
	This message appears if at least one CAL switch is closed.
CAL switch 1 is closed!	Open the CAL switch and press any key to check the statuses again.
Please open the cal switch and press any key. Press EXIT to cancel.	 Or Press the EXIT key to cancel the process and return to the BIOS menu.
Settings are locked for W&M WP A.	This message appears if the ,W&M' parameter has been set to another value besides ,none' for at least one weighing point and ,Settings locked' has been activated.
Continuing will change the calibration check number 2046138865! Press C, C, C and then OK to clear W&M and settings locked. Press EXIT to cancel.	Press the C key three times and then press the OK key to reset the ,W&M' parameter and ,Settings locked'.
	\triangleright The calibration check number changes.
	Or
	Press the EXIT key to cancel the process and return to the BIOS menu.

6.3.3 Troubleshooting Menu

-	
ERROR RECOVERY MENU Select error recovery option Restore last software from SD-Card	If all checks have been carried out, the troubleshooting menu appears.
Listen for FlashIt! Coldstart in safe mode	[Restore last software from SD-Card]
	▶ Press the \blacktriangleright key/ OK to confirm the selection.
	The last saved software image (bios, firmware, and application) is restored in the device.
ERROR RECOVERY MENU	[Listen for FlashIt!]
Select error recovery option Restore last software from SD-Card	Press the \checkmark key to select the line.
Listen for Flashit!	Press the \blacktriangleright key/ OK to confirm the selection.
Colostart in sare mode	 It is now possible to load software on the device via the network using the "FlashIt!" program; see also page page 326.
	[Coldstart in safe mode]
Select error recovery option Restore last software from SD-Card	\blacktriangleright Press the \checkmark key to select the line.
Listen for FlashIt! Coldstart in safe mode	 Press the ► key/OK to confirm the selection. The device starts in a mode where all settings (even language settings) are ignored.
Safe mode activated All settings have been ignored until now. In the maintenance level you can - Export a service report1 To record the faulty conditions for later inspection. - IBackup settings1 Although setting were not loaded, you can make a backup for later review. - IRestore settings1 Load settings from another backup to return the device to some wellknown settings. - IFactory reset1 Permanently reset all settings to default.	 A help window appears. Press the EXIT key to close the help window and switch to the system maintenance menu.

System maintenance (safe mode) Backup Restore Export Import Alibi memory maintenance SD card maintenance Create service report Shutdown & Power off Update software Factory reset Test hardware	 Press the ▼ key to select the desired menu item. Press the ► key/OK to confirm the selection. The rest of the procedure is described in Chapter 6.1. Press the EXIT key to exit the system maintenance menu.
Operating ? Do a cold start to finish safe mode? Cancel Continue	 A prompt window appears. Press the [Cancel] soft key to select additional menu items in the system maintenance menu if necessary. Press the [Next] soft key to carry out a cold start.

7 ModBus Protocol

7.1 General Description

The J-Bus/ModBus protocol implemented in the device permits fast, simple and reliable communication between a PC or a PLC.


Device fully supports


- ModBus-RTU (via a serial interface), see Chapter 7.2
- ModBus-TCP (via a network interface), see Chapter 7.3
- ModBus-UDP (via a network interface), see Chapter 7.3

including functions 1, 2, 3, 4, 5, 6, 8 (sub-function 0), 15 and 16.

J-Bus is a French 'clone' of the ModBus. There is a small difference: J-Bus addresses count from 0 (instead of 1) to hex FFFF (instead of dec. 9999). Some ModBus masters automatically subtract 1 before sending a message, and some ModBus slaves subtract 1 to get the requested address. Therefore the address access may shift by 1; this is the only point which must be taken into account. In everyday practice, no other problems when connecting J-Bus and ModBus devices should appear.

Binary data from and to the SPM of device are transmitted using this protocol. Any data exchange includes two telegrams: a command from the PC to device and a reply from device to the PC.





A reply is sent to each error-free command.

If the received command is correct but cannot be executed nevertheless (e.g. due to a faulty address or faulty data), an error telegram is the reply.

7.2 ModBus-RTU

A serial interface is used for connection. The telegram consists of four blocks:

$Addr_8$	Func ₈	<data></data>	Crc ₁₆			
Legend						
Addr ₈	Slave devic	e address within a	a range of 0 or 1 to) 247		
Func ₈	Function co	ode				
<data></data>	Additional	data (see Chapter				
Crc ₁₆	Checksum	of all preceding cl				
Note	A telegram these devic		executed by all M	odBus participa	nts, but replied	by none of

At 9600 baud, the reply time is typically 4 ms and a max. of 8 ms.

A faulty command received by device (e.g., parity error in the data, or CRC error) is ignored and no reply is sent. The pauses between the individual characters and a command must not exceed the 3.5-fold value of a character length; otherwise device detects a premature end of the command.

7.3 ModBus-TCP/UDP

Connection is via the network interface. The telegram consists of six blocks:

Trans ₁₆	Proto ₁₆	Size ₁₆	$Addr_{_8}$	Func ₈	<data></data>							
Legend												
Trans ₁₆		Sequential transaction number. This number is used by the device so that the reply can be assigned to the query.										
Proto ₁₆	Reserved for fut	Reserved for future upgrades, always 0 here.										
Size ₁₆	Number of follo	Number of following bytes										
Addr ₈	Normally, the de	vice address is not	used with ModBu	is-TCP/UDP.								
	It is used if Mod	Bus-TCP/UDP is co	nnected behind a	ModBusRTU gate	way.							
	The device ignores this parameter for ModBus-TCP/-UDP.											
Func ₈	Function code (s	ee Chapter 7.4)										
<data></data>	Additional data	(see Chapter 7.4)										

Telegrams can be exchanged using TCP or UPD via Port 502. Normally, this is a fixed setting in the ModBus-TCP master.

For UDP, the reply time is typically 4 ms and a max. of 8 ms. When network traffic is heavy, failed telegram transmissions must be expected. Suitable measures must be taken in the Modbus-UDP master to force a repeated transmission in the event of telegram loss.

With TCP, the typical response time is approx. 10 ms. With heavy network traffic, transmission can be delayed (max. 120 seconds for extreme network loads or for long transmission distances such as via the Internet). However, no telegrams are normally lost.

Comparison

ModBus-TCP	ModBus-UDP						
Reliable transmission:	Unreliable transmission:						
As long as the line is not interrupted, no telegram is lost.	With heavy network traffic or transmission over long distances, telegram loss must be expected.						
Low speed:	High speed:						
With transmission problems, transmission can be delayed considerably.	The reply is transmitted quickly, or not at all.						
Suitable for:	Suitable for:						
- Parameter transmission	- Transmission of dynamic values						
- Result logging	- Visualization						
- Non-time-critical process control	 Time-critical process control (requiring timeout handling) 						

7.4 Functions

Function 1 or 2: read n bits

Command	Function number	Address of 1st bit	Number of bits		
	1 byte	2 bytes	2 bytes		
Value range	1, 2	0, 8 , 16	8, 16, 24		

The bit address must always be the 1st bit of a byte. The number of bits to be read must not be smaller than 8 and must be a multiple of 8.

Reply	Function number	Number read. Bytes	Value of 1st byte	Value of 2nd byte	Value of last byte	
	1 byte	1 byte	1 byte	1 byte	 1 byte	-
			8th to 1st bit		Last bit	


The number of bits is limited by the telegram to 2008 bits (251 bytes). If there are more than 2008 bits, then an error telegram is sent as a reply.

Example of function 1 for reading the status bits of the scale (8 bits start at bit 32) with ModBus-RTU.

Command	1	1	0	32	0	8	CRC	CRC				
Reply	1	1	1	Х	CRC	CRC						
Example with Mo	odBus-T	CP:										
Command	47	11	0	0	0	6	0	1	0	32	0	8
Reply	47	11	0	0	0	4	0	1	1	X		
The individual byt	tes are s	hown.										
The read byte X				Bit $0 = bit 32 \text{ of SPM} = ADC \text{ error}$								
is interpreted as	follows:	llows: Bit 1 = bit 33 of SPM			of SPM =	= above	Max (ma	iximum	capacity	/)		
						:						
				Bit 6 =	bit 38 c	of SPM =	= weight	is stable	2			

Bit 7 = bit 39 of SPM = weight is below zero or above Max

Function 3 or 4: read n successive words



If the address of one of the words to be read is out of the permissible range (0 to 16383), an error message is sent as a reply (the address plus the number of words must not exceed 16384).

The number of words is limited by the telegram to 125 words (250 bytes). If there are more than 125 words, then an error telegram is sent as a reply.

Example of function 3 for reading a gross weight (D8 = W16) of 893 kg with ModBus-RTU:

Command	1	3	0	16	0	2	CRC	CRC					
					1	1		1	-	1			
Reply	1	3	4	0	0	3	125	CRC	CRC				
Example with ModBu	is-TCP:												
Command	47	12	0	0	0	6	0	3	0	16	0	2	
Reply	47	12	0	0	0	7	0	3	4	0	0	3	125

The individual bytes are shown.

Command				Address of the bit			Valu	Value of the bit			ys 0			
	1 byte			2 by	ytes		1 by	te		1 byt	e			
Value range	5			0 tc	0 127		0 or	255		0				
Reply	Functio			Add bit	Iress of	the	Valu	e of	the bit	Alwa	ys 0			
	1 byte		l	2 by	ytes		1 by	te		1 byt	e			
Example of function	5 for s	etting bi	t 11	3 (t	aring) v	vith M	odBu	s-RT	U:					
Command	1	5	()	113	255	(C	CRC	CRC				
									·]			
Reply	1	5	()	113	255	()	CRC	CRC				
Example with ModB	us-TCP:													
Command	47	13	()	0	0	, (6	0	5	0	113	255	0
					1	1					1	1		
Reply	47	13	()	0	0	(6	0	5	0	113	255	
The individual bytes	are sho	wn.												
Function 6: Writing	g a Woi	rd												
Command	Functio	on numb	er	W	ord add	ress	V	alue	of the v	vord				
	1 byte			2	bytes		2	byte	es					
Value range	6			0	to 63									
Reply	Functio	on numb	er	W	ord add	ress	V	alue	of the v	word				

Function 5: Writing a Bit

If the address is out of the permissible range (0...16383), an error message is sent as a reply.

2 bytes

2 bytes

1 byte

Function 8: Diagnosis

Reply

Command	Function number	Sub-function	Any value
	1 byte	2 bytes	2 bytes
Value range	8	0	

This function is intended for testing the communication.

Only sub-function 0 is supported.

The received command is sent as a reply.

Function number	Sub-function	Value of the command
1 byte	2 bytes	2 bytes

Function 15: write n successive bits

Command	Function number	Address of 1st bit	Number of bits	Number of bytes	Value of bits
	1 byte	2 bytes	2 bytes	1 byte	n bytes
Value range	15	0 to 127	8, 16, 24	1, 2, 3	
	•				\downarrow
	1st Byte	2nd byte	3rd byte]	Last byte
	8th to 1st bit				Last bit

8th to 1st bit

The bit address must always be the 1st bit of a byte. The number of bits to be read must not be smaller than 8 and must be a multiple of 8. The number of bits is limited by the telegram to 2008 bits (251 bytes). If there are more than 2008 bits, then an error telegram is sent as a reply.

 Function	Address of 1st	Number of
number	bit	bits
1 byte	2 bytes	

Example of function 15 with ModBus-RTU:

Command	1	15	0	64	0	8	1	3	CRC	CRC

Reply 1 15 0 64 0 8 CRC CRC	
---	--

Example with ModBus-TCP:

Command	47	14	0	0	0	8	0	15	0	64	0	8	1	3
			1	1										
Reply	47	14	0	0	0	6	0	15	0	64	0	8		

The individual bytes are shown.

Command	Function number					Numbe bytes	Number of bytes		e of s
	1 byte	2 bytes		2 bytes		1 byte		n byt	es
Value range	16	0 to 63		1 to 64		2 to 12	8		
	4								- \
	MSB	LSB	MSI	В			MSB		LSB
	1st word						Last wo	ord	
Reply	Function number	Address of 1 word		Number o words	of				
	1 byte	2 bytes		2 bytes					

Function 16: write n successive words

If the address is out of the permissible range (0 to 16383), an error message is sent as a reply (the address plus the number of words must not exceed 16384).

The number of words is limited by the telegram to 125 words (250 bytes). If there are more than 125 words, then an error telegram is sent as a reply.

Example of function 16 for writing the limit_1 switch-on point using value 893 with ModBus-RTU:

Command	1	16	0	48	0	2	4	0	0	3	125	CRC	CRC				
Reply	1	16	0	48	0	2	CRC	CRC									
Example wit	th Mo	dBus-1	ICP:														
Command	47	15	0	0	0	8	0	16	0	48	0	2	4	0	0	3	125
Reply	47	15	0	0	0	6	0	16	0	48	0	2					

The individual bytes are shown.

7.5 Error Messages

If a command was transmitted correctly, but cannot be executed because, e.g. the address is too high, an error message is sent as a reply to the command.

The error message has the following format:

Function number +128	Function number
1 byte	1 byte

The 2nd byte contains the received function number; the most significant bit is set additionally. Meaning of the error number:

1	The function number is unknown
2	The address is out of the permissible range
3	The data format is faulty (e.g. more data than specified in the number were written)

Example of an error message, which was generated by an invalid function number with ModBus-RTU.

Command	1	9	0	0	0	0	CRC	CRC		
						1				
Reply	1	137	1	CRC	CRC					
Example with ModB	us-TCP:									
Command	47	16	0	0	0	8	0	9	0	0

0

0

3

0

137

1

The individual bytes are shown.

47

16

0

Reply

0

0

7.6 Word Addresses

16	Gross weight, 1st byte (MSB)				Gross weight, 2nd byte											
17	Gross	weigh	t, 3rd b	oyte					Gross	weigh	t, 4th b	oyte (LS	5B)			
2	39	38	37	36	35	34	33	32	47	46	45	44	43	42	41	40
							1						1	I		
7	119	118	117	116	115	114	113	112	127	126	125	124	123	122	121	120

Address	Meaning
Read bits:	
32	ADC error
33	Above Max (FSD)
34	Above Max + n d
35	Below zero (minus sign)
36	Zero within ¼ d
37	Within the zero setting range
38	The weight is stable
39	The weight is below zero or above Max
Write bits:	
112	Set zero
113	Set tare
114	Reset tare

For additional bits, see the operating instructions of the respective application.

8 EW Com Protocol

This function enables the use of the following commands.

No license is required for its use.

Note	These commands can still be used for existing systems if available PR 16xx devices are being
	replaced.
	These commands may not be used for new systems.

8.1 Weight Function Commands

These commands only support weighing points with a max. of 6 digits before and a max. of 3 digits after the decimal point.

Command	Reply	Description
WG{A B C D}	QG{A B C D}vwwwwwemz	Read gross weight
$WN{A B C D}$	QN{A B C D}vwwwwwemz	Read net weight
WT{A B C D}	QT{A B C D}vwwwwwemz	Read tare weight
		vwwwwwe = Weight with a +/- sign and exponent (e.g. '002340' = 002.34 g; 001005 = 100 kg) e = Exponent:
		'5' = XXXXX; '4' = XXXX.X; '3' = XXX.XX; '2' = XX.XXX m = '1' = stability
		v = +/- sign and can be '-' or ' '
		z = '1' = tared; '2' = test is active; '4' = in ¼ d
		Possible error messages:
		E100@0 general error for @ see Chapter 8.3
		E30000 BCC error
		E50000 analog test active
		E60000 weighing point unknown
WZ{A B C D}	0	Zero device
		Possible error messages:
		E100@0 general error for @ see Chapter 8.3
		E30000 BCC error
		E60000 weighing point unknown
		E70000 weighing point tared or no standstill
WS{A B C D}	Q	Tare
WS{A B C D}vwwwwwe	Q	Preset tare
		Possible error messages:
		E100@0 general error for @ see Chapter 8.3
		E30000 BCC error
		E60000 weighing point unknown
		E63000 preset tare >MAX
		E70000 weighing point tared or no standstill

Command	Reply	Description
$WF{A B C D}$	Q	Reset tare
		Possible error messages:
		E100@0 general error for @ see Chapter 8.3
		E60000 weighing point unknown
		E70000 weighing point tared or no standstill
	Qlwwwww ddssnnnn	d = Unit, variable (mg, g, kg, t, lb, oz)
		ss = Scale interval (01, 02, 05, 10, 20, 50)
		nnnnn = Span in mV/V (01234 corresponds to 0.1234 mV/V)

8.2 Other Commands

Command	Reply	Description
ZSDTTMMJJJJJssmm	QZSD	Set date and time Possible error messages: E20000 telegram too long E60000 telegram too short
ZSC	QZSC	Reset communication
V	QV5500/00-vv.vv.vv B: nnnnnnnn	Version query vv.vv.vv = Version number nnnnnnnn = Board number

8.3 SPM Commands

Command	Reply	Description
mrx <aa><aa></aa></aa>	qmrx<0q>	Read SPM bit
mrb <aa><aa></aa></aa>	qmrb <dd></dd>	Read SPM byte
mrw <aa><aa></aa></aa>	qmrw <dd><dd></dd></dd>	Read SPM word
mrd <aa><aa></aa></aa>	qmrd <dd<dd><dd></dd></dd<dd>	Read SPM double word
mrb <aa><aa><nn></nn></aa></aa>	qmrb <dd></dd>	Read SPM bytes
mrw <aa><aa><nn></nn></aa></aa>	qmrw <dd></dd>	Read SPM words
mrd <aa><aa><nn></nn></aa></aa>	qmrd <dd></dd>	Read SPM double words
Length 1 can be omitted.		
msx <aa><aa></aa></aa>	q	Set bit
mcx <aa><aa></aa></aa>	q	Clear bit
msb <aa><aa></aa></aa>	q	Set byte
mcb <aa><aa></aa></aa>	q	Clear byte
msw <aa><aa></aa></aa>	q	Set word
mcw <aa><aa></aa></aa>	q	Clear word
msd <aa><aa></aa></aa>	q	Set double word
mcd <aa><aa></aa></aa>	q	Clear double word
mwx <aa><aa><0q></aa></aa>	q	Write SPM bit
mwb <aa><aa><dd></dd></aa></aa>	q	Write SPM byte
mww <aa><aa><dd></dd></aa></aa>	q	Write SPM word
mwd <aa><aa><dd><dd><dd><dd></dd></dd></dd></dd></aa></aa>	q	Write SPM D word
mwb <aa><aa><nn><dd></dd></nn></aa></aa>	q	Write nn SPM bytes
mww <aa><aa><nn><dd><dd></dd></dd></nn></aa></aa>	q	Write nn SPM words
mwd <aa><aa><nn><dd><dd><dd><dd><</dd></dd></dd></dd></nn></aa></aa>	q	Write nn SPM D words

Length 1 can be omitted. An AND/OR function is also possible.

Legend

(<aa> a character in binary code)

m	Memory command, binary
r,w,a,o,s,c	Read, write, AND, OR, set, clear
x,b,w,d	Bit, byte, word, double word
q	Confirmation
<99><99>	Address (high byte, low byte)
<dd></dd>	Data byte
<nn></nn>	Number of data
<0q>	1 bit
<dd></dd>	Several data bytes
In case of error t	he renty is e-xx

In case of error, the reply is e<xx><yy><zz>, see also Chapter 8.4.

NoteThe addresses in these telegrams are binary.The addresses in the list in the Chapter 'Fieldbus Interfaces' in the corresponding Applikation
Manual are decimal.

8.4 Error Messages for EW Com Commands

Errors	Description	Errors	Description
E20000	Error in telegram structure	E10010	Arithmetic overflow
E30000	BCC error	E10020	Overload
E40000	Hardware error messages	E10030	ADC hardware error
E50000	Analog test active	E10040	Weight > 5 digits
E60000	Wrong SPM address	E10050	No weight
E63000	Preset tare > MAX	E10060	No sense voltage
E70000	Tared weighing point or no stability	E10070	Mixed-up inputs

9 Repairs and Maintenance

Repairs are subject to inspection and must be carried out at Sartorius Intec. In case of defect or malfunction, please contact your local Sartorius Intec dealer or service center for repair. When returning the device for repair, please include a precise and complete description of the problem. Maintenance work may only be carried out by a trained technician with expert knowledge of the hazards involved and the required precautions.

9.1 Battery for Date/Time

The lithium battery for backing up the calendar/time chip is located on the main board.

The battery is activated before the instrument leaves the factory.

Note Check the date and time after first turning on the device and change if necessary.

Replacing the Battery

If the voltage drops below the specified minimum, or in case of defect, the battery must be replaced by Sartorius Intec customer service or by an equivalent trained technician. For details on disposal, see Chapter 10.

For details on battery lifetime, see Chapter 12.3.1.

If the battery needs to be changed, this is shown on the display.

9.2 Rechargeable Battery for Voltage Supply

This device contains an NiMH rechargeable battery. In the event of a power failure, the processor is supplied for approx. 1 min. in order to save the current state and shut down properly.

Changing the Rechargeable Battery

If the voltage drops below the specified minimum, or in case of defect, the battery must be replaced by Sartorius Intec customer service or by an equivalent trained technician. For details on disposal, see Chapter 10.

9.3 Solder Work

Soldering work on the instrument is neither required nor permitted.

9.4 Cleaning


	_	Prevent moisture from penetrating the interior.
	-	Do not use aggressive cleaning agents (solvents or similar).
<u>_•</u> _	-	For use in the food industry, use a cleaning agent suitable for that particular
⚠ Warning		working environment.
,	-	Spraying with water or blowing off with compressed air is not permissible.

- ▶ Disconnect the device from the power supply.
- ▶ Clean the device with a cloth lightly moistened with a soap solution.
- ▶ Wipe down the device with a soft, dry cloth after cleaning.

10 Disposal

If the packaging is no longer needed, it can be disposed of by local waste disposal authorities. The packaging is made from environmentally friendly materials, which are suitable for recycling.

For more information, please see the T&Cs.



In other countries, please consult with the local authorities.

11 Error Messages

11.1 Error Messages in Measuring Circuit

The weighing electronics can generate error messages, which are output on the weight display.

Display	Error and Possible Cause	Remote display
Arith. error	Internal arithmetic overflow: - incorrect calibration values due to incorrect calibration, for example	Error 1
Overload	Input voltage is higher than Max + (x d): - Wrong settings - Too much weight on the scale	Error 2
No signal	 Measuring input open: Input signal is higher than the permissible range of 36 mV. Measuring cable is interrupted (cable break detection) Other hardware defect 	Error 3
Value exceeds display	Measured value cannot be displayed. Example: 30,000 kg scale and weight unit toggle to mg. > 9,999,000 mg (= 9,999 kg) generates this error message.	Error 4
No sense voltage	No sense voltage: - Load cells not connected. - Sense line or supply line is interrupted. - Wrong polarity or sense voltage is low.	Error 6
Negative input	Negative input (< -0.1mV/V): - Wrong polarity of load cell signal. - Wrong polarity of supply voltage.	Error 7
No values from scale	 Internal weighing point: Input signal is higher than the permissible range of 36 mV. Cannot read weight values from ADC (analog-digital converter). Error in weighing electronics board Defective load cell Cable break 	Error 9
Test active	No gross weight value: - Test is not yet finished.	Error 10

Wrong serial number Only if CAL switch is closed.	 Weighing electronics board has been changed after calibration. Device is not calibrated. 	Error ?
Read config failed	 The stored configuration and calibration data are not read. Transfer data stored in backup device using [System maintenance]-[Restore]-[SD card] recreating data in process controller (see Chapter 6.1.3.1) Initially set weighing electronics (i.e. ,Internal weighing point') to ,not assigned', save and then assign. 	Error A
Warmup 123	Device in warm-up mode, approx. 30 s.	123
negative input negative	weight Indication range overload	
negatives Signal negatives (ewicht Anzeigebereich Max Überlas	st

11.2 Error Messages with xBPI Scales

11.2.1 Error Messages

Display	Error and Possible Cause Remote		
Overload	Input voltage is higher than Max + (x d): - Wrong settings	Error 2	
	- Too much weight on the scale		
Value exceeds display	The weight value is not displayed:	Error 4	
	- Too many digits have been set		
No weight value	The xBPI scale is not providing any usable weights.	Error 5	
	- Taring process cannot be completed.		
Incompatible units	Incompatible mass units:	Error 8	
	- Wrong calibration values by e.g. incorrect calibration		
No values from scale	No communication with xBPI scale:	Error 9	
	- Cable break		
	- Internal scale error		
	- The scale is not connected to the supply voltage.		
Wrong configuration	- Tare disabled	Error 13	
	- Tare 2 not allowed		
	- Application tare is too high		
Scale not ready	The scale is not ready for weighing:	Error <	
	- The instrument is in the warm-up phase.		
	- The instrument is in automatic taring mode.		
	- The instrument was switched on with the scale loaded.		
Wrong serial number	Serial number of scale does not match the number set in the	Error ?	
-	device.		
Read config failed	The stored configuration and calibration data are not read.	Error A	
	 Transfer data stored in backup device using [System maintenance]-[Restore]-[SD card] recreating data in 		
	process controller (see Chapter 6.1.3.1).		
	- Initially set weighing electronics (i.e. ,Internal weighing		
	point') to ,not assigned', save and then assign.		

11.2.2 Error during "Set zero" and "Set tare"

An error occurs in the LOAD ERROR variable only with actions SET_ZERO and SET_TARE. Possible error numbers are:

IND_STS_OK=0,	//! "OK" ok, didit	
IND_STS_NO_WPT=1,	//! "no wpt" specified wpt does not exist	
IND_STS_WPT_IN_USE=2,	//! "in use" weighing point is in use	
IND_STS_NOT_TARED=3,	//! "not tared" cannot get TARE or NETTO if not tared	
IND_STS_BAD_UNIT_EXPO=4,	//! "wrong expo/unit" bad unit	
IND_STS_RANGE_ERROR=5,	//! "range error"	
IND_STS_TEST_ACTIV=6,	//! "test active" test is active, no weights	
IND_STS_CALI_ACTIV=7,	//! "cali active" in calibration, no weights	
IND_STS_NO_STAND=8,	//! "no standstill" no standstill	
IND_STS_IS_REACTOR=9,	//! "is reactor" wp is a reactor	
IND_STS_NO_PHY_WPT=10,	//! "no physical weighing point assigned"	
IND_STS_NOT_DOSING=11,	//! "not in dosing mode"	
IND_STS_NOT_RESERVED=12,	//! "weighing point is not reserved"	
IND_STS_TARE_ACTIV=13,	//! "tare is active"	
IND_STS_NO_TEST=14,	//! "weighing point is not in test"	
IND_STS_DIMMED=15,	//! "weight is dimmed"	
IND_STS_WGT_ERROR=16,	//! "weight has error"	
IND_STS_NOT_READY=17,	//! "scale not ready"	
IND_STS_TARE_BELOW_ZERO=18,	//! "cannot tare below zero"	
PHY_WPT_STS_CMD_ERR= 101,		
PHY_WPT_STS_TIMEOUT= 102,	<pre>//! for xBPI: timeout in sending a command to the scale</pre>	

Display	Iay Error and Possible Cause	
Overload	Input voltage is higher than Max + (x d): - Wrong settings - Too much weight on the scale	Error 2
Value exceeds display	The weight value is not displayed: - Too many digits have been set	Error 4
Incompatible units	Incompatible mass units: - Wrong calibration values by e.g. incorrect calibration	Error 8
No values from scale	No communication with Pendeo load cell: - Cable break - Internal scale error - The scale is not connected to the supply voltage.	Error 9
Wrong configuration	The number of load cells does not match with the configuration.	Error 13
Scale not ready	 The scale is not ready for weighing: Min. 1 load cell gives an error status or is defective (no communication). 	Error <
Wrong serial number	Serial number of load cell does not correspond to the number set in the device.	Error ?
Warmup 123	Load cells in warm-up mode, approx. 30 s. Error @	
Read config failed	 The stored configuration and calibration data are not read. Transfer data stored in backup device using [System maintenance]-[Restore]-[SD card] recreating data in process controller (see Chapter 6.1.3.1). Initially set weighing electronics (i.e. ,Internal weighing point') to ,not assigned', save and then assign. 	Error A

11.3 Error Messages with Pendeo® Load Cells

11.4 Error messages with PR-Net Weighing Point


Display	Error and Possible Cause	Remote display
Wrong configuration	No IP address or no host name available.	Error 13

11.5 Error messages with Type ,Mettler-Scale' Weighing Point

Display	Error and Possible Cause	Remote display
Arith. error	Internal arithmetic overflow: - Parameter/calibration values don't match with Mettler-Scale values.	Error 1

11.6 Error Messages during Calibration

11.6.1 Determining the Maximum Capacity (MAX)



The maximum capacity of the scale can be increased retroactively.

This message appears when the measurement signal for the given maximum capacity would exceed the permissible input voltage.



The maximum capacity of the scale can be increased retroactively. When the capacity is reduced, however, a message appears when the new maximum capacity falls below the calibration weight ("calibrated at").

WP-A	Max	4000g	e=	2g
			пп	
→0 ←				
.		STOP]
 Ma	Se	t Max failed.		#min 1.0 g
Ma Sca	n	ot enough d		2.0 g
Dea				ע≪ נ
Ma				I ≫⊻⊽
cal				₿ ≫¥∿
Ser —	T	Ok		

This message appears if the selected resolution is too low, e.g. 5 kg.

This message appears when the selected resolution is so high that less than 0.8 internal counts per scale interval (d) are available.

Max	4000g	e=	29
	1		
	STOP		J
Se	t Max failed. too many d).0 g !.0 g
] ≫√⊽ ≫⊻⊽
	Ok		9 × v 7 × v e
		Set Max failed. too many d	Set Max failed. too many d

WP-A


→0←

-

4∲₿

Ma

Sca Dea Ma cal Ser



3000g

STOP

Set Max failed. Cannot align weight to scale.

Ok

P=

2g

dmin

тg

1.0 g 1 ≫∿ 3 ≫∿⊽ 5 ≫√⊽

岁る

Max

This message appears if the maximum capacity [Max] of the scale range (weighing range) is not an integer multiple of the scale interval (1 d).


Weight units do not match, e.g. subsequent change of [Max] from kg to mg.

WP-A	Max	4500g	e=	5 9
→0←				
<mark>▶ -</mark>		STOP		J
Ma Sca		t Max failed. ugh µV∕d for		DO 9 5 9
Dea				ע≪י נ
Ma				₿ ≫¥∿
cal				₿ ≫≚∿
Ser —	Т	Ok T		3 ½;

This message appears if the selected resolution is so high that less than 0.8 μ V/e are available when "OIML/ NSC" has been selected.

After [OK] is pressed, the input value for the maximum capacity [Max] is canceled.

11.6.2 Determining the Scale Interval



This message appears if the maximum capacity [Max] of the scale range is not an integer multiple of the scale interval.

11.6.3 Determining the Dead Load





The dead load entered in mV/V plus maximum capacity in mV/V is higher than 3 mV/V (= 36 mV).

This message appears when the scale is not stable.

Remedy

- Check the mechanical function of the scale.
- Adapt the filter setting; reduce the resolution.
- Adapt the stability conditions.



This message appears if the measurement signal is negative (load cells connected with wrong polarity or defective) when determining the dead load with [by load].

Cause

Load cell connected with wrong polarity, or defective, or mechanical problem of the scale.



This message appears if the dead load entered in mV/V is higher than 5 mV/V.

11.6.4 Calibrating with Weight

WP-A	Max	3000g	e=	0.1g
+	7	<u>ac</u>	76	
▲		STOP		J
Ma Sca Dea		SPAN failed Jgh µV/d for		1.0 g 1.1 g 1 ™v
Ma not Ser) <u>**</u>
ву		Ok T		e

WP-A 3000g 2g Max ╋ ϚΤΟΡ 4**0** Jmin).O g Set SPAN failed. Ma no standstill 2.0 g Sca Dea °⊻v Ma ∎ ≫∛∿ cal my v 此 Ser b Ok by

3000g

Max

2g

Δ

This message appears when the scale interval is too small, if ,W&M' has been selected. Remedy:

Enter larger scale interval.

This message appears when the scale is not stable. Remedy:

- ▶ Check the mechanical function of the scale.
- Adapt the filter setting; reduce the resolution.
- Adapt the stability conditions.

This message appears if the load has been removed from the scale rather than added.



This message appears when an attempt is made to calibrate the scale using a weight that is heavier than the [Max].

WP-A	Max	3000g	e=	1g
+	J	44	ΓN	
<mark>▶</mark>		STOP		dmin
Ma Sca		t SPAN failed Neight >Max	l.).O g
Dea	•			.0 g 3 ≫⁄∿
Ma				<u>) %</u> v
cal				2 🖄
Ser	T	Ok		P 🖄
hv				P

WP-A

12 Specifications

12.1 Note on Using 'Free Software'

This device also contains "free software" in the firmware that is licensed under the GNU General Public License (GPL) Version 2, June 1991, and the GNU Lesser General Public License (LGPL) Version 2.1, February 1999. This device also contains "free software" from MIT and BSD.

This 'free software' was developed by third parties, is copyrighted, and is provided free of charge.

The license terms and conditions of Free Software Foundation, Inc in English are included in the delivery of the instrument.

The source text with the terms can be found on the enclosed CD-ROM.

12.2 Decoding the Serial Number

30 252 00015		
30	274	00015
Location no.: 30 = Hamburg	Code for the year/month: 274* = February 2012	Current number

* will count up according to the year group table of Sartorius

12.3 General Data

The following characteristics are valid after a warm-up time of at least 60 minutes (reference temperature: 23°C).

12.3.1 Battery for Date/Time

The lithium battery for backing up the date/time chip is activated before the instrument leaves the factory.

Lifespan	Device continuously connected to mains voltage	10 years
	Device not connected to mains voltage for some time (e.g. in storage)	7 years

12.3.2 Rechargeable Battery for Voltage Supply

The NiMH rechargeable battery continues to supply the processor for approx. 1 minute after a power failure has occurred, in order to save the current status of the device. The temperature of the rechargeable battery is monitored and can be displayed.

12.3.3 Display

Туре	Size	Resolution
TFT graphical color display	4.3"	480 x 272 pixels

12.3.4 Power Connection 230 V AC

Supply voltage	100 V-240 V AC	+10%/-15%	50/60 Hz
Max. power consumption	14 W/32 VA		
Primary fuse	2x 1 AT, 250 V, 5 x 20 mm; Littlefuse series 218, order no. 0218.0	01.P	

12.3.5 Power Connection 24 V DC

Supply voltage	24 V DC	±10%	
Max. power consumption	1 W		
Primary fuse	1x 2 AT, 250 V, 5 x 20 mm e.g. made by Schurter: SPT5>	20. order no : 0001 2507	

12.4 Effect of Ambient Conditions

12.4.1 Ambient Conditions

Temperature range				
	Ambient temperature for operation	-10 to +50°C		
	Ambient temperature for use in legal metrology	-10 to +40°C		
	Power-on temperature	> 0°C		
	Storage/transport	-20 to +70°C		
Moistur	e	< 95%, no condensation (in accordance with IEC 68-2)		
Protection class		IP65 front, IP20 rear		
Elevation		< 2000 m		

12.4.2 Electromagnetic Compatibility (EMC)

All data in compliance with NAMUR NE 21, EN 45501, and EN 61326.

Housing	Radio frequency electromagnetic fields (80-3000 MHz)	EN 61000-4-3	10 V/m
	Electrostatic discharge (ESD)	EN 61000-4-2	6/8 kV
Signal und	Fast transients (bursts)	EN 61000-4-4	1 kV
control lines	Peak voltages (surges) 1.2/50 μs	EN 61000-4-5	1/2 kV
	Conducted disturbances by radio frequency (0.15-80 MHz)	EN 61000-4-6	10 V
Mains inputs	Fast transients (bursts)	EN 61000-4-4	2 kV
	Peak voltages (surges) 1.2/50 µs	EN 61000-4-5	1/2 kV
	Conducted disturbances by radio frequency (0.15-80 MHz)	EN 61000-4-6	10 V
	Voltage dips	EN 61000-4-11	0/40/70% 20/200/500 ms
	Mains failure link	EN 61000-4-11	20 ms

12.4.3 RF Interference Suppression

Electromagnetic emission



EN 55011, Group 1, Class A For industrial areas

12.5 Mechanics

12.5.1 Design

Control cabinet housing made of stainless steel and aluminum, protection class IP65, rear IP20.

12.5.2 Dimensions

Width	186/192/199 mm
Height	90/96/103 mm
Depth	approx. 203 mm (incl. screen clamping rail)
12.5.3 Weights	
Net weight	2.2 kg

12.6 Documentation on the Enclosed CD

The enclosed CD has a directory containing the following documents:

- Eu Declaration of Conformity
- Manuals

13 Appendix

13.1 Configuration Printout

ien eeniguaaie			
	5500 :28.01.2015 16:08:08	F2 key	: Toggle weight unit
Hardware	: PR5500/00	General devices	
	: 2014-05-07		
Production number	: 1011-104711-000001	Remote display	: not assigned
Bios	:Rel 01.00.01.249020		
Firmware	2015-01-14 07:53 :Rel 01.00.01.249118 2015-01-15 14:13	ModBus-RTU master	: not assigned
Basic	: Rel 01.00.06.58	PC via EW-Com	: not assigned
	2015-01-15 10:59 : 362184361		· · · · · · · · · · · · · · · · · · ·
		Printer	: Network printer
			: LPR (Port 515)
HW options		Printer type	:Generic PCL5 (unico
		Queue name	: lp0 : 172.24.20.83
	RS-485/RS-485	IP address	: 172.24.20.83
	: 2012-08-06		
	: 1208-270039-900010		
	Digital I/O	Add. application de	evices
	: 2014-02-26		: not assigned
	: 1011-101999-000004	iiekee princer	· not assigned
	-empty-		: Network printer
			: LPR (Port 515)
	weighing electronic		:Generic PCL5 (unico
	: 2014-05-14	Queue name	
Production number	: 1011-100815-000002	IP address	: 172.24.20.83
Operating paramete	rs		
Operating		Network settings	
External keyheard	:(en) English	HW address	: 00:90:6C:96:7E:A9
	l:English QWERTY	HW address Host name	: 00:90:6C:96:7E:A9 : PR5500-967EA9
Input method	l:English QWERTY : Pinyin	HW address Host name use DHCP	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes
Input method Screensaver	l:English QWERTY : Pinyin : after 10 minutes	HW address Host name use DHCP Web server enabled	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes
Input method Screensaver Keyclick sound	l:English QWERTY : Pinyin : after 10 minutes : no key click	HW address Host name use DHCP Web server enabled VNC access enabled	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes
Input method Screensaver Keyclick sound	l:English QWERTY : Pinyin : after 10 minutes	HW address Host name use DHCP Web server enabled VNC access enabled	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes
Input method Screensaver Keyclick sound Coldstart with STO Programming	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds	HW address Host name use DHCP Web server enabled VNC access enabled VNC client	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds	HW address Host name use DHCP Web server enabled VNC access enabled VNC client	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming Software download	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled	HW address Host name use DHCP Web server enabled VNC access enabled VNC client	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming Software download	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming Software download Label/Language down	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming Software download Label/Language down Operational keys	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : Yes : 255.255.255.255
Input method Screensaver Keyclick sound Coldstart with STO Programming Software download Label/Language down Operational keys	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled n: enabled	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : 255.255.255.255 ections : Alibi :hhnfs01.sartorius.c
Input method Screensaver Keyclick sound Coldstart with STO Programming 	<pre>l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled n: enabled d: off :set tare & reset ta</pre>	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : 255.255.255.255 ections : Alibi :hhnfs01.sartorius.c
Input method Screensaver Keyclick sound Coldstart with STO Programming 	l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled n: enabled d: off :set tare & reset ta : only when not tared	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : 255.255.255.255 ections : Alibi : hhnfs01.sartorius.c : teams :D_Manuals/Share_PR5 : SARTORIUS
Input method Screensaver Keyclick sound Coldstart with STO Programming 	<pre>l:English QWERTY : Pinyin : after 10 minutes : no key click P: for 3 seconds : enabled n: enabled d: off :set tare & reset ta</pre>	HW address Host name use DHCP Web server enabled VNC access enabled VNC client Network share conne ===================================	: 00:90:6C:96:7E:A9 : PR5500-967EA9 : Yes : Yes : 255.255.255.255 ections : Alibi :hhnfs01.sartorius.c : teams :D_Manuals/Share_PR5

Appendix

Password	• *******	License settings
		Board number : 36218436
Backups		OPC server license : 757170
		Dosing license : 397206
Connection name	: Backups	Alibi license : 802669
Server	:hhnfs01.sartorius.c	Application license: 152027
Share name on ser	ve: teams	Basic with Tilt co
Folder path	:D Manuals/Share PR5	
Domain	: SARTORIUS	
User name	: Monika.Eschner	Weighing point A :Internal weighing
Password	********	
		WP serial number : 46460599
		Last change :2015-01-28 15:59:2
Exports		Calibration check n: 161971695
		Max : 3000.00
Connection name	: Exports	300000
Server	:hhnfs01.sartorius.c	Scale interval : 0.01
Share name on ser		Dead load at : $+0.040564 \text{ mV}^{-1}$
Folder path	:D_Manuals/Share_PR5	103.3805 g
Domain	: SARTORIUS	Max at : +1.177127 mV/
User name	: Monika.Eschner	3000.0000 g
Password	• * * * * * * * * * *	calibrated at : 2516.50
		+0.987413 mV/
		Sensitivity : 9.81 cnt/
ONECLICKUPDATE		0.047085 uV/
Connection name	: ONECLICKUPDATE	Units
Server	: 172.24.22.198	
Share name on ser		Number of units : 1 weight uni
Folder path	:	
Domain		
User name	•	
Password	•	Parameters
IUSSWOID	·	
		Settings locked : of
Reports		W&M : non
		Measurement time : 160 m
Connection name	: Reports	Digital filter : no filter
Server	:hhnfs01.sartorius.c	External load cell : above 8
Share name on ser		
Folder path		Standstill range : 1.00
Domain	: SARTORIUS	Tare timeout : 2.5
User name	: Monika.Eschner	Zeroset range : 50.00
Password	• * * * * * * * * * *	Zerotrack : Ye
		Zerotrack range : 0.25
		Zerotrack step : 0.25
Software		Zerotrack time : 1.0
		Overload : 9
Connection name	: Software	Minimum weight : 20
Server	:hhnfs01.sartorius.c	Range mode : single rang
Share name on ser	ve: teams	
Folder path	:D_Manuals/Share_PR5	
Domain	: SARTORIUS	
User name	: Monika.Eschner	
Password	********	

13.2 Test Printout

▶ Test line width and change if necessary.


▶ Check line coding and change in printer if necessary.

Note	Printer may not be able to output
	all characters.

13.3 Alibi Printout

Sequence number	:	#000027
Date/Time	:2015-01-11	
Serial number		2564616265
G		1550.3 g>
NET		<u>_</u>
T	: A	0.0 g
PR 5500 ALIBI		
Sequence number	:	#000028
Date/Time	:2015-01-11	L-11:07:08
Serial number	:	2564616265
G		1550.5 g>
NET		1550.5 g>
Т	: A	0.0 g
PR 5500 ALIBI	• 11	0.0 9
Sequence number	:	#000029
Date/Time	:2015-01-11	1-11:12:44
Serial number	:	2564616265
G	: A	<0.1 g>
NET	: A	<0.1 g>
Т	: A	0.0 g
PR 5500 ALIBI		2
Sequence number	:	#000030
Date/Time	:2015-01-11	L-11:15:03
Serial number	:	2564616265
G	: A <2	1000.2 g>
NET	: A <2	1000.2 g>
Т	: A	0.0 g
PR 5500 ALIBI		2
Sequence number	:	#000031
Date/Time	:2015-01-11	
Serial number		2564616265
G		2516.6 g>
NET	: A <2	2516.6 g>
Т	: A	0.0 g
PR 5500 ALIBI		
Sequence number	:	#000032
Date/Time	:2015-01-18	3-14:44:06
Serial number	:	2564616265
G	: A	<-0.4 g>
NET	: A	<-0.4 g>
Т	: A	0.0 g
PR 5500 ALIBI		
Sequence number	:	#000033
Date/Time	:2015-01-18	3-14:44:37
Serial number	:	2564616265
G	: A	<-0.4 g>
NET	: A	<-0.4 g>
Т	: A	0.0 g
		-

13.4 LEDs




LED	Function	LED	Function
1	ADC supply voltage +9 V	6	3.3 V
2	ADC supply voltage -9 V	7	Main supply voltage 24 V
3	5 V	8	5 V buffered
4	300 mA rechargeable battery current, illuminates when charging	9	3.3 VCC buffered
5	60 mA rechargeable battery current, illuminates when charging	10	USB supply (not shown) The LED is positioned below the carrier card for the option cards.

13.5 Terminal Coding

The combinatorics defined during the order process are used to encode the corresponding connectors before their delivery. The connectors only need to be encoded subsequently if plug-in cards are supplied after the original delivery.

The coding position for the individual cards is described in Chapter 4.4.

Procedure



- ▶ Remove terminal (6) from terminal block (4).
- ▶ Disconnect coding pin (1) from coding profile (2).
- Insert coding pin (1) into the corresponding slot (3) of terminal block (4).
- Remove (pinch off) coding ridge (5) on terminal (6).
- Re-insert terminal (6) into terminal block (4).

13.6 Exchanging the Plug-In Cards

13.6.1 Safety Information

 Before a plug-in card is inserted/removed, it is essential that

 the device is shut down properly (menu [Operation]-[System maintenance]-[Shutdown & Power off]).

 the device is disconnected from any power sources.

 all LEDs have gone out.

13.6.2 Optional and Fieldbus Cards



Note

If an option card has to be replaced by a fieldbus, the carrier plate (1) must be reversed!

- ▶ Insert all plugs again and switch on the device.
- ▷ Once the plug-in cards are replaced the device will detect them automatically.

Note The installed plug-in cards can be displayed under [Operation]-[System information]-[Show HW options].


4 9	Show hardware options	Dadmin	
Built-in		R5232	Interfaces (fixed installation)
Option-1	PR5900/04	RS-485/RS-485	Slot for optional card 1
Option-2	PR5900/17	Digital I/O	Slot for optional card 2
Option-FB		-empty-	Slot for fieldbus cards: in this case [-empty-] is displayed because
WP A	PR5900/W1	weighing electronic	no fieldbus card is installed.
			Internal weighing electronics A
			5 5
Info	Monitor		

13.7 Replacing the Device


When replacing a faulty device, the data on the faulty device can be completely imported into the new device by plugging the SC card of the old device into the new device.

Settings and database can restored from the SD card (backup), see Chapter 6.1.3.1.

If the licenses (including board number) are also transferred to the new device, the SIL chip of the old device must also be connected to the new device.



$\underline{\land}$	 Before a component is inserted/removed, it is essential that the device is shut down properly (menu [Operation]-[System maintenance]- [Shutdown & Power off]).
⚠ Warning	 the device is disconnected from any power sources. all LEDs have gone out.



- Dismount the complete carrier plate (2).
- Remove the SIL chip (1) and SD card from the faulty device and insert in the replacement device.
- Switch on the device.
- Press the STOP and EXIT keys at the same time to trigger a cold start (for presets see Chapter 5.19.3).

WP-A	Max	3000g	d=	0.01g
-		0.	1] _
09 <u>, , , ,</u>	to restore SD card fr	s function, if the software om a defectiv	e of the v devic	30009
SD card dom	for the de	vice as a repl fective devic		
Accept SD ca Use SD card		he software		•

- \triangleright A selection window appears.
- Select and confirm the menu item [Use SD card to update the software].
- ▷ The device installs the BIOS, firmware, and application from the SD card.
- A prompt window appears if no database file is found in the folder.
- Press the [Yes] soft key to restore the database from the faulty device in the replacement device.
- Transfer additional settings; see Chapter 6.1.3.1.

13.8 Replacing the SD Card

Note

Only Sartorius-supplied SD cards may be used. There is no warranty for third-party cards.

WP-A	Max	3000g	d=	0.01g	1
_		0.	1) _g	
09	defect SD replaced a	s function, if card has bee and the new c s permanent	2n 🖊	30009	
SD card do					
Accept SD c	ard without	updating sof	tware	۱.	
Use SD card to update the software					

- Export the data from the device onto a USB stick, see Chapter 6.1.4.1.
- Remove the defective SD card.
- ▶ Insert the new SD card.
- Only if the new card has already been used in another device: Press the STOP and EXIT keys at the same time to trigger a cold start.
- Only if the new card has already been used in another device: Select and confirm the menu item [Use SD card without updating software].
- Import the data from the USB stick into the device, see Chapter 6.1.5.1.

Sartorius Mechatronics T&H GmbH Meiendorfer Straße 205 22145 Hamburg, Germany Tel: +49.40.67960.303 Fax: +49.40.67960.383 www.sartorius-intec.com

© Sartorius Mechatronics T&H GmbH All rights are strictly reserved Printed in Germany